



# 190i & 190s Series

Intelligent Weighing Indicators

Operation Manual (Full Version)



PLEASE READ THIS MANUAL VERY CAREFULLY  
BEFORE OPERATING THIS INSTRUMENT

***Specifications subject to change without prior notice***

V219 October 2016



# Content

1. Reminders .....	8
1.1 Metrological Legislation .....	8
1.2 Seal & Serial Number .....	8
1.3 Warm Up time .....	8
1.4 Placing the weighing platform.....	8
1.5 Cautions.....	8
1.6 Support & Service .....	9
2. Specifications .....	9
3. Keys, Display & Connections .....	10
3.1 Keys & Display Indicators .....	10
3.2 Connection Points.....	13
4. Power & Connections.....	14
4.1 Power Adaptor .....	14
4.2 Built-In Rechargeable Battery.....	14
4.3 Connect with Weighing Platform or Load Cell Junction Box .....	14
4.3.1 Load cell connector pin assignment .....	15
4.4 Comports on Instrument .....	15
4.5 Comports Pin Assignment .....	15
4.6 Control Output Port.....	16
5. Initial Setup.....	17
5.1 Internal Functions & Settings.....	17
5.2 How to Enter & Select Internal Function.....	17
5.3 Key Function under Internal Function Mode.....	18
5.4 Internal Function Table .....	19
5.5 Setting Comport 1 & Comport 2.....	23
5.5.1 When comport is set as PC .....	24

5.5.2 When comport is set as CMD .....	25
5.5.3 When comport is set as Manual .....	25
5.5.4 When comport is set as Auto (Auto 1~3) .....	27
5.5.5 When Comport 1 is set as Scanner .....	28
6. Basic Operations .....	28
6.1 Power On, Inputting Operator Number & Power Off .....	28
6.2 Warm up Time & Set Weight to Zero When Unloaded .....	29
6.3 Keyboard Lock .....	29
6.4 Tare Modes .....	29
6.4.1 Manual Tare .....	29
6.4.2 Auto Tare (F12) .....	30
6.4.3 Repetitive Tare (F13) .....	30
6.4.4 Preset Tare (F63) .....	31
6.5 Select the Preferred Function Mode .....	31
6.6 Weight Units .....	32
6.6.1 Weight unit gram (g) .....	32
6.6.2 Select the Preferred Weight Unit .....	32
6.7 Memory Accumulation Function .....	33
6.7.1 Automatic Accumulation .....	33
6.7.2 Manual Accumulation .....	33
6.7.3 When data is accumulated to memory .....	33
6.7.4 Memory recall and clearance .....	34
6.8 Extended display mode .....	34
6.9 Tri-color Backlight .....	35
6.9.1 When powered by built-in rechargeable battery .....	35
6.9.2 When powered by external power adaptor .....	35
6.10 Customer & Product Code .....	35

6.10.1 Enter a customer & product code manually.....	35
6.10.2 Enter a customer & product code by scanner .....	36
6.10.3 Clear a customer & product code entered .....	36
6.10.4 Print a customer & product code entered .....	37
6.11 Enter a Key Command by Scanner .....	37
7. Weighing Mode .....	38
8. Piece Count Mode.....	38
8.1 Auto Unit Piece Weight Enhancement Function .....	38
8.2 Shift among Quantity, Average Piece Weight and Weight Info.....	39
8.3 Recall the Average Piece Weight before Powered Off .....	39
9. Action-Tare-Memory (ATM) .....	39
9.1 Description of ATM Mode.....	39
9.2 Basic ATM Settings .....	40
9.3 Start Using ATM .....	40
9.3.1 Weight Check Control for ATM.....	41
10. Peak Hold Mode.....	41
10.1 Description of Peak Hold Mode .....	41
10.2 Comport Settings for Peak Hold Mode .....	42
10.3 Start Using Peak Hold .....	42
11. Animal Weighing Mode.....	43
11.1 Description of Animal Weighing Mode .....	43
11.2 Basic Animal Weighing Settings .....	43
11.3 Start Using Animal Weighing.....	44
12. Static Check Function .....	44
12.1 Set LO & HI Limit .....	44
12.2 Hints for entering LO and HI limits: - .....	45
12.3 To Cancel Check Function .....	45

13. Dynamic Check Mode .....	45
13.1 Near Zero Function Description.....	45
13.2 Near Zero Value Illustration Diagram.....	46
14. Communication & Outputs .....	47
14.1 Print Output & Formats .....	47
14.2 Auto 1~3 Output & Formats .....	47
14.3 PC Output & Protocol .....	47
14.4 Sending Keyboard Commands from Computer.....	47
14.5 Requesting Operation Results & System Parameters by Computer ...	47
14.6 PC Software .....	48
15. Printing Formats .....	49
15.1 Lab 1 Print Format.....	49
15.2 Standard Lab 2 Print Format .....	50
15.2.1 Standard Lab 2 print format for Weighing & ATM mode .....	50
15.2.2 Standard Lab 2 print format for Piece count mode .....	51
15.2.3 Standard Lab 2 print format for Peak Hold mode .....	51
15.2.4 Standard Lab 2 print format for Animal weighing mode.....	51
15.3 Customizing Lab 2 Print Format .....	52
15.3.1 Print output format variants table.....	52
15.3.2 To edit custom Lab2 print output format .....	53
15.4 Lab 3 Data Base Output Format.....	54
15.5 Lab 4 Print Format.....	55
15.6 Lab 5 Print Format.....	55
16. Label Printing .....	56
16.1 Label Format Groups & Label File Names .....	56
16.1.1 FL1 (Label Format Group 1) .....	56
16.1.2 FL2 (Label Format Group 2) .....	57

16.2 Label Programming .....	57
16.2.1 Label programing information table .....	58
16.2.2 Label programming sample .....	60
16.3 Repetitive Printout .....	60
17. Built-in Battery & Recharging .....	61
17.1 Battery Operation Time .....	61
17.2 Symbols & Remaining Power .....	61
17.3 Battery Recharge .....	61
18. Error Codes .....	62
19. Daily Care & Maintenance .....	63
20. Downloading All Appendixes .....	63
21. Appendix A: - Keyboard Commands .....	64
22. Appendix B: - PC Output Protocols .....	65
23. Appendix C: - Operation Result Commands .....	68
24. Appendix D: - System Parameter Inquiry Commands .....	70
25. Appendix E: - TSC Printer Installation & Setup Procedures .....	79
E.1 Before Installation .....	79
E.1.1 Printer Installation .....	79
E.1.2 Uploading TCF File to Printer .....	80
26. Appendix F: - Create & Upload Label to TSC Printer .....	81
F.1 Selecting the Correct Edition for Bartender Software .....	81
F.2 Adding Information from Instrument to Label & Uploading to a TSC Printer .....	81

# **1. Reminders**

## **1.1 Metrological Legislation**

Because of metrological legislation, some metrological parameter settings are limited to be done by authorized personnel only. Do not attempt to change any parameters under internal function number F60 ~ F99. Contact your dealer for installation and technical assistance.

## **1.2 Seal & Serial Number**

This instrument is legal for trade only when it is sealed (and/or stamped) and bearing a serial number. Do not attempt to break the seal (or stamp) or serial number affixed to this instrument. No warranty service will be provided if the seal (or stamp) or data plate affixed to this instrument is damaged or removed. Always contact your dealer for after sales service.

## **1.3 Warm Up time**

- a. Allow warm up period of not less than 60 seconds before calibration and usage. The higher the setup resolution of the scale, the longer the warm up period is required. In most cases, 120 seconds is a safe warm up period for all applications. This warm up period is needed to energy all components to reach a stable status.
- b. The internal count value is deemed stable when the internal AD count varies less than 3 counts within 2 seconds.
- c. To read the internal AD count value, enter internal function F1. The internal AD count value of a not yet fully energized PCB will go up continuously.

## **1.4 Placing the weighing platform**

In order to obtain an accurate weighing result, the weighing platform must be placed on a strong and level surface. Avoid using the platform and this instrument and the weighing platform in any environment where excessive wind flow, vibration and extreme temperature change exist.

## **1.5 Cautions**

- a. The instrument is not an explosion proof device.
- b. The instrument is not a water proof device.
- c. Do not open the instrument, no user serviceable parts inside.



Always contact your dealer for service.

- d. Do not place this instrument in where shock, excessive vibration or extremes of temperature (before or after installation) exist.

## 1.6 Support & Service

Always contact your dealer for product information, after sales service and questions when in doubt.


## 2. Specifications

Capacity & Readability	<ul style="list-style-type: none"><li>• Free Setting</li><li>• Single or Dual Weighing Range</li></ul>
A/D & Internal Resolution	<ul style="list-style-type: none"><li>• 24 bit Low-Noise Delta to Sigma to Delta (<math>\Delta-\Sigma</math>) Analog-to-Digital Converter</li><li>• 3,200,000 Counts at 15 mV</li><li>• Minimum input per d = 0.05 <math>\mu</math>V</li></ul>
Weighing Range	Support both Single & Dual Weighing Range
Max. Tare Range	- Max (Subtractive Tare)
Power Source	<ul style="list-style-type: none"><li>• Built-in Rechargeable Battery = 6V, 4AH (190i); 6V, 5AH (190s)</li><li>• External Power Adaptor = DC 12V, 1A</li></ul>
Load Cell Connection	<ul style="list-style-type: none"><li>• Excitation Voltage = 5V DC</li><li>• Support both 4-wire &amp; 6-wire Load Cells</li><li>• Maximum Load Cell Connection = 10 x 350<math>\Omega</math> Load Cells or 20 x 700<math>\Omega</math> Load Cells</li></ul>
Battery Recharging & Protection	Intelligent Digital Controlled Progressive Charging System
Operation Environment	-10 ~ 40°C. Non-condensed. R.H. $\leq$ 85%

***Specifications subject to change prior to notice***

## 3. Keys, Display & Connections

### 3.1 Keys & Display Indicators



#### 1. On/Off

Press this key to turn this instrument on or off.

#### 2. Zero

Press this key to set weight displayed to zero when unloaded.

#### 3. Tare

Press this key to tare off the weight of a container.

#### 4. Function

Press this key to shift among various function modes.

#### 5. Unit<sup>1</sup>

Press this key to shift among various weight units.

#### 6. Set

Press this key to access internal function setting mode (F1~F29) or to prompt/introduce an operation parameter/value.

---

<sup>1</sup> Refer to F9 on how to enable/disable weight units.

## 7. **Preset Tare** <sup>2</sup>

Press this key to introduce a preset Tare value.

## 8. **Print/M+**

- When loaded: - Press this key to send print data out and/or 3 accumulate current value to memory.
- When unloaded: - Press this key to read total accumulated weight.

## 9. **Check Function**

Press this key to start check function and to enter value for Lo and Hi Limit.

## 10. **CE/x10**

Press this key: -

- to clear value entered during setting process, or
- to trigger the extended display mode<sup>4</sup>

## 11. **Battery Power/Level Indicator**

Visible to show: -

- When instrument is powered by built-in rechargeable: - remaining battery of the built-in rechargeable battery,
- When instrument is powered by external power adaptor: - Battery rechargeable recharging status.

## 12. **Weighing Range Indicator**

- **W<sub>1</sub> Indicator**<sup>5</sup>: - (When under dual weighing range mode) Visible when this instrument is operating at the first weighing range (W<sub>1</sub>).
- **W<sub>2</sub> Indicator**<sup>6</sup>: - (When under dual weighing range mode) Visible when this instrument is operating in the second weighing range (W<sub>2</sub>).

## 13. **Minus Indicator**

---

2 When F63 is set to ON.

3 Refer to F16 and F17 settings for details.

4 When F68 = OIML or NTEP.

5 Not visible when single range is selected.

6 This indicator will not appear when this instrument is in single range mode.

Visible when a negative value is displayed.

#### 14. **Gross/Net Indicators**

- **G:** - Visible when gross result is being displayed.
- **Net:** - Visible when net result is being displayed.

#### 15. **Stable Indicator**

Visible when weight value is stable.

#### 16. **Zero Indicator**

Visible when weight is = zero.

#### 17. **M+ Indicator**

Visible when memory contains of accumulated data.

#### 18. **Preset Tare & Product Code Data Indicator**

Visible when preset-tare value and/or product code has been entered.

#### 19. **Weight Unit indicators**

- kg = kilogram,
- g = gram,
- lb = pound.

#### 20. **Counting Function Indicators**


- PCS = Pieces (Piece Count Mode in function),
- kg/PCS and g/PCS = Weight per piece (when Piece Count Mode in function).

#### 21. **Numeric & Alphabetical Info Panel**


Numeric value and alphabetical Info are shown here.

### 3.2 Connection Points

190i Indicator



190s Indicator



**A. DC Jack Input for Indicator**

External power adaptor is plugged in here. Do not plug in any other power adaptor than the one which comes with this instrument.

**B. Reserved**

**C. Load Cell Connector**

Signal wires from load cell (or junction box) are connected here.

#### **D. Control Output Port**

- 190i: - Control output.
- 190s: - Thread through control put cable here.

#### **E. Comport 2<sup>7</sup>**

- 190i: - Communication comport 2 (serial).
- 190s: - Thread through comport 2 cable here.

#### **F. Comport 1<sup>8</sup>**

- 190i: - Communication comport 1 (serial or TTL)
- 190s: - Thread through comport 1 cable here.

## **4. Power & Connections**

### **4.1 Power Adaptor**

Always use the power adaptor supplied together with this instrument to avoid un-recoverable damages to this instrument.

#### **Notes: -**

- When an energized power adaptor is plugged in, this instrument will power on automatically.
- Minimum backlight will remain lit on when an energized power adaptor is plugged in even this instrument is switched off.

### **4.2 Built-In Rechargeable Battery**

Before first time use, recharge the built-in batter for at least 8 hours to ensure the best battery performance.

### **4.3 Connect<sup>9</sup> with Weighing Platform or Load Cell Junction Box**

Connect this instrument with a weighing platform (load cell) through load cell connector located at the back according to the below pin assignment table.

---

7 Settings of comport #2 is done through F17.

8 Settings of comport #1 is done through F16.

9 Turn this instrument off and unplug power adaptor before making any connection or disconnection.

**Note: -**

If a 4-wire load cell or junction box is used, short-circuit pin 1&2 and pin 3&4. Otherwise, this instrument will not work.

**4.3.1 Load cell connector pin assignment**

Pin # on Load Cell Connector	Pin Assignment
1	Excitation +ve
2	Remote Sense +ve
3	Excitation -ve
4	Remote Sense -ve
5	Signal +ve
6	Signal -ve
7	Ground

**4.4 Comports on Instrument**

There are 2 built-in comports on this instrument: -

- Comport 1 can be used for serial or TTL communication depends on the jumper setting of the Serial/TTL selection jumper. Default setting = serial. Contact your dealer in case TTL output is required for Comport 1.
- Comport 2 supports only serial communication.

Both comports support bi-directional communication when set as PC and CMD modes. Refer to **5.5** for setting details.

**4.5 Comports Pin Assignment**

Refer to below table for pin assignment between this instrument and a computer or serial printer.

## Comport pin assignment on instrument

Comport 1 (male)	Comport 2 (female)
2 = RXD	2 = TXD
3 = TXD	3 = RXD
5 = GND	5 = GND
9 = DC 5V Output	Nil

### Notes: -

- Comport 1 is assigned as DTE and has a male connector.
- Comport 2 is assigned as DCE and has a female connector.

## 4.6 Control Output Port

### Control Output Port Pin Assignment

Pin No. on Control Output Port	Description <sup>10</sup>
1	Control Output #4, Normal Open
2	Control Output #4, Common
3	Control Output #4, Normal Close
4	Control Output #3, Normal Open
5	Control Output #3, Common
6	Control Output #3, Normal Close
8	Control Output #2, Normal Open
9	Control Output #2, Common

10 When this instrument is in check function mode: -

- Output #1 = Buzzer Output
- Output #2 = LO Output
- Output #3 = OK Output
- Output #4 = HI Output



10	Control Output #2, Normal Close
11	Control Output #1, Normal Open
12	Control Output #1, Common
13	Control Output #1, Normal Close

**Notes: -**

- In case control output is used, always plug in the power adaptor which comes with this instrument. Otherwise, no output signal will be sent.
- Common of a particular output is independent to the common of other control outputs.
- Max. loading per relay = DC30V 2A / AC125V 1A.

## 5. Initial Setup

There are 2 groups of internal function: -

- Group #1: - F1~F29 are accessible without restriction,
- Group #2: - F60~F99 are restricted functions which may request a password or hardware key to access. These functions are for dealer and authorized personnel only. Do not change any settings of these functions to avoid operation errors.

Below paragraphs describe those settings related to F1~F29. Contact your dealer for F60~F99 settings.

### 5.1 Internal Functions & Settings

Application parameters can be checked and set through internal function. Set all preferred operation parameters according to **5.4**.

### 5.2 How to Enter & Select Internal Function<sup>11</sup>

To avoid operation error, it is strongly recommended that internal function mode should be entered when instrument is in weighing mode.

---

<sup>11</sup> To fulfil the metrology law of certain countries, accessing to internal function by **[Set]** may be disabled. Contact your dealer for more information.

Follow the below procedures for internal function setup: -

1. In weighing function, press **[Set]**,
2. Displays **F1**,
3. This instrument is now in internal function mode.
4. Press **[Func]** and **[Unit]** to access the preferred internal function number.

### 5.3 Key Function under Internal Function Mode

Key	Function in Setup & Calibration
<b>[On/Off]</b>	Power off
<b>[Zero]</b>	Quit without saving
<b>[Tare]</b>	Go to internal function during power on countdown
<b>[Func]</b>	Go to next manual Move cursor to one place right
<b>[Unit]</b>	Go to previous manual Move cursor to one place left
<b>[Set]</b>	Enter / Save
<b>[PT]</b>	No Function
<b>[Print/M+]</b>	Increase numeric value by 1 Quick access to the higher 10 <sup>th</sup> Internal function available
<b>[Check]</b>	Decrease numeric value by 1 Quick access to the lower 10 <sup>th</sup> Internal function available
<b>[CE/x10]</b>	Clear Confirm System Initialization

## 5.4 Internal Function Table

Refer to the below tables for internal function number, parameter and setting notes.

Funct ion No.	Description	Parameters / Note Default = **					
F1	Internal Analogue to Digital (ad) Value	<p>Press <b>[Tare]</b> to set offset value to zero when unloaded. Then add load on the platform to observe the span value of load applied.</p> <ul style="list-style-type: none"><li>When ADC is more than 1 million. W<sub>1</sub> sign will appear. Actual ADC is = 1 million plus the ADC value being displayed.</li><li>When ADC is more than 2 million. W<sub>2</sub> sign will appear. Actual ADC is = 2 million plus the ADC value being displayed.</li><li>When ADC is more than 3 million. Both W<sub>1</sub> &amp; W<sub>2</sub> sign will appear. Actual ADC is = 3 million plus the ADC value being displayed.</li></ul> <p>Press <b>[Zero]</b> to quit to F1.</p>					
F2	All Segment Check	All display segments and backlight colors will be lit on. Check any segments or backlight colors are missing.					
F3	Capacity, Division & Default Weight Unit	Display basic metrology characteristics (capacity, division and weight unit). Value displayed = Max + 1e					
F4	Date Format & Date	DD/MM/YY	** YY/MM/DD		MM/DD/YY		
	<ul style="list-style-type: none"><li>Press <b>[Set]</b> to check current date value.</li><li>To change date value, enter date value and then press <b>[Set]</b> to confirm.</li></ul>						
F5	Time	HH/MM/SS					
	To change time, press <b>[Set]</b> , then enter a new value and press <b>[Set]</b> .						
F6	System Initialization (Set F7~F29 to Default)	** NO			YES		
	If YES is selected, press <b>[CE/x10]</b> when “SURE ?” is displayed. Indicator shows Done when initialization is completed.						
F7	Auto Power Off	OFF	1	3	** 5	10	20

	Time (Minute)									
	Auto power off function will be disabled when an energized power adaptor is pulled in.									
F8	Backlight Brightness	Brightness (01 ~ 99) <b>** Default = 60</b>				Color Ratio (Green Vs Red) <b>** Default = 50</b>				
	<ul style="list-style-type: none"><li>To change setting, enter preferred value and then press <b>[Set]</b>.</li><li>Set brightness (bt) first, then set color ratio. Color ratio is used to generate the preferred yellow color.</li></ul> <p>When instrument is powered by built-in rechargeable battery, backlight will turn to minimum when battery is low or when weight value remains unchanged for 5 seconds.</p>									
F9	Weight Unit Enable / Disable	kg ( <b>** On/Off</b> )			g (On/ <b>** Off</b> )			lb (On/ <b>** Off</b> )		
F10	Filter Strength	1	2	3	4	<b>**</b> 5	6	7	8	9
	<b>Select: -</b> <ul style="list-style-type: none"><li>1 (strongest filter) for bad working environment where vibration, wind flow... etc. affect stable reading,</li><li>5 for normal environment,</li><li>9 (least filter) for very good working environment where wind and vibration have no effect to stable reading.</li></ul>									
F11	Auxiliary Function	<ul style="list-style-type: none"><li>Cnt (Counting) / On/<b>** Off</b></li><li>AtM (Action Tare Memory) / On/<b>** Off</b></li><li>PEK (Peak) / On/<b>** Off</b></li><li>Ani (Animal) / On/<b>** Off</b></li><li>PCd (Quick Access to Customer/Product Code Setting) / On/<b>** Off</b></li></ul>								
F12	Auto Tare Function	<b>** OFF</b>			ON			Contin		
	<b>Notes: -</b> <ul style="list-style-type: none"><li>Off = Auto Tare Function disable</li><li>On = Only the first table weight applied will be tare off. Minimum tare load <math>\geq 2d</math></li><li>Contin = All stable weight applied will be tare off. Minimum tare load <math>\geq 10d</math></li></ul>									

<b>F13</b>	Repetitive Tare Function		<b>** OFF</b>		ON			
	If F12 is set = Contin, Repetitive Tare setting “Off” will be surpassed.							
<b>F14</b>	Buzzer		Kb (keypad buzzer) ( <b>**On/Off</b> )		St (System buzzer) ( <b>**On/Off</b> )			
<b>F15</b>	Check Result Buzzer		OFF	<b>** IN</b>	OUT	Hi	Lo	
	<ul style="list-style-type: none"><li>oFF = Check Buzzer disabled.</li><li>IN = Check Buzzer activates when reading is within range.</li><li>ouT = Check Buzzer activates when reading is out of range.</li><li>Hi = Check Buzzer activates when reading is more than Hi limit.</li><li>Lo = Check Buzzer activates when reading is lower than Lo limit.</li></ul>							
<b>F16</b>	Set Comport 1	Off	Auto 1	Auto 2	Auto 3	Manual	<b>** PC</b>	Scanner
	Refer to F17 for details							
<b>F17</b>	Set Comport 2	Off	Auto 1	Auto 2	Auto 3	Manual	PC	<b>** CMD</b>
	<ul style="list-style-type: none"><li>Off = No data output.</li><li>Auto 1 = auto print when weight is stable.</li><li>Auto 2 = the highest stable weight value (of a weighing process) will be automatically printed when all loads are removed (and gross weight returns to zero or minus).</li><li>Auto 3 = the last stable weight value (of a weighing process) will be automatically printed when all loads are removed (and gross weight returns to zero or minus).</li><li>Manual = Manual output to printer or computer.</li><li>PC = Continuous output.</li><li>CMD = Command / information request mode.</li><li>Scanner = Serial scanner.</li></ul> <p><b>Notes: -</b></p> <ul style="list-style-type: none"><li>Refer to operation manual for detailed setup information.</li></ul>							

	<ul style="list-style-type: none"> <li>Restart instrument (by power off then power on again) after F16 and/or F17 setting is changed under normal operation status.</li> </ul>		
<b>F18</b>	Machine ID and Group Number	Machine ID	Group Number
	<ul style="list-style-type: none"> <li>Id = Machine ID number (0000~9999). Press <b>[CE/x10]</b> to skip or clear machine ID.</li> <li>Gp = Group number (00~99). Press <b>[CE/x10]</b> to skip or clear machine group.</li> </ul>		
<b>F19</b>	Manual Customer & Product Code Setting	H Code	M Code L Code
	<ul style="list-style-type: none"> <li>Product code by keyboard accepts numeric numbers only. Maximum length = 18 digits.</li> <li>Enter Product code starting from H code, then M cord and finally L Cord. Press <b>[Set]</b> to confirm and end editing after last digit has been input.</li> <li>Customer &amp; Product code does not support print format 1 (Lab 1).</li> <li>If a customer/product code has been entered, this code will be included in print format 2, 3, 4 and 5 (Lab 2 ~ Lab 5) automatically.</li> </ul>		
<b>F20</b>	Keyboard Lock	<b>** OFF</b> (Disable)	ON (Enable)
	When keyboard lock is = <b>ON</b> , only Zero, Tare, Set & On/Off key will be accessible during operation status.		
<b>F21</b>	Weight Function Output Print Format	<b>** STD</b>	CUSTOM
<b>F22</b>	Counting Function Output Print Format	<b>** STD</b>	CUSTOM
<b>F23</b>	Reserved.		
<b>F24</b>	Animal Functions Output Print Format	<b>** STD</b>	CUSTOM
<b>F25</b>	Reserved.		
<b>F26</b>	Near Zero Weight Value	<b>** 000000</b>	
	Near Zero value is useful for dynamic weight check applications to bypass unnecessary LO alarm during uploading and unloading process. <b>Notes:</b> - <ul style="list-style-type: none"> <li>Value entered valid only when Check function is activated.</li> </ul>		

	<ul style="list-style-type: none"> <li>Near zero weight value can be any value between 20d and LO limit.</li> <li>Any near zero value which is less than 20d will be ignored. Instrument will deem 20d as minimum near zero weight value.</li> <li>The HI LO comparison remains non-activated when weight reading is less than the near zero value entered here.</li> </ul>		
<b>F27</b>	Decimal Point Format	<b>** Dot (.)</b>	Comma (,)
<b>F28</b>	Ask for Operator Number when Power on	Yes	<b>** No</b>
	<ul style="list-style-type: none"> <li>Yes: - Instrument will ask for operator number during countdown process when power on. Enter 4-digit operator number or press <b>[CE/x10]</b> to skip operator number when being asked.</li> <li>No: - Instrument will not ask for operation number.</li> </ul>		
<b>F29</b>	Read Calibration and parameter set counts. <ul style="list-style-type: none"> <li><b>O</b> (Parameter set count): - shows total times that the important parameters (F80~F88) has been altered.</li> <li><b>C</b> (Calibration count): - shows total times of calibration.</li> </ul>		

## 5.5 Setting Comport 1 & Comport 2

2 comports are on this instrument. Default setting for both comports = serial. Contact your dealer in case of TTL output is required for Comport 1. Following the below procedures to setup comports.

- Go to F16 or F17.
  - F16 is used to configure Comport 1.
  - F17 is used to configure Comport 2.
- Press **[Func]** or **[Unit]** to shift among parameters Off, PC, Scanner (Comport 1 only), CMD (Comport 2 only), Auto1, Auto 2, Auto 3 and Manual.

### Notes: -

- Off = Comport disable. Select this when a particular comport is not used.
- PC & CMD is data string related modes.
- Auto 1, Auto 2, Auto 3 and Manual are print related modes.
- All working modes (except Off, LP50 and TSC) of Comport 1 accept scanner data input during operation.
- All working modes (except Off, LP50 and TSC) of Comport 2 accept

and responses to System Parameter Inquiry and also System Parameter Setting commands during operation.

- When both ports are set to data string related modes, **[Print/M+]** key is used as M+ (memory accumulation) and can only be activated when value is stable and  $\geq 20d$ .
  - If both comports are set to print related mode (e.g. comport 1 is set to Auto 1, comport 2 is set to Auto 2) and at the same time Auto memory accumulation is selected by both modes, then Auto memory accumulation serves only comport 1.
3. Select the preferred output type parameters then press **[Set]** to save.
  4. At this point: -
    - If PC is selected, refer to **5.5.1** for setting details.
    - If CMD is selected, refer to **5.5.2** for setting details.
    - If Manual is selected, refer to **5.5.3** for setting details.
    - If Auto 1~3 is selected, refer to **5.5.4** for setting details.
    - If Scanner is selected, refer to **5.5.5** for setting details.

#### **5.5.1 When comport is set as PC**

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
4. Instrument displays output protocol type. 9 parameters (Prot 1~9) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
5. Instrument displays time interval (in second) between each output. 10 parameters (0, 0.5, 1, 1.5, 10, 30, 60, 90, 120, and 300) are available. 0 = continuous output. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
6. At this point, PC setup is completed.



### 5.5.2 When comport is set as CMD<sup>12</sup>

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
4. At this point, CMD setup is completed.

### 5.5.3 When comport is set as Manual

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
4. Instrument displays Auto Accumulation. 2 parameters (on, off) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
  - On = when pressing **[Print/M+]** during normal operation, the instrument does print and M+ at the same time,
  - Off = when pressing **[Print/M+]** during normal operation, the instrument does print only.
5. Instrument displays Check Control. 2 parameters (on, off) are available. By default, print data will only be transmitted under all auto print modes. Press **[Set]** to save.
  - On = (When check function is in effect) Only OK value (value which is within Lo and Hi Limits) will be transmitted.

---

<sup>12</sup> Refer to **5.5.2** for details.

- Off = (When check function is in effect) Check requirement is disable.
6. Instrument displays Stability control. 2 parameters (Yes, no) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
    - Yes = **[Print/M+]** (during normal operation) will only function when the weight is stable.
    - No = **[Print/M+]** (during normal operation) will always function disregarding the stable condition of the weight when **[Set]** is pressed.
  7. Instrument displays minimum output weight. 21 parameters (0d~20d) are available. Instrument will not generate any output if the actual weight is less than the minimum output weight selected here. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
  8. Instrument displays print format. 5 parameters (Lab 1, Lab 2, Lab 3, LP-50 and TSC). Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
    - Lab 1 = Output in Landscape direction. If Lab 1 is selected, refer to 5.5.3.1 for other settings.
    - Lab 2 = Output in Portrait Direction. If Lab 2 is selected, refer to 5.5.3.2 for other settings.
    - Lab 3 = Database output mode.
    - LP-50 = Output to LP-50 label printer. Refer to 5.5.3.3 for other settings.
    - TSC = Output to TSC label printer. Refer to 5.5.3.3 for other settings.

#### **5.5.3.1 Other settings if Lab 1 is selected**

- a. Instrument displays Line number. Line number is the number of lines in between which the report heading is repeated. Line number should be from 00~99. 00 means no header output. Input the desired line number then press **[Set]** to save.
- b. At this point, Lab 1 setup is completed.

#### **5.5.3.2 Other settings if Lab 2 is selected**

- a. Instrument displays number of copy to generate each time. 8 parameters (1~8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.

- b. At this point, Lab 2 setup is completed.

### 5.5.3.3 Other settings if LP-50 / TSC is selected

- a. Instrument displays number of copy to generate each time. 8 parameters (1~8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
- b. Instrument displays label file number (FL1 01 ~ FL1 99) to print in label format group 1. Press **[Func]** or **[Unit]** until the preferred label file number appears then press **[Set]** to save.
- c. Instrument displays label file number (FL2 01 ~ FL2 99) to print in label format group 2. Press **[Func]** or **[Unit]** until the preferred label file number appears then press **[Set]** to save.
- d. At this point, LP-50 / TSC setup is completed.

### 5.5.4 When comport is set as Auto (Auto 1~3)

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
4. Instrument displays Auto Accumulation. 2 parameters (on, off) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
  - On = Auto memory accumulation enable. Instrument will accumulate the printed value to memory.
  - Off = Auto memory accumulation disable.
5. Instrument displays Check Control. 2 parameters (on, off) are available. By default, print data will only be transmitted under all auto print modes. Press **[Set]** to save.
  - On = (When check function is in effect) Only OK value (value which is within Lo and Hi Limits) will be transmitted.
  - Off = (When check function is in effect) Check requirement is disable.

6. Instrument displays Stability control. 2 parameters (Yes, no) are available. **By default, only stable value will be transmitted under all auto print modes.** Press **[Set]** to save.
7. Instrument displays minimum output weight. 21 parameters (0d~20d) are available. **By default, only stable value which is  $\geq 20d$  under all auto print modes.** Press **[Set]** to save.
8. Instrument displays print format. 4 parameters (Lab 1, Lab 2, LP-50 and TSC). Instrument will not generate any output if the actual weight is less than the parameter weight selected. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
  - Lab 1 = Output in Landscape direction. If Lab 1 is selected, refer to **5.5.3.1** for other settings.
  - Lab 2 = Output in Portrait Direction. If Lab 2 is selected, refer to **5.5.3.2** for other settings.
  - LP-50/TSC = Output to LP-50/TSC label printer. If LP-50/TSC is selected, refer to **5.5.3.3** for other settings.
9. At this point, Auto (Auto 1~3) setup is completed.

#### **5.5.5 When Comport 1 is set as Scanner**

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
4. At this point, scanner setup is completed.

## **6. Basic Operations**

### **6.1 Power On, Inputting Operator Number & Power Off**

To power on instrument, press **[On/Off]** for 0.5 second.

After powered on, instrument will display software number... software revision...all display segments... calibration count value... parameter set count value.

At this point, depends on internal function number F28 setting, instrument may ask for operator number input. If this is the case: -

- Input 4-digit operator number, or
- Press **[CE/x10]** then **[Print/M+]** to skip operator number when oP appears.

After above, the instrument will go to the last working mode before powered off and is ready for operation.

To power off instrument, simply press **[On/Off]**.

## 6.2 Warm up Time & Set Weight to Zero When Unloaded

It is important to allow the instrument enough warm up time. This is especially important when this instrument is running at high resolution (e.g. 6000d or higher) application. Refer to 1.3 for detailed.

If zero result is not obtained when unloaded, press **[Zero]** to set displayed result to zero.

## 6.3 Keyboard Lock

When keyboard lock is enabled, only **[On/Off]**, **[Zero]**, **[Tare]** and **[Set]** key can function. Refer to F20 on 5.4 for keyboard lock settings.

## 6.4 Tare Modes

Tare function is used to cancel the weight of a box or a container in order to get the net weight result. Various tare modes are available. Refer to below paragraphs for details.

### 6.4.1 Manual Tare<sup>13</sup>

1. Remove all loads from platform.

---

13 Maximum tare (subtractive) = -Max for single range mode and dual weighing range/interval

2. Make sure that the **Zero Indicator** is on. If not, press **[Zero]**.
3. Place container on platform.
4. Press **[Tare]**.
5. Weight displayed will become zero and **Net Indicator** appears to indicate tare is in effect and weight being displayed is net weight.
6. To cancel tare effect, remove all loads from platform and press **[Tare]**,
7. **Net Indicator** disappears. **Gross Indicator** appears to indicate tare effect has been removed and weight displayed is gross weight.

#### 6.4.2 Auto Tare<sup>14</sup> (F12)

3 parameters are available: - Off. Auto and Contin

- Off: - Auto tare disable.
- Auto: - instrument will assume the first stable weight ( $\geq 20d$  or  $20d_1$ ) applied is a container and will then tare off the weight of it automatically. When container is removed and gross weight result is zero, tare effect will be cancelled automatically.
- Contin (continuous auto tare): - all stable weight ( $\geq 20d$  or  $20d_1$ ) applied will be tare off automatically. When all loads are removed and gross weight result is zero, tare effect will be cancelled automatically.

#### 6.4.3 Repetitive Tare (F13)<sup>15</sup>

When F13 is set to OFF, this instrument does not permit multiple tare operation. Tare effect can only be cancelled when container is removed and gross weight is zero.

When F13 is set to ON, this instrument will permit multiple tare operation provided that **both** of the below requirements are met: -

- a. The tare operation does not permit a reduction of the value of the tare, and
- b. The tare effect can only be cancelled when there is no load on the platform.

---

mode.

14 Set F12 = ON to enable Auto Tare Function

15 Set F13 = ON to enable Repeated Tare Function.

#### 6.4.4 Preset Tare (F63)<sup>16 17</sup>

Preset tare allows a pre-determined tare weight value to be entered through **[Check]**, **[Print/M+]**, **[Unit]**, **[Func]**. Then press **[Set]** to confirm.

During weighing mode and when weight is zero, press **[PT]**, then enter the pre-determined tare weight value though and press **[Set]** to enter.

After the pre-determined tare value has been entered: -

- Instrument displays the preset tare value entered.
- Net indicator appears to indicate the value being displays is net weight.
- Preset Tare Indicator appears to indicate Preset tare mode is in effect.

To cancel preset tare effect: -

- Remove all loads from platform then press **[Tare]**, or
- Enter a zero preset tare value then press **[Set]**.

**Notes: -**

- The pre-determined tare weight entered will be rounded to the nearest division of the instrument. This does not affect the accuracy of the subsequent weighing and operation.
- Manual tare is possible when Repetitive Tare (F13) is set to On.

#### 6.5 Select the Preferred Function Mode

This instrument supports the below function modes. Abbreviation of each function mode is bracketed.

- Weighing (**Weigh**).
- Piece Count (**Count**).
- Action-Tare-Memory (**AtM**).
- Peak Hold Function (**Peak**).
- Animal Weighing (**Ani**).

---

16 Set F63 = ON to enable Preset Tare Function. Some countries may not consider preset tare function as a legal for trade function. Contact your dealer for more information.

17 Set also F12 to Off

Press **[Func]** until the abbreviation of the desired function mode appears then press **[Set]** to enter.

## **6.6 Weight Units<sup>18</sup>**

This instrument supports weight unit kg, g and lb. To enable/disable a weight unit, set in On/Off in.

To shift among various weight units, press **[Unit]** to shift among various weight units.

### **6.6.1 Weight unit gram (g)**

Disregarding to the setting of **F9**, weight unit gram (g) is available only when 3 or 4 decimal place (0.000 or 0.0000) is selected in F81. Contact your dealer for more information about this.

### **6.6.2 Select the Preferred Weight Unit**

The desired weight units should enable in F9. Press **[Unit]** until the preferred weight unit appears.

#### **Notes: -**

- Weight unit change clear all accumulated weight data from memory.
- The weight unit employed before power off will be employed when powered on again.

---

<sup>18</sup> Depends on F9 setting.



## 6.7 Memory Accumulation Function<sup>19</sup>

There are 2 types of memory accumulation mode: -

- a. Automatic memory accumulation mode, and
- b. Manual memory accumulation mode.

Maximum accumulation limit is = 8 digits (e.g. 99999999) plus decimal (if any).

**Err 28** appears when maximum accumulation limit is exceeded.

### 6.7.1 Automatic Accumulation<sup>20</sup>

Automatically accumulation is activated when Auto Accumulation is set to **On** in Auto 1, Auto 2, Auto 3 or Manual mode is selected in F16 and/or F17.

Under the automatic accumulation mode, corresponding results will be accumulated automatically.

### 6.7.2 Manual Accumulation<sup>21</sup>

Manual Accumulation is activated when scanner, PC or CMD mode is selected for **both** F16 and/or F17.

Under the Manual Accumulation mode, press **[Print/M+]** to accumulate the current value to memory.

### 6.7.3 When data is accumulated to memory<sup>22 23 24</sup>

1. When a result is accumulated to memory, this instrument displays "n\_\_\_\_x". **M+ Indicator** appears to indicate that memory contains stored data. "x" means the total number of transactions accumulated to memory.
2. This instrument returns to normal display status after 2 seconds.

---

19 Only weight result will be accumulated.

20 Refer to **5.5.4** for setting details.

21 Refer to **5.5.3** for setting details.

22 Memory Accumulation Function accumulated weight results only.

23 When F16 and F17 is set to mode Auto1~3, unstable result or result which is less than 20d (or 20d<sub>1</sub> for dual weighing range/interval mode) will not be accumulated to memory.

24 All data stored will be erased when weight unit or working mode is changed.

#### 6.7.4 Memory recall and clearance

Accumulation data will be stored in memory and will not be erased by normal power off (by pressing the **[On/Off]** key) process.

Instrument will automatically erase accumulation data stored when: -

- Changing weight unit, or
- Change to another working mode, or
- A different operator number is entered during power on process.

Follow below procedures to recall and clear accumulation data manually.

1. Remove all loads from platform then press **[Print/M+]** to recall total accumulated weight.
2. Instrument flashes between “**A\_\_\_\_Y**” (Y means the number of transactions accumulated) and total accumulated result.
3. At this point: -
  - Press **[Zero]** to quit, or
  - Press **[CE/x10]** to clear memory. After **[CE/x10]** is pressed, instrument display Clear and M+ Indicator disappears to indicate all no data is stored in memory.
4. Press **[MR]** to recall total accumulated weight.
5. Instrument flashes between “**A\_\_\_\_Y**” (Y means the number of transactions accumulated) and total accumulated result.
6. At this point: -
  - Press **[Zero]** to quit, or
  - Press **[CE/x10]** to clear memory. After **[CE/x10]** is pressed, instrument display Clear and M+ Indicator disappears to indicate all no data is stored in memory.

#### 6.8 Extended display mode<sup>25</sup>

When F68 is set to OIML or NTEP, by pressing **[CE/x10]** the weighing resolution will be temporary (for 5 seconds) changed to 10 times finer. Display keeps flashing when instrument is displaying the extended result.

---

25 When F68 = OIML or NTEP.

## 6.9 Tri-color Backlight

This instrument is equipped with a tri-color backlight. The tri-colors are yellow, green and red.

- In normal operation, green is used for display illumination.
- When check function is activated, yellow = Lo; green = OK; red = Hi.

### 6.9.1 When powered by built-in rechargeable battery

Backlight will turn to minimum when weight remains stable/unchanged for 5 second. In order to save power, stable for backlight means  $\pm 5$  division variation.

### 6.9.2 When powered by external power adaptor

Backlight will remain on always.

## 6.10 Customer & Product Code

This instrument supports customer and product code entry. Maximum code length = 18 digits. Hints for code entry: -

- Only numeric numbers can be entered through keyboard on instrument.
- Numeric numbers, alphabets and symbols dash (-), slash (/), underline ( \_ ) and space are acceptable when entries are done through scanner to instrument.

### 6.10.1 Enter a customer & product code manually<sup>26</sup>

- Go to customer/product code setting manual by either one of the below method.
  - If Quick Manual Code Entry function (PCd) in F11 is set to on: -
    - Press **[Func]** until C.P. Code appears then press **[Set]**.
    - Press **[Func]** or **[Unit]** until the desired mode appears (select C Code to enter customer code or select P Code to enter product code), then press **[Set]** to confirm.
  - If Quick Manual Code Entry function (PCd) in F11 is set to Off: -
    - Go to F19, then press **[Set]**.
    - Press **[Func]** or **[Unit]** until the desired mode appears (select C Code to enter customer code or select P Code to enter

---

<sup>26</sup> If a customer/product code is less than 18 digits, press **[Print/M+]** to skip all blank digits displayed until instrument return to F19.

product code), then press **[Set]** to confirm.

- b. Instrument display H code followed by the 1<sup>st</sup> 6 digits. Enter the first 6 digits of the product code here, then press **[Set]** to confirm.
- c. Instrument displays M code followed by the 2<sup>nd</sup> 6 digits. Enter the 7<sup>th</sup> ~ 12<sup>th</sup> digits of the product code here, then press **[Set]** to confirm.
- d. Instrument displays L code followed by the 3<sup>rd</sup> 6 digits. Enter the last 6 digits of the product code here, then press **[Set]** to confirm.
- e. Instrument displays C.P. Code or F19 depends on method of entering.
- f. To go to other internal function, press **[Unit]** or **[Func]** or press **[Zero]** to quite to operation status.

### 6.10.2 Enter a customer & product code by scanner<sup>27</sup>

Default scanner input target is product code. To change scanner input target, scan either one of the below barcodes, then scan a customer or product barcode.



Scan here to change target to Product Code



Scan here to change target to Customer Code

### 6.10.3 Clear a customer & product code entered

To clear a customer/product code entered, press **[CE/x10]** on above procedures **b**, **c** and **d** on paragraph **6.10.1**.

---

<sup>27</sup> Maximum = 18 digits.

#### 6.10.4 Print a customer & product code entered<sup>28</sup>

Once a customer/product code is entered, it will be printed automatically through the assigned comport. No other setting is required.

#### 6.11 Enter a Key Command by Scanner

Simply scan one of the below barcodes to simulate pressing the **[Zero]**, **[Tare]** and **[Print/M+]** on keyboard.



Scan here to simulate **[Zero]** key



Scan here to simulate **[Tare]** key



Scan here to simulate **[Print/M+]** key

---

<sup>28</sup> Print format LAB 1 does not support customer/product code.

## 7. Weighing Mode

1. Refer to **6.6** on how to select the desired weight unit.
2. If zero weight cannot be obtained when unloaded, press **[Zero]**. After **[Zero]** is pressed, the **Zero Indicator** will appear<sup>29</sup>.
3. Always place an object onto platform gently. Excessive force / shock applied to platform may cause un-recoverable damage to the weight sensor inside platform.
4. The weight of the object is displayed automatically.
5. It is a good practice to remove all loads from platform after weighing. It will prolong the life of the weight sensor.

## 8. Piece Count Mode

1. Refer to **6.5** on how to select the desired weight unit.
2. If a container is used, place it onto the platform and press **[Tare]**.
3. Apply samples with the known quantity (sample size) on platform.
4. Press **[Set]** then input the sample quantity then press **[Set]**.
5. This instrument will calculate, store the average piece weight and confirm with 2 beeps. The quantity is then displayed.
6. Add to or remove from the platform, the corresponding quantity will be displayed automatically.
7. To count different articles, press **[Set]** and repeat procedures listed above.

### 8.1 Auto Unit Piece Weight Enhancement Function

In order to obtain the best counting result and minimize sampling error, this instrument is equipped with Auto Unit Piece Weight Enhancement Function.

This function will automatically be employed when unit piece weight is determined by actual sample method.

Auto Unit Piece Weight Enhancement Function is built-in the Piece Count mode.

This function starts automatically when all of the below are met: -

- a. Unit piece weight is determined by actual sampling method.

---

<sup>29</sup> Maximum weight value can be zero depends on F65 setting. Contact your dealer for detail.

- b. The quantity **added** to platter is more than 5 pieces but less than current quantity on scale.
- c. The total quantity on scale is less than 10000 pieces.

When all the above requirements are met, a new unit piece weight will be calculated and stored in memory and confirmed by a "beep" sound.

## 8.2 Shift among Quantity, Average Piece Weight and Weight Info

1. Press **[Unit]** to shift among quantity, average piece weight and weight info.
2. Quantity Display format = numeric numbers & PCS (e.g. 1000 PCS).  
Average piece weight display format = numeric numbers & weight unit & PCS (e.g. 499.960g/PCS).
3. Weight display format (when Piece Count Function is in effect) = numeric numbers & weight unit & PCS (e.g. 500 kg PCS).

## 8.3 Recall the Average Piece Weight before Powered Off

To recall the last average piece weight before instrument was powered off: -

1. In Piece Count Mode, press and hold **[Set]** for 2 second,
2. Instrument display **recall**.
3. The last average price weight before powered off is now in effective.

# 9. Action-Tare-Memory (ATM)

## 9.1 Description of ATM Mode

It means action, then tare, then memory: -

- Action = load or remove weight from weighing platform.
- Tare = the above weight added on or removed from will be tare off automatically.
- Memory = the above weight will be added to or deducted (in case of removal) from accumulated memory.

## 9.2 Basic ATM Settings

1. Refer to **6.6** on how to select the desired weight unit.
2. Enter ATM mode.
3. Press **[Set]** to select Auto Accumulation target then press **[Set]**.
  - Gross = Gross weight will be accumulated.
  - Net = Net weight will be accumulated.
4. Instrument prompts for delay time (second). Delay time is the time interval (00 ~ 99 second): -
  - Between a valid stable weight result is obtained and before it is tare off and accumulated to memory.
  - Display time of total accumulated weight result (after all loadings are removed) and before it is clear from print out memory.
5. Enter delay time through **[Check]**, **[Print/M+]**, **[Unit]**, **[Func]**. Then press **[Set]** to confirm.
6. At this point, ATM mode is ready for use.

## 9.3 Start Using ATM<sup>30</sup>

1. Apply container on platform. Instrument will tare off the weight of the container.
2. Apply or removed load on or from platform. The weight result is displayed for the time interval set forth by above point 2. Then instrument will accumulate the weight result in memory then clear it from the display.  
**Notes: -**
  - Both positive and negative weight will be accumulated to memory.
  - Positive weight will be added to the accumulated memory.
  - Negative weight will be deducted from the accumulated memory.
3. Apply/remove another load on/from platform. The weight result is displayed for the time interval set forth by above point 2. Then instrument will accumulate the weight result in memory and clear it from the display.
4. Repeat point 3 until all weighing sequence is completed.
5. To recall current total accumulated weight, press **[MR]**.
6. At this point: -
  - Press **[Zero]** to quit, or

---

<sup>30</sup> Weight changed less than 10d will not be processed.



- Press **[Print/M+]** to print the current accumulated weight.
7. When all loads are removed from weighing platform. Total accumulated weight value will then be erased automatically.

### **9.3.1 Weight Check Control for ATM**

When weight Check Control is in effect, only weights within Lo and Hi limit will be tare off and accumulated.

#### **9.3.1.1 Comport settings of weight Check Control for ATM when an external peripheral is connected to instrument.**

- a. Set F26 (near zero value) according to application requirement or 00000 to disable near zero value control. Refer to **13.1** for more information about F26 near zero function.
- b. Refer to **5.5.4** on comport settings and set Check Control = On.
- c. In ATM mode, refer to **12.1** to enter LO and HI limit.

#### **9.3.1.2 Settings of weight Check Control for ATM when no external peripheral is connected to instrument.**

- a. Set both Comport 1 and Comport 2 to Off.
- b. Set F26 (near zero value) according to application requirement or 00000 to disable near zero value control. Refer to **13.1** for more information about F26 near zero function.
- c. At this point, ATM comport setup is completed for this mode.

## **10. Peak Hold Mode<sup>31</sup>**

### **10.1 Description of Peak Hold Mode**

Under this mode, the instrument will display and hold the highest load/force detected. This mode can be used for tension (positive) or compression (negative) tests, all peak results are treated as absolute values.

---

<sup>31</sup> Peak hold mode does not support memory accumulation, weight unit conversation or weight check function.

## 10.2 Comport Settings for Peak Hold Mode<sup>32</sup>

Refer to **5.5** on comport settings. Output type parameters Auto 1 ~ 3 are **not** suggested. If a printer is used, set the connected comport to Manual and the other comport to any data string related modes.

During comport setting procedures, following the below recommendation for parameters selection.

- a. Baud rate setting. If an external peripheral is used, always use the highest available baud rate of it. The highest baud rate this instrument can support is 256000. Baud rate of the peripheral has to be set accordingly.
- b. Parity setting: -
  - Set according to the external peripheral connected.
  - Select any if there is no external peripheral is connected.
- c. Data length setting
  - Set according to the external peripheral connected.
  - Select any if there is no external peripheral is connected.
- d. Auto Accumulation setting: - Select any. Instrument will deem No as default value for this mode.
- e. Check Control setting: - Select Off.
- f. Stability control setting: - Select any. Instrument will deem No as default value for this mode.
- g. Minimum output setting: - Select any. Instrument will deem 0d as default value for this mode.
- h. Print format setting: - Set according to the external peripheral connected.
- i. At this point, comport setup is completed for this mode.

## 10.3 Start Using Peak Hold

1. Refer to **6.6** on how to select the desired weight unit.
2. Refer to **6.5** on how to enter Peak Hold mode.
3. Complete all necessary test setup. If mounting/support accessories are used, apply all of them.
4. Press **[Tare]** to cancel the effect of any extra loads.

---

<sup>32</sup> Set both Comport 1 and Comport 2 to Off if no external peripheral are connected to this instrument.

5. Start measuring process, the peak value detected will be held and flashing.
6. To print the peak value, press **[Print/M+]**.
7. To display actual current value (e.g. after a tension force has been decreased), press **[CE/x10]**.

## 11. Animal Weighing Mode<sup>33</sup>

### 11.1 Description of Animal Weighing Mode

Animal weighing mode is used to weigh live animals.

### 11.2 Basic Animal Weighing Settings

1. Refer to **6.6** on how to select the desired weight unit.
2. Enter Animal Weighing mode.
3. Press **[Set]** to select the preferred filter speed by pressing **[Func]** or **[Unit]** key, 5 filter speed are available from (FLt 1 ~ FLt 5).
  - FLt 1 = Fast (Weight value is based on least number sampling data; accuracy will be lowest).
  - FLt 3 = Normal (Displayed average weight is calculated based on the last 8 internal readings).
  - FLt 5 = Slow (Weight value is based on most number of sampling data, accuracy will be highest).
4. Press **[Set]** to save and then select weight release variation value.
5. Press **[Func]** or **[Unit]** key to select the preferred weight release variation value. 10 parameters are available from Off to 20: -
  - rE oFF = auto release disabled.
  - rE 0.5 = auto release when weight varies  $\geq 0.5\%$  of rate capacity or  $W_1$  for dual weighing range/interval mode.
  - .....
  - rE 20 = auto release when weight varies  $\geq 20\%$  of rate capacity (or  $W_1$  for dual weighing range/interval mode).
6. Press **[Set]** to save.
7. Instrument is now ready for animal weighing application.

---

<sup>33</sup> Animal Weighing function will not operate when weight is less than 20d (or 20d<sub>1</sub> for dual weighing range/interval).

## 11.3 Start Using Animal Weighing

1. Get an animal on platform.
2. This instrument will calculate the weight of an animal. The result obtained will be flashing.
3. In case more animals have to be weight in the same transaction, then get other animals on platform. An updated weight will be calculated and displayed<sup>34</sup> as above step 2.
4. To update the weight reading manually, press **[CE/x10]**.

## 12. Static Check Function<sup>35 36 37 38 39</sup>

Check function is used to compare current weight result with the preset Lo and Hi Limit. The comparison results (LO, OK, HI) will then be displayed in different backlight colors with or without buzzer<sup>40</sup>. Check results are also sent to Control Output Port<sup>41</sup>.

Targets of Check mode are: -

- Weighing mode = weight value.
- Piece Count mode = piece value.
- Auto Tare Accumulation mode = weight value.

### 12.1 Set LO & HI Limit

Follow the below steps to set Lo and Hi Limit.

1. During desired operation mode, press **[Check]**.
2. Instrument displays Low followed by a 6-digital value. Enter the LO limit or press **[CE/x10]** to set LO limit to zero then press **[Set]** to save.
3. Instrument displays HIGH followed by a 6-digital value. Enter the HI

---

34 Provide that extra weight added/removed fulfills the weight release variation value listed on point 5 of **11.2**.

35 Check mode will not operate when weight is less than 20d (or 20d<sub>1</sub> for dual weighing range/interval mode).

36 Set also F15 for desired Check buzzer output.

37 When F25 = Mode 1, set also F26 (Near Zero weight value).

38 Check mode does not support peak hold or animal weighing mode.

39 Set F26 to zero.

40 Set F15 for preferred buzzer output configuration.

41 Refer to **4.6** for details.

- limit or press **[CE/x10]** to set LO limit to zero then press **[Set]** to save.
4. Check Mode is now enabled. The check result is shown by one of the backlight colors<sup>42</sup>. Check results are also sent to Control Output Port.

## 12.2 Hints for entering LO and HI limits: -

- a. For normal comparison, set both Lo and Hi Limit.
- b. To check only if result is lower than or equal to LO (result  $\leq$  LO), set HI Limit = 0.
- c. To check only if result is higher than or equal to HI (result  $\geq$  HI), set LO Limit = 0.
- d. To check if result is equal to a specified value, set both HI Limit and LO Limit = the specified value.

## 12.3 To Cancel Check Function

To cancel check function, press **[CE/x10]** on point **2** and **3** of **12.1**.

# 13. Dynamic Check Mode<sup>43</sup>

Check function mode also supports dynamic applications which within the below specifications listed.

- a. Maximum belt speed: - 30 meter per minute.
- b. Maximum accuracy: - 3000d.
- c. Maximum speed: - 30 pack per minutes.

This instrument supports near zero function. Enter near zero value in F26. It is recommended that this value is = 70% of the target weight value. Refer to **13.1** for details.

## 13.1 Near Zero Function Description

Near zero value is very useful for dynamic and conveyor weighing applications. It is used to avoid false LO signal output when load is approaching and leaving

---


<sup>42</sup> Yellow = Lo; Green = OK; Red = Hi.

<sup>43</sup> Set preferred near zero weight value in F26. By default, system will ignore any near zero which is less than 20d. If it is the case, system will deem 20d as near zero weight value.

the weighing platform.

HI/OK/LO comparison will only start when weight reading exceeds the preset near zero value. Refer to below diagram for more illustration.

### 13.2 Near Zero Value Illustration Diagram



After Hi, Lo limits and near zero value have been entered, this instrument is ready for dynamic checking.

## 14. Communication & Outputs<sup>44</sup>

### 14.1 Print Output & Formats

If Manual is selected in F16 and/or F17, refer to **5.5.3.1** (Lab 1), **5.5.3.2** (Lab 2) and **5.5.3.3** (LP-50/TSC) for details.

### 14.2 Auto 1~3 Output & Formats

If Auto 1~3 is selected in F16 and/or F17, refer to **5.5.4** for details.

### 14.3 PC Output & Protocol

If PC is selected in F16 and/or F17, refer to **Appendix B** for protocol details.

### 14.4 Sending Keyboard Commands from Computer

When Comport 2 is assigned as CMD, keyboard commands can be sent by an external device to this instrument. Refer to **Appendix A** for details.

### 14.5 Requesting Operation Results & System Parameters by Computer

To obtain operation results and system parameters by computer, set F17 to CMD.

- Refer to **Appendix C** for details to obtain operation results.
- Refer to **Appendix D** for details to obtain system parameters.


---

<sup>44</sup> Instrument should be re-started (by power off then power on again) after F16 and/or F17 setting is changed under normal operation status.

## 14.6 PC Software

A PC software is built to work with this instrument. This software enables users to perform: -

- Real Time Operation Status Monitoring
- Operation Parameters Setting
- Real Time Process Monitoring
- Individual and Totalized Record Storage
- Database File Output



Click / visit the below link to down this software and operation manual of it.

[www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)

Before using this software, read carefully the Software License Agreement of using this software. Do not use it if you do not agree with all terms and conditions listed on the License Agreement. It is assumed that by using this software, user agrees with all content of the License Agreement.



# 15. Printing Formats

## 15.1 Lab 1 Print Format<sup>45</sup>

When Lab 1 is selected, output in default format will be generated with printed data is sent. No header will be generated when line number is set = 00. See below table for print format and explanations.

Weighing Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	10:59:52	1 W	25.010kg	25.000kg	50.010kg	25.010kg		L
2015-06-26	10:59:55	2 W	49.990kg	25.000kg	74.990kg	75.000kg		L
2015-06-26	10:59:59	3 W	75.000kg	25.000kg	100.000kg	150.000kg		A
2015-06-26	11:00:05	4 W	99.990kg	25.000kg	124.990kg	249.990kg		A

Piece Counting Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:00:26	1 C	100 P	25.000kg	50.000kg	25.000kg	250.038 g	
2015-06-26	11:00:30	2 C	200 P	25.000kg	74.990kg	74.990kg	250.038 g	
2015-06-26	11:00:33	3 C	300 P	25.000kg	100.010kg	150.000kg	250.038 g	L
2015-06-26	11:00:36	4 C	400 P	25.000kg	125.000kg	250.000kg	250.038 g	L

ATM Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:02:16	1 W	25.000kg	25.000kg	50.000kg	25.000kg		L
2015-06-26	11:02:19	2 W	24.990kg	50.000kg	74.990kg	49.990kg		L
2015-06-26	11:02:21	3 W	25.000kg	75.000kg	100.000kg	74.990kg		L
2015-06-26	11:02:24	4 W	25.000kg	99.990kg	124.990kg	99.990kg		L

Animal Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:14:09	1 W	25.000kg	24.990kg	49.990kg	25.000kg		
2015-06-26	11:14:33	2 W	75.000kg	24.990kg	99.990kg	100.000kg		
2015-06-26	11:15:05	3 W	125.000kg	24.990kg	149.990kg	225.000kg		
2015-06-26	11:15:13	4 W	50.000kg	24.990kg	74.990kg	275.000kg		

- Date = Date of Printing
- Time = Time of Printing
- No. = No of transaction and data type. W = Individual Weighing/ATM/Animal, C = Counting, M = memory recall data.
- Net = Net result. Quantity of pieces for price count mode. Weight for all other function.
- Tare = Tare Weight

---

<sup>45</sup> Lab 1 format does not support Customer/Produce Code.

- Gross = Gross Weight
- Total = Total accumulated weights
- Ref = Unit price Weight (Piece Count function only)
- R = Check result (when check mode is in effect). A = OK, L = LO, H = HI

## 15.2 Standard Lab 2 Print Format<sup>46</sup>

Standard ticket/receipt printout of various function modes are described illustrated below.

### 15.2.1 Standard Lab 2 print format for Weighing & ATM mode

Refer to below diagram for printout content.

Time	09:39:21
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Net	3.751kg
Tare	0.000kg
Gross	3.751kg
Total	7.502kg
High	8.000kg
Low	3.000kg
Accept	

#### *Data Explanation*

*Time of Printout*

*Date of Printout*

*Accumulation No.*

*Customer Code (If entered)*

*Product Code (If entered)*

*Net Weight*

*Tare Weight*

*Gross Weight*

*Total Accumulated Net Weight*

*Hi Limit (If entered)*

*Lo Limit (If entered)*

*Comparison Result*

<sup>46</sup> When Lab 2 is selected under in F16 and/or F17

### 15.2.2 Standard Lab 2 print format for Piece count mode

Refer to below diagram for printout content.

Time	09:41:04
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Net	3.751kg
Unit.W	75.0145 g
Count	50pcs
Total	7.502kg
Total	100pcs
High	80pcs
Low	30pcs
Accept	

#### Data Explanation

Time of Printout  
Date of Printout  
Accumulation No.  
Customer Code (If entered)  
Product Code (If entered)  
Net Weight  
Unit Weight  
Pieces  
Total Accumulated Net Weight  
Total Accumulated Pieces

Hi Limit (If entered)  
Lo Limit (If entered)  
Comparison Result

### 15.2.3 Standard Lab 2 print format for Peak Hold mode

Refer to below diagram for printout content.

Time	09:42:53
Date	2016-09-10
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Peak	14.760kg

#### Data Explanation

Time of Printout  
Date of Printout  
Customer Code (If entered)  
Product Code (If entered)  
Peak Value

### 15.2.4 Standard Lab 2 print format for Animal weighing mode

Refer to below diagram for printout content.

Time	10:07:15
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Hold.W	12.503kg
Total	25.006kg

#### Data Explanation

Time of Printout  
Date of Printout  
Accumulation No.  
Customer Code (If entered)  
Product Code (If entered)  
Animal Net Weight  
Total Accumulated Net Weight

### 15.3 Customizing Lab 2 Print Format<sup>47</sup>

Custom printout is available for the below modes: -

- Weighing.
- Auto-Tare-Memory.
- Piece Count.
- Animal weighing.

19 variants + 2 commands (**Cr LF and End**) are available for custom print output format. Refer to the below **Print output format variants table** for more detail.

#### 15.3.1 Print output format variants table

Symbol	Description
End	Edit finished
Cr LF	Insert one blank row
dAtE	Date of printing
tiME	Time of print
nEt	Net weight
tArE	Tare weight
GroSS	Gross weight
Unit	Average piece weight
Count	Number of piece
H rEF	HI limit
L rEF	LO limit
Ani	Weight Hold (Animal weighing)
Ch rES	Comparison result
trAnS	Transaction sequent number (if this transaction is accumulated to memory)
ACC	Total accumulated weight (when accumulation function is in effect)

---

<sup>47</sup> When Lab 2 is selected under in F16 and/or F17.

SiGn	Signature
P Code	Product code
Peak	Peak hold value
Id	Machine ID
GrouP	Machine group number
oPCodE	Operator number
C CodE	Customer code

### 15.3.2 To edit custom Lab2 print output format

Follow the below steps to create custom printout.

- Go to internal function and select the desired function number to edit,
- Select **CUSTOM** and press **[Set]**,
- This instrument displays **Line 1** and the last variant or command (see **15.3.1** for details) stored,
- Press **[Set]** to confirm or select other variant or command by press **[Func]** or **[Unit]**. Then press **[Set]** to confirm and save,
- This instrument displays **Line 2** and the last variant or command stored,
- Repeat steps **d** and **e** for other lines,
- To finish editing, select command **End**, then press **[Set]** to confirm.
- This instrument returns to and displays the current internal function number,
- If required, repeat steps **a** to **h** to create and edit custom printout format for other modes.

### 15.4 Lab 3 Data Base Output Format<sup>48</sup>

Current working mode and all related data are sent under this mode. Refer to below table for data output format.

Function & Output	Weighing	Count	ATM	Peak Hold	Animal
<b>Data 1</b>	Opr	Opr	Opr	Opr	Opr
<b>Data 2</b>	Seq	Seq	Seq	(Blank)	Seq
<b>Data 3</b>	0	1	2	3	4
<b>Data 4</b>	Mac	Mac	Mac	Mac	Mac
<b>Data 5</b>	MacGp	MacGp	MacGp	MacGp	MacGp
<b>Data 6</b>	Date	Date	Date	Date	Date
<b>Data 7</b>	Time	Time	Time	Time	Time
<b>Data 8</b>	Name	Name	Name	Name	Name
<b>Data 9</b>	Pcode	Pcode	Pcode	Pcode	Pcode
<b>Data 10</b>	Gross	Gross	Gross	Tare	Gross
<b>Data 11</b>	Tare	Tare	Tare	Peak	Tare
<b>Data 12</b>	Net	Net	Net	Unit	Net
<b>Data 13</b>	Low	Total.W	Low	CR LF	Total.W
<b>Data 14</b>	High	Unit	High		Unit
<b>Data 15</b>	Result	Count	Result		CR LF
<b>Data 16</b>	Total.W	Unit.W	Total.W		
<b>Data 17</b>	Unit	Unit	Unit		
<b>Data 18</b>	CR LF	Low	CR LF		
<b>Data 19</b>		High			
<b>Data 20</b>		Result			
<b>Data 21</b>		Total.C			
<b>Data 22</b>		CR LF			

**Note:** - Semi colon is inserted between data.

---

<sup>48</sup> When Lab 3 is selected under in F16 and/or F17.

## 15.5 Lab 4 Print Format<sup>49</sup>

Transaction data is sent in journal output format with gross and net weight of each individual transaction. Refer to below diagram for details.

Name	ANDHFYROLSJFHEIOMC	
Pcode	562188261631321879	
Opr	8888	
Mac	1234	
MacGp	56	
Date	2016-09-09	
Time	13:54:08	
Seq	Gross	Net
001	2.499	2.499 kg
002	2.499	2.499 kg
003	5.001	5.001 kg
004	5.002	5.002 kg
005	7.502	7.502 kg
006	2.499	2.499 kg
-----		
006		25.002 kg

### Data Explanation

Customer Code (if entered)

Product Code (If entered)

Operator No. (If entered)

Machine ID (If entered)

Machine Group No. (If entered)

Date of 1st Printout

Time of 1st Printout

Accumulation No., Gross Weight and Net Weight or Pieces

Total Accumulation No. and Total Net Weight or Pieces

## 15.6 Lab 5 Print Format<sup>50</sup>

Transaction data is sent in journal output format with time and net weight of each individual transaction. Refer to below diagram for details.

Name	ANDHFYROLSJFHEIOMC	
Pcode	562188261631321879	
Opr	8888	
Mac	1234	
MacGp	56	
Date 2016-09-09		
Seq	Time	Net
001	14:08:51	2.499 kg
002	14:08:55	5.002 kg
003	14:08:59	5.002 kg
004	14:09:02	7.502 kg
005	14:09:06	10.004 kg
006	14:09:09	7.502 kg
-----		
006	Total	37.511 kg

### Data Explanation

Customer Code (if entered)

Product Code (If entered)

Operator No. (If entered)

Machine ID (If entered)

Machine Group No. (If entered)

Date of 1st Printout

Accumulation No., Time of Printout and Net Weight or Pieces

Total Accumulation No. and Total Net Weight or Pieces

49 When Lab 4 is selected under in F16 and/or F17.

50 When Lab 5 is selected under in F16 and/or F17.

## 16. Label Printing

This instrument supports the below label printer models: -

- LP50 by Datecs ([www.datecs.bg/en](http://www.datecs.bg/en))
- TDP247, TDP345 by TSC ([www.tscprinters.com](http://www.tscprinters.com))
- TTP247, TTP345 by TSC ([www.tscprinters.com](http://www.tscprinters.com))

### Notes: -

- Set all preferred operation parameters according to F16 and/or F17 listed on **5.4**.
- Refer to **Appendix E** for TSC printer installation and setup procedures.
- Refer to **Appendix F** for detail on how to create and upload label to TSC printer by Bartender Label software.

### Cautions: -

1. Do not combine data of different working modes on the same label.
2. Do not print any labels of non-current working mode. This will retrieve wrong data of non-current working mode.
3. Print only label data when the same working mode is in operation.
4. Do not combine data of various working modes on same label. This will retrieve wrong data of non-current working mode.

### 16.1 Label Format Groups & Label File Names

2 label format groups are available, these are: -

- FL1 (label file group 1), and
- FL2 (label file group 2).

#### 16.1.1 FL1 (Label Format Group 1)

**FL1** (format group 1) is for current transaction data printing (during normal working status).

100 printout selections (00 ~ 99) are available in format group 1. In order to trigger the preferred label to be printed, label files stored in printer for this format group 1 must have a file name of AA01, AA02, AA03.... AA99.



- **FL1 00:** - Select this to disable current transaction label printing.
- **FL1 01:** - Select this to print label file AA01 stored in printer.
- **FL1 02:** - Select this to print label file AA02 stored in printer.
- ....
- **FL1 98:** - Select this to print label file AA98 stored in printer.
- **FL1 99:** - Select this to print label file AA99 stored in printer.

### **16.1.2 FL2 (Label Format Group 2)**

**FL2** (format group 2) is for totalized (MR) data printing (during normal working status).

100 printout selections (00 ~ 99) are available in format group 2. In order to trigger the preferred label to be printed, label files stored in printer for this format group 1 must have a file name of BB01, BB02, BB03.... BB99.

- **FL2 00:** - Select this to disable totalized (MR) data label printing
- **FL2 01:** - Select this to print label file BB01 stored in printer.
- **FL2 02:** - Select this to print label file BB02 stored in printer.
- ....
- **FL2 98:** - Select this to print label file BB98 stored in printer.
- **FL2 99:** - Select this to print label file BB99 stored in printer.

## **16.2 Label Programming**

Prompt commands, information description, working mode and suggested length on label are listed on the below table.

**Caution:** - Do not combine information of different working mode on the same label.

### 16.2.1 Label programing information table

Prompt Command <sup>51</sup>	Description	Working Mode <sup>52</sup>	Suggested Length
<b>a</b>	Peak Value	Peak	9
<b>b</b>	Product Code	All	18
<b>c</b>	Total accumulated pieces	Piece count	10
<b>d</b>	Machine ID	All	4
<b>e</b>	Machine Group Number	All	2
<b>f</b>	Operator Number	All	6
<b>K</b>	Date	All	10
<b>L</b>	Time	All	8
<b>M</b>	No. of accumulated transaction (8 digits with leading space)	All	8
<b>m</b>	No. of accumulated transaction (6 digits with leading zero)	All	6
<b>N</b>	Total accumulated weight	All	9
<b>n</b>	Total accumulated weight without unit or decimal	All	6
<b>O</b>	Net weight	All	10
<b>o</b>	Net weight without unit or decimal	All	6
<b>P</b>	Tare weight	All	10
<b>p</b>	Tare weight without unit or decimal	All	6

<sup>51</sup> Prompt commands are case sensitive.

<sup>52</sup> "All" means the information is good for all working modes.

<b>Q</b>	Gross weight	All	10
<b>q</b>	Gross weight without unit or decimal	All	6
<b>R</b>	HI limit <sup>53</sup>	All	10
<b>S</b>	LO limit <sup>54</sup>	All	10
<b>T</b>	Comparison Result	All	11
<b>U</b>	Number of piece	Piece Count	10
<b>V</b>	Average piece weight	Piece Count	9
<b>Y</b>	Weight hold	Animal Weighing	11
<b>y</b>	Weight hold without unit or decimal	Animal Weighing	6
<b>Z</b>	Customer Code	All	18



---

53 Each working mode has its own Hi Limit format (weight for weighing & auto tare accumulation mode; pieces for piece count mode. If Hi Limit has to be printed, set Hi Limit value under the preferred working mode.

54 Each working mode has its own Lo Limit format (weight for weighing mode& auto tare accumulation; pieces for piece count mode. If Hi Limit has to be printed, set Hi Limit value under the preferred working mode.

## 16.2.2 Label programming sample

### 16.2.2.1 Sample label of current transaction (FL1)

<b>Fidelity Measurement</b>	
Product Name	
P. Code 123456	
	
123456	
Net	50.00kg
	
50.00kg	
Tare	25.00kg
Gross	75.00kg
23.06.2012	17:28:08

0



P

Q

L

K

### 16.2.2.2 Sample label of totalized data (FL2)

<b>Fidelity Measurement</b>	
Product Name	
P. Code 123456	
	
123456	
	
<b>Fidelity Measurement</b>	
<b>Net Total = 300.00kg</b>	
Bags In Box=	6
Box Weight=	25.00kg
23.06.2012	17:28:58

N

M

P

L

K

## 16.3 Repetitive Printout

This Instrument supports repetitive printout under Manual print mode. Press **[Print/M+]** for additional printout copies.

Conditions and criteria as below: -

- a. When Auto Accumulation is set to On: Repetitive print is only possible when the actual weight on scale is equal to the weight value of the 1<sup>st</sup> printout.
- b. When Auto Accumulation is set to Off: Repetitive print is possible if minimum output weight set is matched and when **[Print/M+]** is pressed.
- c. Weight value of repetitive printout will not change the total accumulation result. Only the weight value of the 1<sup>st</sup> printout will be accumulated to memory.

## 17. Built-in Battery & Recharging

### 17.1 Battery Operation Time

Remaining battery power of the built-in rechargeable battery is displayed by the **Battery Power/Level Indicator**.

### 17.2 Symbols & Remaining Power



Full Battery:  $\geq 6.3V$ .



2 Blocks:  $\geq 6.0V$  (Battery level~75%).




1 Block:  $\geq 5.7V$  (Battery level~20%).




Frame only:  $< 5.7V$  (Battery level is less than 15%).

### 17.3 Battery Recharge

When  appears, it means that the built-in rechargeable battery is at low voltage status. It is recommended to recharge as soon as possible.

To protect the built-in rechargeable battery, this instrument will be powered off automatically when battery is at extremely low level. If this is the case, do not attempt to power this instrument on. Recharge this instrument immediately. Fail to do so may cause unrecoverable damages to the built-in rechargeable battery.

Battery charging status is shown by the Battery Power/Level Indicator: -

- Progressing: - Recharging in process.
- Flashing  : - Recharge completed.

Battery recharge is possible while operating. Overcharge protection circuit is inside to prevent battery damages from overcharge.

**Note:** - This instrument will auto power on when the power adaptor when an energized power adaptor is plugged in.

## 18. Error Codes

Error Code No.	Description
<b>Err 1</b>	Time value error
<b>Err 2</b>	Date value error
<b>Err 3</b>	Exceed manual zero
<b>Err 4</b>	Offset out of range / unstable during power on (5 minutes for OIML and NTEP mode)
<b>Err 5</b>	No load cell detected
<b>Err 6</b>	Tare operation error
<b>Err 7</b>	Logic error. HI limit to be set is lower than LO limit (and HI is not = 0)
<b>Err 8</b>	Logic error. LO limit to be set is higher than HI limit (and HI is not = 0)
<b>Err 13</b>	Exceed maximum power on
<b>Err 19</b>	Capacity or division setting error (Division set is higher than 10000d)
<b>Err 22</b>	Manual Zero and Tare stability error
<b>Err 23</b>	Capacity setting error, Capacity 1 > Capacity 2
<b>Err 24</b>	Division setting error, e1 > e2
<b>Err 25</b>	Span gain is too low
<b>Err 26</b>	Not able to obtain stable status for longer than 10 sec
<b>Err 27</b>	<ul style="list-style-type: none"> <li>Calculated value per e of Cal 2 varies more than 1% as of Cal 1. Properly a load cell problem.</li> <li>Mass value of Cal 2 is less than 150% of Cal 1.</li> </ul>
<b>Err 28</b>	Maximum accumulation limit is exceeded.
<b>--oL--</b>	Overload (Gross weight is more than Max plus 9d)
<b>HALt</b>	Major system error detected. Power off instrument and remove power adaptor immediately. Then check load

	cell connection and system power status.
<b>UndEr</b>	Negative Weight values exceeds display range
<b>Reboot</b>	Important parameters have been changed. Power off and then power on instrument again to reboot.
<b>-----</b>	Negative Tare value exceeds display range

## 19. Daily Care & Maintenance

1. Clean the instrument with a soft, damp cloth. If necessary, use a mild detergent in water.
2. Do not use any harsh, abrasive material, acetone, volatile solvent, thinner or alcohol for cleaning.
3. Verify the accuracy of this instrument periodically. Re-calibrate if necessary. In some countries, calibration requires authorized/qualified agent. Contact your dealer for more information.
4. Store this instrument in a dry and clean place,
5. Recharge battery before and every 4 months during long time storage.

## 20. Downloading All Appendixes

For environment protection and information updating speed, all Appendixes of this manual are listed on the full manual version which is available for download at: -


[www.fi-measurement.com/resource/manuals](http://www.fi-measurement.com/resource/manuals)

## 21. Appendix A: - Keyboard Commands<sup>55</sup>

Keyboard commands can be sent to this instrument from computer through any standard communication program to simulate keyboard entries.

To enable keyboard commands, connect the external peripheral which generates keyboard commands to Comport 2 and set Comport 2 to CMD. Keyboard Command format as below: -

- a. Hex code 0D (CR), then
- b. Hex code 0A (LF) then
- c. Letter shown on below illustration diagram, then
- d. Space (Hex code 20).



---

<sup>55</sup> Keyboard commands are case sensitive.



# 22. Appendix B: - PC Output Protocols

Data Code	Description
,	Comma
+,-	Polarity Sign Positive = space, Negative = minus (-)
P	Polarity Sign Positive = 0, Negative = minus (-) Control command <ul style="list-style-type: none"> <li>• ETX : End of Text</li> <li>• STX : Start of Text</li> <li>• CF : Carriage Return</li> <li>• LF : Line Feed</li> <li>• SOH : Start of Heading</li> <li>• = : ASCII equal sign (DEC 61, HEX 3D)</li> </ul>
C	
G/N	Gross/Net <ul style="list-style-type: none"> <li>• NT = Net weight</li> <li>• GS = Gross weight</li> </ul>
NET	Net Weight
S	Status Code <ul style="list-style-type: none"> <li>• ST for Stable</li> <li>• US for unstable</li> </ul>
R	Revered 7 digits weight value including location of decimal point. If there is no decimal point, then the last character = space.
SP	Space
SWA	Status Word A
SWB	Status Word B
U	Weight Unit <ul style="list-style-type: none"> <li>• kg = kilogram</li> <li>• lb = pound</li> <li>• g(space) = gram</li> </ul>
W	7 digits weight value including location of decimal point. If there is no decimal point, then the first character = space.

Weight

Protocol 1

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
s	s	,	G	N	+	-	w	w	w	w	w	w	,	u	u	c	c
S	T		G	S				1		0	0	0		k	g	CR	LF
S	T		G	S	-			0		0	1	2		k	g	CR	LF
S	T		G	S		2	2	0		4	5	0		l	b	CR	LF

220.450lb

1.000kg

-0.012kg

Protocol 2

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
c	SWA	SWB	SP	Field 1 (Net Weight)				Field 2 (Tare Weight)				CR				CR
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
STX	5	7		0	0	0	0	1	5	0	0	2	0	0	0	CR
STX	5	!		2	2	0	4	5	0	1	0	0	0	0	0	CR

Net

-0.015kg

220.450lb

Tare Value

2.000kg

100.000lb

Protocol 3

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
c	c	SP	+	-	w	w	w	w	w	w	SP	u	u	SP	SP	SP	c	c	c
SOH	STX					1		0	0	0		k	g				CR	LF	LF
SOH	STX		-			0		0	1	5		k	g				CR	LF	LF
SOH	STX			2	2	0		4	5	0		l	b				CR	LF	LF

1.000kg

-0.015kg

220.450lb

Protocol 4

1	2	3	4	5	6	7	8	9
c	c	r	r	r	r	r	r	p
=	0	0	0	.	1			0
=	5	1	0	.	0			-
=	0	0	5	4	.	0	2	0

1.000kg

-0.015kg

220.450lb

Protocol 5

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
s	s	,	G	N	,	+	-	w	w	w	w	w	w	u	u	c	c
S	T		G	S					1	.	0	0	0	0	k	g	CR
S	T		G	S		-		0	0	.	0	1	5	k	g	CR	LF
S	T		G	S			2	2	0	.	4	5	0	l	b	CR	LF

1.000kg

-0.015kg

220.450lb

Protocol 6

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
NET			SP	+-	w	w	w	w	w	w	w	u	u	c	c
N	E	T					1	.	0	0	0	k	g	CR	LF
N	E	T		-			0	.	0	1	4	k	g	CR	LF
N	E	T			2	2	0	.	4	5	0	l	b	CR	LF

1.000kg  
-0.014kg  
220.450lb

Protocol 7

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
c	c	SP	+-	w	w	w	w	w	w	w	SP	u	u	SP	SP	SP	c	c
SOH	STX					1	.	0	0	0	0	k	g				CR	LF
SOH	STX		-			0	.	0	1	5		k	g				CR	LF
SOH	STX			2	2	0	.	4	5	0		l	b				CR	LF

1.000kg  
-0.015kg  
220.450lb

Protocol 8

1	2	3	4	5	6	7	8	9	10
c	+-	w	w	w	w	w	w	w	c
STX			1	.	0	0	0	0	ETX
STX	-			0	.	0	1	5	ETX
STX		2	2	0	.	4	5	0	ETX

1.000kg  
-0.015kg  
220.450lb

Protocol 9

1	2	3	4	5	6	7	8	9	10	11	12
c	+-	SP		w	w	w	w	w	u	u	c
STX				1	.	0	0	0	k	g	ETX
STX	-			0	.	0	1	5	k	g	ETX
STX		2	2	0	.	4	5	0	l	b	ETX

1.000kg  
-0.015kg  
220.450lb

## 23. Appendix C: - Operation Result Commands<sup>56</sup>

Operation Result commands are those commands which are used to request operation result and details from this instrument. These commands can be sent to this instrument from computer through any standard communication program. Command format as below: -

- a. Hex code 0D (CR), then
- b. Hex code 0A (LF) then f
- c. Command code listed on below command table, then
- d. Space (Hex code 20).

Refer to below table for commands details.

**Operation Result Commands Table**

Prompt Command <sup>57</sup>	Description
<b>a</b>	Peak Value
<b>b</b>	Product Code
<b>c</b>	Total accumulated pieces
<b>d</b>	Machine ID
<b>e</b>	Machine Group Number
<b>f</b>	Operator Number
<b>g</b>	Customer Code
<b>J</b>	Current status, weight and tare weight values
<b>K</b>	Date
<b>L</b>	Time

56     Connect the external peripheral which generates operation result commands to Comport 2 and set Comport 2 to CMD.

57     Prompt commands are case sensitive.

<b>M</b>	No. of accumulated transaction
<b>N</b>	Total accumulated weight
<b>n</b>	Total accumulated weight without unit or decimal
<b>O</b>	Net weight
<b>o</b>	Net weight without unit or decimal
<b>P</b>	Tare weight
<b>p</b>	Tare weight without unit or decimal
<b>Q</b>	Gross weight
<b>q</b>	Gross weight without unit or decimal
<b>R</b>	HI limit
<b>S</b>	LO limit
<b>T</b>	Comparison Result
<b>U</b>	Number of piece
<b>V</b>	Average piece weight
<b>Y</b>	Weight hold
<b>y</b>	Weight hold without unit or decimal
<b>Z</b>	Read internal count (AD) value

## 24. Appendix D: - System Parameter Inquiry Commands<sup>58</sup>

System parameter inquiry commands are used to check system parameter settings. Command format as below: -

- a. Hex code 0D (ASCII code \$0D), then
- b. Hex code 0A (LF) (ASCII code \$0A) then
- c. Command code listed on below table (all commands are case sensitive), then
- d. Hex code 20 (ASCII code \$20).

Command Code	Description	Number & Description Responded Parameters Notes: - <ul style="list-style-type: none"><li>a. If more than one parameter, semi colon separation is inserted between parameters.</li><li>b. Response from instrument always end up with Hex code 0D 0A</li></ul>
Aa	Calibration weight unit and application	<ul style="list-style-type: none"><li>• <b>d1</b> = calibration weight unit: - 0 = kg; 1 = lb.</li><li>• <b>d2</b> = application: - 0 = none; 1 = OIML; 2= NTEP</li></ul>
Ab	Decimal format, decimal point of kg, g and lb	<ul style="list-style-type: none"><li>• <b>d1</b> = decimal format: - 0 = dot; 1 = comma</li><li>• <b>d2</b> = kg: - 0 = no decimal; 1 = 1 decimal place..... 4 = 4 decimal place</li><li>• <b>d3</b> = g: - 0 = no decimal; 1 = 1 decimal place..... 4 =</li></ul>

<sup>58</sup> Connect the external peripheral which generates system parameter inquiry commands to Comport 2 and set Comport 2 to CMD.

		<p>4 decimal place; n = not applicable</p> <ul style="list-style-type: none"> <li>• <b>d4</b> = lb: - 0 = no decimal; 1 = 1 decimal place..... 4 = 4 decimal place</li> </ul>
Ac	Capacity1 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = capacity in kg. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d2</b> = capacity = g. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d3</b> = capacity = lb. Data length = 8 including decimal with leading space (Hex code 20)</li> </ul>
Ad	Capacity 2 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = mode: - 0 = Off; 1 = dual weighing range; 2 = dual interval</li> <li>• <b>d2</b> = capacity in kg. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d3</b> = capacity = g. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d4</b> = capacity = lb. Data length = 8 including decimal with leading space (Hex code 20)</li> </ul>
Ae	Division 1 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = kg: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>

		<ul style="list-style-type: none"> <li>• <b>d2</b> = g: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li>• <b>d3</b> = lb: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>
Af	Division 2 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = kg: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li>• <b>d2</b> = g: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li>• <b>d3</b> = lb: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>
Ag	Gravity Factor of Calibration Place and Operation Place	<ul style="list-style-type: none"> <li>• <b>d1</b> = gravity factor of calibration place. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d2</b> = gravity of location of operation place. Data length = 8 including decimal with leading space (Hex code 20).</li> </ul>
Ah	Linearity Compensation Function	0 = Off; 1 = On
Ai	ad value of zero point (offset) value, weight value of LD1, ad value of LD1, weight value of LD2 and ad value of LD2	<ul style="list-style-type: none"> <li>• <b>d1</b> = ad value of zero point. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d2</b> = weight value of LD1. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d3</b> = ad value of LD1. Data length = 8 (integers only)</li> </ul>



		<p>with leading space (Hex code 20).</p> <ul style="list-style-type: none"> <li>• <b>d4</b> = weight value of LD2. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d5</b> = ad value of LD2. Data length = 8 (integers only) with leading space (Hex code 20).</li> </ul>
Aj	ad value of zero point (offset), span weight value, net span AD value	<ul style="list-style-type: none"> <li>• <b>d1</b> = as value of zero point. Data length = 8 (integers only) with leading space (Hex code 20).</li> <li>• <b>d2</b> = span weight value. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d3</b> = net span AD value. Data length = Data length = 8 (integers only) with leading space (Hex code 20)</li> </ul>
Ak	Weight unit enable/disable for kg, g and lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = kg: - 0 = Off; 1 = On</li> <li>• <b>d2</b> = g: - 0 = Off; 1 = On</li> <li>• <b>d3</b> = lb: - 0 = Off; 1 = On</li> </ul>
Al	Filter strength	0 = level 1; 1 = level 2; ... ;7 = level 8; 8 = level 9
Am	Initial Zero range, manual zero range, auto zero tracking speed	<ul style="list-style-type: none"> <li>• <b>d1</b> = initial zero range: - 0 = Off, 1 = 1%, 2 = 2%; ... 5 = 5%; 6 = 10%; 7 = 20%</li> <li>• <b>d2</b> = manual zero range: - 0 = 1%; 1 = 2%; 2 = 3%; 3 = 4%; 4 = 5%; 5 = 10%; 6</li> </ul>

		<p>= 20%; 7 = 50%; 8 = 75%; 9 = 100%</p> <ul style="list-style-type: none"> <li>• <b>d3</b> = auto zero tracking speed: - 00 = Off; 01 = 0.25e; 02 = 0.50e; 03 = 10e; 04 = 1.5e; 05 = 2.0e; 06 = 2.5e; 07 = 3.0e; ....; 09 = 5e; 10 = 7.5e; 11 = 10e</li> </ul>
An	Auto tare, repetitive tare and preset tare	<ul style="list-style-type: none"> <li>• <b>d1</b> = auto tare: - 0 = Off; 1 = On; 2= Continuous</li> <li>• <b>d2</b> = repetitive tare: - 0 = Off; 1 = On</li> <li>• <b>d3</b> = Preset tare: - 0 = Off; 1 = On</li> </ul>
Ao	Stability control of manual zero and manual tare	<ul style="list-style-type: none"> <li>• <b>d1</b> = manual zero stability control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d2</b> = manual tare stability control: - 0 = no (disable); 1 = Yes (enable)</li> </ul>
Ap	Auto power off time, backlight brightness, color ratio, keypad buzzer and system buzzer	<ul style="list-style-type: none"> <li>• <b>d1</b> = auto power off time: - 0 = Off; 1 = 1 minute; 2 = 3 minute; 3 = 5 minute; 4 = 10 minute; 5 = 20 minute</li> <li>• <b>d2</b> = backlight brightness (01 ~ 99). 01 = lowest, 99 = highest.</li> <li>• <b>d3</b> = color ratio (01 ~ 99). 01 = least red output, 99 = highest red output</li> <li>• <b>d4</b> = keypad buzzer: - 0 = Off; 1 = On</li> <li>• <b>d5</b> = system buzzer: - 0 = Off; 1 = On</li> </ul>

Aq	Check result buzzer, near zero value, high limit for weighing, low limit for weighing, high limit for counting, low limit for counting	<ul style="list-style-type: none"> <li>• <b>d1</b> = check result buzzer: - 0 = Off; 1 = In; 2 = Out; 3 = hi, 4 = lo</li> <li>• <b>d2</b> = near zero value. Data length = 8 with leading space (Hex code 20)</li> <li>• <b>d3</b> = Hi Limit for weighing. Integer only. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d4</b> = Lo Limit for weighing. Integer only. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d5</b> = Hi Limit for counting. Integer only. Data length = 8 (integers only) with leading space (Hex code 20).</li> <li>• <b>d6</b> = Lo Limit for counting. Integer only. Data length = 8 (integers only) with leading space (Hex code 20).</li> </ul>
Ar	Comport 1 working mode, baud rate, output protocol, print stability control, transmission interval, Auto Accumulation, number of copy, check result control, print format, label	<ul style="list-style-type: none"> <li>• <b>d1</b> = working mode: - 0 = Auto 1; 1 = Auto 2; 2 = Auto 3; 3 = Manual; 4 = PC; 5 = Scanner; 6 = Off</li> <li>• <b>d2</b> = baud rate: - 0 = 1200; 1 = 2400; 3 = 4800; 3 = 9600; 4 = 19200; 5 = 38400; 6 = 57600; 7 = 115200; 8 = 256000</li> </ul>

	<p>format group 1 file number, label format group 2 file number, data length, parity, minimum output weight value</p>	<ul style="list-style-type: none"> <li>• <b>d3</b> = protocol: - 0 = Protocol 1; 1 = Protocol 2; ...; 8 = Protocol 9</li> <li>• <b>d4</b> = print stability control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d5</b> = transmission interval: - 0 = int 0; 1 = int 0.5; 2 = int 1.0; 3 = int 1.5; ....; 9 = int 300.</li> <li>• <b>d6</b> = Auto Accumulation: - 0 = Off (disable); 1 = On (enable)</li> <li>• <b>d7</b> = number of copy: - 0 = 1 copy; ... 7 = 8 Copy</li> <li>• <b>d8</b> = check result control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d9</b> = print format: - 0 = Lab 1; 1 = Lab 2; 2 = Lab 3; 3= Lab 4; 4 = Lab 5; 5 = LP-50; 6 = TSC</li> <li>• <b>d10</b> =label format group 1 file number (00~99): - 00 = file AA00; 1 = file AA01; ...98 = file AA98; 99 = file AA99</li> <li>• <b>d11</b> = label format group 2 file number (00~99): - 00 = file BB00; 1 = file BB01; ...98 = file BB98; 99 = file BB99</li> <li>• <b>d12</b> = data length: - 0 = 7bit; 1 = 8bit</li> <li>• <b>d13</b> = parity: = 0 = none; 1 = Odd; 2 = even</li> </ul>
--	---	---

		<ul style="list-style-type: none"> <li>• <b>d14</b> = minimum output weight value: - 0 = from 00d; 01 = from 01d; ...; 20 = from 20d. Data length = 2 with leading zero</li> </ul>
As	Comport 2 working mode, baud rate, output protocol, print stability control, transmission interval, Auto Accumulation, number of copy, check result control, print format, label format group 1 file number, label format group 2 file number, data length, parity, minimum output weight value	<ul style="list-style-type: none"> <li>• <b>d1</b> = working mode: - 0 = Auto 1; 1 = Auto 2; 2 = Auto 3; 3 = Manual; 4 = PC; 5 = CMD; 6 = Off</li> <li>• <b>d2</b> = baud rate: - 0 = 1200; 1 = 2400; 3 = 4800; 3 = 9600; 4 = 19200; 5 = 38400; 6 = 57600; 7 = 115200; 8 = 256000</li> <li>• <b>d3</b> = protocol: - 0 = Protocol 1; 1 = Protocol 2; ...; 8 = Protocol 9</li> <li>• <b>d4</b> = print stability control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d5</b> = transmission interval: - 0 = int 0; 1 = int 0.5; 2 = int 1.0; 3 = int 1.5; ....; 9 = int 300.</li> <li>• <b>d6</b> = Auto Accumulation: - 0 = Off (disable); 1 = On (enable)</li> <li>• <b>d7</b> = number of copy: - 0 = 1 copy; ... 7 = 8 Copy</li> <li>• <b>d8</b> = check result control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d9</b> = print format: - 0 = Lab 1; 1 = Lab 2; 2 = Lab 3; 3 = Lab 4; 4 = Lab 5; 5 = LP-50; 6 = TSC</li> </ul>

		<ul style="list-style-type: none"> <li>• <b>d10</b> =label format group 1 file number (00~99): - 00 = file AA00; 1 = file AA01; ...98 = file AA98; 99 = file AA99</li> <li>• <b>d11</b> = label format group 2 file number (00~99): - 00 = file BB00; 1 = file BB01; ...98 = file BB98; 99 = file BB99</li> <li>• <b>d12</b> = data length: - 0 = 7bit; 1 = 8bit</li> <li>• <b>d13</b> = parity: = 0 = none; 1 = Odd; 2 = even</li> <li>• <b>d14</b> = minimum output weight value: - 0 = from 00d; 01 = from 01d; ...; 20 = from 20d. Data length = 2 with leading zero</li> </ul>
At	Current weight unit and function mode	<ul style="list-style-type: none"> <li>• <b>d1</b> = weight unit: - 0 = kg; 1 = g; 2 = lb</li> <li>• <b>d2</b> = function mode: - 0 = weighing; 1 = piece count; 2 = AT 1; 3 = peak hold; 4= animal weighing</li> </ul>
Av	Auxiliary Function mode enable/disable status	<ul style="list-style-type: none"> <li>• <b>d1</b> = Piece count: - 0 = Off; 1 = On</li> <li>• <b>d2</b> = ATM: - 0 = Off; 1 = On</li> <li>• <b>d3</b> = Peak Hold: - 0 = Off; 1 = On</li> <li>• <b>d4</b> = Animal Weighing: - 0 = Off; 1 = On</li> </ul>
Aw	Machine ID & group number	<ul style="list-style-type: none"> <li>• <b>d1</b> = 4-digit machine ID number. Nothing = no machine ID is set</li> </ul>

		<ul style="list-style-type: none"> <li><b>d2</b> = 2-digit machine group number. Nothing = no group number is set</li> </ul>
Ax	Operator Number	4-digit operator number. **** = no operator number is set

## 25. Appendix E: - TSC Printer Installation & Setup Procedures

### E.1 Before Installation

Get the below ready before printer installation.

1. An appropriate cable to connect printer and computer. This cable usually comes with the printer. If not, contact your printer supplier.
2. Printer installation driver. This driver usually comes with the printer. If not, contact your printer supplier.
3. Diagnostic tool for printer. This tool usually comes with the printer. If not, contact your printer supplier or download it at: -

[www.tscprinters.com/cms/plugin/download\\_en/print\\_desc.php?file\\_id=141&width=250&link=www.tscprinters.com/cms/upload/download\\_en/DiagTool\\_V163.zip](http://www.tscprinters.com/cms/plugin/download_en/print_desc.php?file_id=141&width=250&link=www.tscprinters.com/cms/upload/download_en/DiagTool_V163.zip)

4. TCF file for printer. The suitable TCF file can be downloaded at: -

- For TDP247 and TDP345: -
- [www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)
- For TTP247and TTP345: -
- [www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)

#### E.1.1 Printer Installation



1. Turn off the printer, connect the appropriate cable, and then turn on the printer.
2. If the printer supports Plug-and-Play, and you have connected it using a USB or Parallel cable, then the Windows Add Hardware Wizard will automatically detect the printer and display a dialog that allows you to install a driver. Click Cancel and do not install the driver using this wizard.
3. Run the Driver Wizard utility from the Installation Directory where the driver files are located.
4. Select Install Printer Drivers and complete the wizard.

5. The driver should now be installed.

### E.1.2 Uploading TCF File to Printer

In order to allow proper operation between this instrument and TSC label printer, a TCF file must be uploaded to printer.

1. Connect printer with computer.
2. Power on printer.
3. Download the correct TCF file point 4 of E.1.
4. Unzip the download file and save in to computer.
5. Run Diagnostic tool for printer.
6. Click on Command Tool.
7. Click on Send file.
8. Double click on the TCF file and it will be uploaded to printer automatically.





## 26. Appendix F: - Create & Upload Label to TSC Printer

### F.1 Selecting the Correct Edition for Bartender Software



To enable label uploading from computer to TSC printer, it is necessary to run as Bartender as Automation or Enterprise Automation edition. Procedures as below: -

1. Install Bartender Software to computer. The Bartender software usually comes with the TSC printer. If not, please contact your printer supplier.
2. Run Bartender, then click on Help, then click on Edition Selection.
3. Select Enterprise Automation or Automation, then click OK.
4. At this point, correct Bartender edition is selected.


### F.2 Adding Information from Instrument to Label & Uploading to a TSC Printer

The below procedures is based on Bartender Label Software. If a different label creating software is used, contact your label software for more details if in doubt.


1. Create the foundation of a label by Bartender. All information to be obtained from instrument should be added afterward.
2. Once the label foundation has been completed; (a) click on File and (b) select Export Printer Code Template.
3. On Print System; (a) select TSC KP-100/200 (Flash) and (b) select To Port.
4. Click More Option.
5. Then (a) click Print Dialog Data Sources, then (b) click on Format ID/Name.




6. On Template Field, select Template Field for Type.
7. Enter the correct label file name on Name/Value. Refer to **16.1** for correct file name format.



8. (a) click Copies, check KDU and (b) input asterisk (\*) on Prompt box.
9. Below procedures explain how to edit information to be obtained from instrument.



10. Click Template Object Data Sources and Select the object which information from instrument (for example net, gross, tare weight and product code) to be sent to printer and printed on label.




11. Double click on the preferred data source to which variant(s) has/have to add.

- (a) check the box below External Keyboard, then
- (b) enter the appropriate command on the Prompt Box (refer to **16.2.1** for command detail).

12. Select Auto on the Source box under Template Field
13. Repeat point 11 to ~ 12 for all other data sources.

14. Click OK.

15. Click Export. In case of Verification Messages appear, select one of method on the dialogue box to fix and click Continue.





Fidelity Measurement Co., Ltd.  
[www.fi-measurement.com](http://www.fi-measurement.com)  
e-mail: [info@fi-measurement.com](mailto:info@fi-measurement.com)