



# **Multi-Function Weighing Scales Series Operation Manual (Full Version)**



**PLEASE READ THIS MANUAL VERY CAREFULLY  
BEFORE OPERATING THIS INSTRUMENT**

***Specifications subject to change without prior notice***

V135 Rev 001 February 2018



# Content

- 1. Reminders ..... 9
  - 1.1 Metrological Legislation ..... 9
  - 1.2 Seal & Serial Number ..... 9
  - 1.3 Warm Up Time ..... 9
  - 1.4 Placing the Instrument ..... 9
  - 1.5 Cautions ..... 9
  - 1.6 Support & Service ..... 10
- 2. Specifications ..... 10
- 3. Keys, Display & Connection Points ..... 11
  - 3.1 Keys & Display Indicators ..... 11
  - 3.2 Connection Points ..... 14
- 4. Power & Comports ..... 15
  - 4.1 Power Adaptor ..... 15
  - 4.2 Built-In Rechargeable Battery ..... 15
  - 4.3 Comports on Instrument ..... 15
  - 4.4 Comports Pin Assignment ..... 15
- 5. Initial Setup ..... 16
  - 5.1 Internal Functions & Settings ..... 16
  - 5.2 How to Enter & Select Internal Function ..... 16
  - 5.3 Key Function under Internal Function Mode ..... 17
  - 5.4 Internal Function Table ..... 18
  - 5.5 Setting Comport 1 & Comport 2 ..... 23
    - 5.5.1 When comport is set as PC ..... 24
    - 5.5.2 When comport is set as CMD ..... 25
    - 5.5.3 When comport is set as Manual ..... 25
    - 5.5.4 When comport is set as Auto (Auto 1~3) ..... 27

5.5.5 When Comport 1 is set as Scanner .....	28
6. Basic Operations .....	29
6.1 Power On, Inputting Operator Number & Power Off .....	29
6.2 Warm Up Time & Set Weight to Zero When Unloaded.....	29
6.3 Keyboard Lock .....	29
6.4 Tare Modes .....	29
6.4.1 Manual Tare .....	30
6.4.2 Auto Tare (F12) .....	30
6.4.3 Repetitive Tare (F13) .....	30
6.4.4 Preset Tare (F63) .....	31
6.5 Select the Preferred Function Mode .....	32
6.6 Weight Units.....	32
6.6.1 Weight unit gram (g) .....	32
6.6.2 Select the preferred weight unit.....	32
6.7 Memory Accumulation .....	32
6.7.1 Automatic Accumulation.....	33
6.7.2 Manual Accumulation.....	33
6.7.3 When data is accumulated to memory .....	33
6.7.4 Memory recall and clearance.....	33
6.8 Extended Display Mode .....	34
6.9 Tri-color Backlight .....	34
6.9.1 When powered by built-in rechargeable battery .....	34
6.9.2 When powered by external power adaptor.....	35
6.10 Customer & Product Code .....	35
6.10.1 Enter a customer & product code manually.....	36
6.10.2 Enter a customer & product code by scanner .....	37
6.10.3 Clear a customer & product code entered .....	37

6.10.4 Print a customer & product code entered .....	37
6.11 Quick Access PLU.....	37
6.11.1 Weight limits PLUs .....	38
6.11.2 Quantity limits PLUs.....	38
6.11.3 Preset Tare PLUs .....	39
6.11.4 Customer & product code PLUs .....	40
6.12 Enter a Key Command by Scanner .....	41
7. Weighing Mode .....	41
8. Piece Count Mode.....	42
8.1 Auto Unit Piece Weight Enhancement Function .....	42
8.2 Shift among Quantity, Average Piece Weight and Weight Info.....	42
8.3 Recall the Average Piece Weight before Powered Off .....	43
9. Action-Tare-Memory (ATM) .....	43
9.1 Description of ATM Mode.....	43
9.2 Basic ATM Settings .....	43
9.3 Start Using ATM .....	44
9.3.1 Weight Check Control for ATM .....	44
10. Animal Weighing Mode .....	45
10.1 Description of Animal Weighing Mode .....	45
10.2 Basic Animal Weighing Settings .....	45
10.3 Start Using Animal Weighing .....	46
11. Check Function .....	46
11.1 Set Lo & Hi Limits.....	46
11.2 Hints for entering Lo and Hi Limits.....	47
11.3 Cancel Check Function .....	47
12. Dynamic Check Mode .....	47
12.1 Near Zero Function Description.....	48

12.2 Near Zero Value Illustration Diagram.....	48
13. Communication & Outputs .....	48
13.1 Print Output & Formats .....	48
13.2 Auto 1~3 Output & Formats .....	48
13.3 PC Output & Protocol .....	49
13.4 Sending Keyboard Commands from Computer.....	49
13.5 Requesting Operation Results & System Parameters by Computer...	49
13.6 PC Software.....	49
13.7 iOS and Android Apps.....	49
13.7.1 Using App via WIFI Connection .....	50
13.7.2 Using App via Bluetooth Connection .....	50
13.7.3 Bluetooth Default Settings when iOS is selected .....	50
13.7.4 Bluetooth Default Settings when Android is selected .....	51
13.7.5 Using App via Bluetooth Module by Third Party .....	51
13.7.6 Running App on a Smart Device.....	51
14. Printing Formats .....	53
14.1 Lab 1 Print Format.....	53
14.2 Standard Lab 2 Print Format .....	54
14.2.1 Standard Lab 2 print format for Weighing & ATM mode .....	54
14.2.2 Standard Lab 2 print format for Piece count mode.....	55
14.2.3 Standard Lab 2 print format for Animal weighing mode .....	55
14.3 Customizing Lab 2 Print Format .....	55
14.3.1 Print output format variants table.....	56
14.3.2 To edit custom Lab 2 print output format .....	57
14.4 Lab 3 Print Format.....	57
14.5 Lab 4 Print Format.....	58
14.6 Lab 5 Print Format.....	59

15. Label Printing .....	59
15.1 Label Format Groups & Label File Names .....	60
15.1.1 FL1 (Label Format Group 1) .....	60
15.1.2 FL2 (Label Format Group 2) .....	60
15.2 Label Programming .....	61
15.2.1 Label programming information table .....	61
15.2.2 Label programming sample .....	63
15.3 Quick Access to Label Settings .....	63
15.4 Repetitive Printout.....	64
16. Built-in Battery & Recharging .....	64
16.1 Battery Operation Time .....	64
16.2 Symbols & Remaining Power .....	64
16.3 Battery Recharge .....	65
17. Error Codes .....	65
18. Daily Care & Maintenance .....	67
19. Downloading All Appendixes .....	67
20. Appendix A: - Keyboard Commands .....	68
21. Appendix B: - PC Output Protocols .....	69
22. Appendix C: - Operation Result Commands .....	72
23. Appendix D: - System Parameter Inquiry Commands .....	74
24. Appendix E: - TSC Printer Installation & Setup Procedures .....	83
E.1 Before Installation .....	83
E.1.1 Printer Installation.....	83
E.1.2 Uploading TCF File to Printer .....	84
25. Appendix F: - Create & Upload Label to TSC Printer.....	85
F.1 Selecting the Correct Edition for Bartender Software .....	85
F.2 Adding Information from Instrument to Label & Uploading to a TSC Printer.....	85

F.3 Sample Label .....87



# **1. Reminders**

## **1.1 Metrological Legislation**

Because of metrological legislation, some metrological parameter settings are limited to be done by authorized personnel only. Do not attempt to change any parameters under internal function number F60 ~ F99. Contact your dealer for installation and technical assistance.

## **1.2 Seal & Serial Number**

This instrument is legal for trade only when it is sealed (and/or stamped) and bearing a serial number. Do not attempt to break the seal (or stamp) or serial number affixed to this instrument. No warranty service will be provided if the seal (or stamp) or data plate affixed to this instrument is damaged or removed. Always contact your dealer for after sales service.

## **1.3 Warm Up Time**

- a. Allow warm up period of not less than 60 seconds before calibration and usage. The higher the setup resolution of the scale, the longer the warm up period is required. In most cases, 120 seconds is a safe warm up period for all applications. This warm up period is needed to energy all components to reach a stable status.
- b. The internal count value is deemed stable when the internal AD count varies less than 3 counts within 2 seconds.
- c. To read the internal AD count value, enter internal function F1. The internal AD count value of a not yet fully energized PCB will go up continuously.

## **1.4 Placing the Instrument**

In order to obtain an accurate weighing result, this instrument must be placed on a strong and level surface. Avoid using this instrument in any environment where excessive wind flow, vibration and extreme temperature change exist.

## **1.5 Cautions**

- a. The instrument is not an explosion proof device.
- b. The instrument is not a water proof device.
- c. Do not open the instrument, no user serviceable parts inside. Always contact your dealer for service.

- d. Do not place this instrument in where shock, excessive vibration or extremes of temperature (before or after installation) exist.

## 1.6 Support & Service

Always contact your dealer for product information, after sales service and questions when in doubt.

## 2. Specifications

Model	Capacity (Max)	Readability (d)	$n_{\max}$
G2-1500B	1500g	0.1g	15,000
G2-3000B	3000g	0.2g	15,000
G2-7500B	7500g	0.5g	15,000
G2-15KB	15kg	1g	15,000
G2-30KB	30kg	2g	15,000
G2-3000L	3000g	0.1g	30,000
G2-6000L	6000g	0.2g	30,000
G2-15KL	15kg	0.5g	30,000
G2-30KL	30kg	1g	30,000
G2-5000H	5000g	0.05g	100,000
G2-10KH	10kg	0.1g	100,000
G2-20KH	20kg	0.2g	100,000
G2-20KX	20kg	0.1g	200,000
G2-3000III***	1500/3000g	0.5/1g	3000/3000
G2-6000III***	3000/6000g	1/2g	3000/3000
G2-15KIII***	6/15kg	2/5g	3000/3000
G2-30KIII***	15/30kg	5/10g	3000/3000
G2-5000V ##	5000g	1g	5000
G2-10KV ##	10kg	2g	5000
G2-25KV ##	25kg	5g	5000

Weight Units	kg/g/lb
Digits & Indications	<ul style="list-style-type: none"> <li>6 x 31mm HTN Bold Type Wide Angle LCD Numeric Digits</li> <li>Gross, Net, Stable, Zero, Weight Unit, Weighing Range, Battery Level Indicators</li> </ul>
Max. Tare Range	-Max or -Max <sub>1</sub> (Subtractive Tare)
Power Source	<ul style="list-style-type: none"> <li>Built-in Rechargeable Battery = 6V, 4AH</li> <li>External Power Adaptor = DC 12V, 1A</li> </ul>
Platter	210 x 250mm ABS Platter with Stainless Steel Insert
Operation Environment	<ul style="list-style-type: none"> <li>Version III, V, B: -10 ~ 40°C</li> <li>Version L: 0 ~ 40°C</li> <li>Version H &amp; X: 10 ~ 35°C</li> </ul> Non-condensed. R.H. ≤ 85%


***In the interest of improvement, specifications may change prior to notice***

\*\* Dual weighing range model.

## OIML approved models.

## 3. Keys, Display & Connection Points

### 3.1 Keys & Display Indicators



#### 1. [ON/OFF] Key

Press this key to turn this instrument on or off.

#### 2. [CHECK] Key

- When in operation mode: - to start check function and to enter value for Lo and Hi Limit.
- When in setting mode: - quick access to label settings.

### 3. **[FUNC/SET] Key**

- Short Press = FUNC: - to shift between weighing, piece count, auto tare memory and animal weighing<sup>1</sup> mode.
- Long Press = SET
  - a. to prompt/introduce an operation parameter/value during piece count, action-tare-accumulation and animal weighing mode.
  - b. when in weighing mode: - to access internal function setting mode (F1~F29)

### 4. **[MR/UNIT] Key<sup>2</sup>**

- Short Press = MR: - to recall total stored transactions.
- Long Press = UNIT: - to shift among various weight units (if weight unit conversation is enable).

### 5. **[TARE] Key**

To tare off the weight of a container.

### 6. **[ZERO] Key**

To set weight displayed to zero when unloaded.

### 7. **[PRINT/M+] Key**

To send print data out and/or accumulate current value to memory<sup>3</sup>.

### 8. **[CE/x10] Key**

To clear value entered during setting process, or to trigger the extended display mode<sup>4</sup>.

### 9. **[Numeric Key]**

Numeric keys 0~9.

### 10. **Reserved**

---

1 Depends on F11 setting.

2 Refer to F9 on how to enable/disable weight units.

3 Refer to F16 and F17 settings for details.

4 When F68 = OIML or NTEP.

## 11. Reserved

## 12. Weighing Range Indicator

- **W<sub>1</sub> Indicator**<sup>5</sup>: - (When under dual weighing range/interval mode)  
Visible when this instrument is operating at the first weighing range (W<sub>1</sub>).
- **W<sub>2</sub> Indicator**<sup>6</sup>: - (When under dual weighing range/interval mode)  
Visible when this instrument is operating in the second weighing range (W<sub>2</sub>).

## 13. Minus Indicator

Visible when a negative value is displayed.

## 14. Gross/Net Indicators

- **G**: - Visible when gross result is being displayed.
- **Net**: - Visible when net result is being displayed.

## 15. Stable Indicator

Visible when weight value is stable.

## 16. Zero Indicator

Visible when instrument is at zero status.

## 17. M+ Indicator

Visible when memory contains of accumulated data.

## 18. Preset Tare Indicator

Visible when preset-tare value has been entered.

## 19. Weight Unit Indicators

kg = kilogram; g = gram; lb = pound.

## 20. Counting Function Indicators

- **PCS** = Pieces (Piece Count Mode in function).

---

5 Not visible when single range is selected.

6 This indicator will not appear when this instrument is in single range mode.

- kg/PCS, g/PCS and lb/PCS = Weight per piece (when Piece Count Mode in function).

## 21. Numeric & Alphabetical Info Panel


Numeric value and alphabetical Info are shown here.

## 22. Battery Power/Level Indicator

Visible to show: -

- When instrument is powered by built-in rechargeable: - remaining battery of the built-in rechargeable battery.
- When instrument is powered by external power adaptor: - Battery rechargeable recharging status.

## 3.2 Connection Points



### A. DC Jack Input

External power adaptor (DC9 ~ 12V) is plugged in here.

### B. Comport 1<sup>7</sup>

Comport 1 (serial or TTL).

### C. Comport 2<sup>8</sup>

Comport 2 (serial).

### D. Battery Compartment

### E. Under Pan Weighing Access Hole

Access hole for under pan weighing hook, thread size = M4 x 0.7.

<sup>7</sup> Settings of comport #1 is done through F16.

<sup>8</sup> Settings of comport #2 is done through F17.

## **4. Power & Comports**

### **4.1 Power Adaptor**

Always use the power adaptor supplied together with this instrument to avoid un-recoverable damages to this instrument.

#### **Notes: -**

- When an energized power adaptor is plugged in, this instrument will power on automatically.
- Minimum backlight will remain lit on when an energized power adaptor is plugged in even this instrument is switched off.

### **4.2 Built-In Rechargeable Battery**

Before first time use, recharge the built-in batter for at least 8 hours to ensure the best battery performance.

### **4.3 Comports on Instrument**

There are 2 built-in comports on this instrument: -

- Comport 1 can be used for serial or TTL communication depends on the jumper setting of the Serial/TTL selection jumper. Default setting = serial. Contact your dealer in case TTL output is required for Comport 1.
- Comport 2 supports only serial communication.

Both comports support bi-directional communication when set as PC and CMD modes. Refer to **5.5** for setting details.

### **4.4 Comports Pin Assignment**

Refer to below table for pin assignment between this instrument and a computer or serial printer.

## Comport pin assignment on instrument

Comport 1 (male)	Comport 2 (female)
2 = RXD	2 = TXD
3 = TXD	3 = RXD
5 = GND	5 = GND
9 = DC 5V Output	Nil

### Notes: -

- Comport 1 is assigned as DTE and has a male connector.
- Comport 2 is assigned as DCE and has a female connector.

## 5. Initial Setup

There are 2 groups of internal function: -

- Group #1: - F1~F30 are accessible without restriction.
- Group #2: - F60~F99 are restricted functions which request a password or hardware key to access. These functions are for dealer and authorized personnel only. Do not change any settings of these functions to avoid operation errors.

Below paragraphs describe those settings related to F1~F30.

### 5.1 Internal Functions & Settings

Application parameters can be checked and set through internal function. Set all preferred operation parameters according to **5.4**.

### 5.2 How to Enter & Select Internal Function<sup>9 10</sup>

Follow the below procedures for internal function setup: -

1. In weighing function, press and hold **[FUNC/SET]** until instrument displays F1 and is now in internal function mode.

---

<sup>9</sup> Internal function mode can only be accessed when instrument is in weighing mode.

<sup>10</sup> To fulfil the metrology law of certain countries, accessing to internal function by **[Set]** may be disabled. Contact your dealer for more information.



2. Release **[FUNC/SET]**.
3. Press **[FUNC/SET]** and **[MR/UNIT]** to access the preferred internal function number.
4. Quick access to a function number: -
  - Press **[1]** to go to F10.
  - Press **[2]** to go to F20.
  - Press **[3]** to go to F30.
  - Press **[6]** to go to F60 (for dealer and authorized personnel only).
  - Press **[8]** to go to F80 (for dealer and authorized personnel only).
  - Press **[9]** to go to F99 (for dealer and authorized personnel only).
  - Press **[0]** to go to F1.

### 5.3 Key Function under Internal Function Mode

Key	Function in Setup & Calibration
<b>[ON/OFF]</b>	Quit without saving and power off
<b>[FUNC/SET]</b>	Go to next page
<b>[MR/UNIT]</b>	Go to previous page
<b>[TARE]</b>	Set F1 value being shown to zero and to display the net span gain of additional load applied
<b>[ZERO]</b>	Quit without saving
<b>[PRINT/M+]</b>	Enter, save and return
<b>[CE/X10]</b>	Clear
<b>[0] ~ [9]</b>	Numeric keys
<b>[CHECK]</b>	Quick access to label settings

## 5.4 Internal Function Table

Refer to the below tables for internal function number, parameter and setting notes.

Function No.	Description	Parameters/Note Default = **		
F1	Internal Analogue to Digital (ad) Value	<p>Press <b>[TARE]</b> to set offset value to zero when unloaded. Then add load on the platform to observe the span value of load applied.</p> <ul style="list-style-type: none"> <li>When ADC is more than 1 million. W<sub>1</sub> sign will appear. Actual ADC is = 1 million plus the ADC value being displayed.</li> <li>When ADC is more than 2 million. W<sub>2</sub> sign will appear. Actual ADC is = 2 million plus the ADC value being displayed.</li> <li>When ADC is more than 3 million. Both W<sub>1</sub> &amp; W<sub>2</sub> signs will appear. Actual ADC is = 3 million plus the ADC value being displayed.</li> </ul> <p>Press <b>[ZERO]</b> to quit to F1.</p>		
F2	All Segment Check	All display segments and backlight colors will be lit on. Check any segments or backlight colors are missing.		
F3	Capacity, Division & Default Weight Unit	Display basic metrology characteristics (capacity, division and weight unit). Value displayed = Max + 1e		
F4	Date Format & Date	DD/MM/YY	** YY/MM/DD	MM/DD/YY
		Press <b>[PRINT/M+]</b> to check current date value. To change date value, enter date value and then press <b>[PRINT/M+]</b> to confirm.		
F5	Time	HH/MM/SS To change time, press <b>[PRINT/M+]</b> , then enter a new value and press <b>[PRINT/M+]</b> .		
F6	System Initialization (Set F7~F30 to Default)	** NO	YES	

	If <b>YES</b> is selected, press <b>[1]</b> when “ <b>SURE ?</b> ” is displayed. Indicator shows Done when initialization is completed.									
<b>F7</b>	Auto Power Off Time (Minute)	OFF	1	3	<b>** 5</b>		10	20		
	Auto power off function will be disabled when an energized power adaptor is pulled in.									
<b>F8</b>	Backlight Brightness	Brightness (01 ~ 99) <b>** Default = 60</b>			Color Ratio (Green Vs Red) <b>** Default = 50</b>					
	<ul style="list-style-type: none"><li>To change setting, enter value through numeric keys and then press <b>[PRINT/M+]</b>.</li><li>Set brightness (bt) first, then set color ratio. Color ratio is used to generate the preferred yellow color.</li></ul> <p>When instrument is powered by built-in rechargeable battery, backlight will be turned to minimum when battery is low or when weight value remains unchanged for 5 seconds.</p>									
<b>F9</b>	Weight Unit Enable/Disable	kg ( <b>** On/Off</b> )			g (On/ <b>** Off</b> )			lb (On/ <b>** Off</b> )		
<b>F10</b>	Filter Strength	1	2	3	4	<b>** 5</b>	6	7	8	9
	<b>Select: -</b> <ul style="list-style-type: none"><li>1 (strongest filter) for bad working environment where vibration, wind flow... etc. affects stable reading.</li><li>5 for normal environment.</li><li>9 (least filter) for very good working environment where wind and vibration have no effect to stable reading.</li></ul>									
<b>F11</b>	Auxiliary Function	<ul style="list-style-type: none"><li>Cnt (Counting) / On/<b>** Off</b></li><li>AtM (Action Tare Memory) / On/<b>** Off</b></li><li>Ani (Animal) / On/<b>** Off</b></li><li>PCd (Quick Access to Customer / Product Code Setting) / On/<b>** Off</b></li></ul>								
<b>F12</b>	Auto Tare Function	<b>** OFF</b>			ON			Contin		
	<b>Notes: -</b> <ul style="list-style-type: none"><li>Off = Auto Tare Function disable.</li><li>On = Only the first table weight applied will be tare off.</li></ul>									

	Minimum tare load $\geq 2d$ . <ul style="list-style-type: none"><li>Contin = All stable weight applied will be tare off. Minimum tare load <math>\geq 10d</math>.</li></ul>							
F13	Repetitive Tare Function	** OFF		ON				
If F12 is set = <b>Contin</b> , Repetitive Tare setting "Off" will be surpassed.								
F14	Buzzer	Kb (keypad buzzer) (**On/Off)		St (System buzzer) (**On/Off)				
F15	Check Result Buzzer	OFF	** IN	OUT	Hi	Lo		
	<ul style="list-style-type: none"><li>oFF = Check Buzzer disabled.</li><li>IN = Check Buzzer activates when reading is within range.</li><li>ouT = Check Buzzer activates when reading is out of range.</li><li>Hi = Check Buzzer activates when reading more than Hi limit.</li><li>Lo = Check Buzzer activates when reading lower than Lo limit.</li></ul>							
F16	Set Comport 1	<ul style="list-style-type: none"><li>Off</li><li>Auto 1</li><li>Auto 2</li><li>Auto 3</li><li>Manual</li><li>** PC</li><li>Scanner only</li><li>bt</li></ul>						
Refer to F17 for details								
F17	Set Comport 2	Off	Auto 1	Auto 2	Auto 3	Manual	PC	**CMD only
	<ul style="list-style-type: none"><li>Off = No data output.</li><li>Auto 1 = Auto print when weight is stable.</li><li>Auto 2 = The highest stable weight value (of a weighing process) will be automatically printed when all loads are removed (and gross weight returns to zero or minus).</li></ul>							

	<ul style="list-style-type: none"><li>Auto 3 = The last stable weight value (of a weighing process) will be automatically printed when all loads are removed (and gross weight returns to zero or minus).</li><li>Manual = Manual output to printer or computer.</li><li>PC = Continuous output.</li><li>CMD = Command/information request mode.</li><li>Scanner = Serial scanner.</li><li>bt = Bluetooth connection with iOS and Android App.</li></ul> <p><b>Notes: -</b></p> <ul style="list-style-type: none"><li>Refer to operation manual for detailed setup information.</li><li>Restart instrument (by power off then power on again) after F16 and/or F17 setting is changed under normal operation status.</li><li>Disconnect all Bluetooth connection before attempting any Bluetooth setting.</li></ul>			
<b>F18</b>	Machine ID and Group Number	Machine ID	Group Number	
	<ul style="list-style-type: none"><li>Id = Machine ID number (0000~9999). Press <b>[CE/x10]</b> to skip or clear machine ID.</li><li>Gp = Group number (00~99). Press <b>[CE/x10]</b> to skip or clear machine group.</li></ul>			
<b>F19</b>	Manual Customer & Product Code Setting	H Code	M Code	L Code
	<ul style="list-style-type: none"><li>Customer &amp; Product code by keyboard accept both numeric numbers and alphabets. Maximum length = 18 digits.</li><li>Enter code starting from H code, then M code and finally L Code. Press <b>[Print/M+]</b> to confirm and end editing after last digit has been input.</li><li>Customer &amp; Product code does not support print format 1 (Lab 1).</li><li>If a Customer / product code has been entered, this code</li></ul>			

	will be included in print format 2, 3, 4 and 5 (Lab 2 ~ Lab 5) automatically.		
<b>F20</b>	Keyboard Lock	<b>** OFF</b> (Disable)	ON (Enable)
	When keyboard lock is = <b>ON</b> , only ZERO, TARE & ON/OFF key will be accessible during operation status.		
<b>F21</b>	Weight Function Output Print Format	<b>** STD</b>	CUSTOM
<b>F22</b>	Counting Function Output Print Format	<b>** STD</b>	CUSTOM
<b>F23</b>	Reserved.		
<b>F24</b>	Animal Functions Output Print Format	<b>** STD</b>	CUSTOM
<b>F25</b>	Check Modes	<b>** Mode 1</b>	Mode 2
	<ul style="list-style-type: none"> <li>Mode 1 = Standard static/Dynamic Weight Check Mode.</li> <li>Mode 2 = Inflow/Outflow Control Logic Mode.</li> </ul> <b>Note:</b> - if Mode 1 is selected, set also F26.		
<b>F26</b>	Near Zero Weight Value	<b>** 000000</b>	
	Near Zero value is useful for dynamic weight check applications to bypass unnecessary LO alarm during uploading and unloading process. <b>Notes:</b> - <ul style="list-style-type: none"> <li>Value entered valid only when Check function is activated.</li> <li>Near zero weight value can be any value between 20d and Lo limit.</li> <li>Any near zero value which less than 20d will be ignored. Instrument will deem 20d as minimum near zero weight value.</li> <li>The HI LO comparison remains non-activated when weight reading is less than the near zero value entered here.</li> </ul>		
<b>F27</b>	Decimal Point	<b>** Dot (.)</b>	Comma (,)

	Format		
<b>F28</b>	Ask for Operator Number when Power on	Yes	<b>** No</b>
	<ul style="list-style-type: none"> <li>Yes: - Instrument will ask for operator number during countdown process when power on. Enter 4-digit operator number or press <b>[CE/x10]</b> to skip operator number when being asked.</li> <li>No: - Instrument will not ask for operation number.</li> </ul>		
<b>F29</b>	Read Calibration and parameter set counts. <ul style="list-style-type: none"> <li><b>O</b> (Parameter set count): - shows total times that the important parameters (F80~F88) has been altered.</li> <li><b>C</b> (Calibration count): - shows total times of calibration.</li> </ul>		
<b>F30</b>	Allow Letters and Symbols for Customer & Product Code Manual Entry	On	<b>** Off</b>

## 5.5 Setting Comport 1 & Comport 2

2 comports are on this instrument. Default setting for both comports = serial. Contact your dealer in case of TTL output is required for Comport 1. Following the below procedures to setup comports.

- Go to F16 or F17.
  - F16 is used to configure Comport 1.
  - F17 is used to configure Comport 2.
- Press **[FUNC/SET]** or **[MR/UNIT]** to shift among parameters Off, PC, Scanner (Comport 1 only), CMD (Comport 2 only), Auto1, Auto 2, Auto 3 and Manual.

### Notes: -

- Off = Comport disable. Select this when a particular comport is not used.
- PC & CMD is data string related modes.
- Auto 1, Auto 2, Auto 3 and Manual are print related modes.
- When both ports are set to data string related modes, **[PRINT/M+]**

key is used as M+ (memory accumulation) and can only be activated when value is stable and  $\geq 20d$ .

- If both comports are set to print related mode (e.g. comport 1 is set to Auto 1, comport 2 is set to Auto 2) and at the same time Auto memory accumulation is selected by both modes, then Auto memory accumulation serves only comport 1.
3. Select the preferred output type parameters then press **[PRINT/M+]** to save.
  4. At this point: -
    - If PC is selected, refer to **5.5.1** for setting details.
    - If CMD is selected, refer to **5.5.2** for setting details.
    - If Manual is selected, refer to **5.5.3** for setting details.
    - If Auto 1~3 is selected, refer to **5.5.4** for setting details.
    - If Scanner is selected, refer to **5.5.5** for setting details.

#### **5.5.1 When comport is set as PC**

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. Instrument displays output protocol type. 9 parameters (Prot 1~9) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
5. Instrument displays time interval (in second) between each output. 10 parameters (0, 0.5, 1, 1.5, 10, 30, 60, 90, 120, and 300) are available. 0 = continuous output. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
6. At this point, PC setup is completed.



### 5.5.2 When comport is set as CMD

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. At this point, CMD setup is completed.

### 5.5.3 When comport is set as Manual

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. Instrument displays Auto Accumulation. 2 parameters (on, off) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
  - On = when pressing **[PRINT/M+]** during normal operation, the instrument does print and M+ at the same time.
  - Off = when pressing **[PRINT/M+]** during normal operation, the instrument does print only.
5. Instrument displays Check Control. 2 parameters (on, off) are available. By default, print data will only be transmitted under all auto print modes. Press **[PRINT/M+]** to save.
  - On = (When check function is in effect) Only OK value (value which is within Lo and Hi Limits) will be transmitted.
  - Off = (When check function is in effect) Check requirement is disable.
6. Instrument displays Stability control. 2 parameters (Yes, no) are

available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.

- Yes = **[PRINT/M+]** (during normal operation) will only function when the weight is stable.
- No = **[PRINT/M+]** (during normal operation) will always function disregarding the stable condition of the weight when **[PRINT/M+]** is pressed.
- 7. Instrument displays minimum output weight. 21 parameters (0d~20d) are available. Instrument will not generate any output if the actual weight is less than the minimum output weight selected here. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
- 8. Instrument displays print format. 5 parameters (Lab 1, Lab 2, Lab 3, LP-50 and TSC). Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
  - Lab 1 = Output in Landscape direction. If Lab 1 is selected, refer to **5.5.3.1** for other settings.
  - Lab 2 = Output in Portrait Direction. If Lab 2 is selected, refer to **5.5.3.2** for other settings.
  - Lab 3 = Database output mode.
  - LP-50 = Output to LP-50 label printer. Refer to **5.5.3.3** for other settings.
  - TSC = Output to TSC label printer. Refer to **5.5.3.3** for other settings.

#### **5.5.3.1 Other settings if Lab 1 is selected**

- a. Instrument displays Line number. Line number is the number of lines in between which the report heading is repeated. Line number should be from 00~99. 00 means no header output. Input the desired line number then press **[PRINT/M+]** to save.
- b. At this point, Lab 1 setup is completed.

#### **5.5.3.2 Other settings if Lab 2 is selected**

- a. Instrument displays number of copy to generate each time. 8 parameters (1~8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.

- b. At this point, Lab 2 setup is completed.

### 5.5.3.3 Other settings if LP-50/TSC is selected

- a. Instrument displays number of copy to generate each time. 8 parameters (1~8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
- b. Instrument displays label file number (FL1 01 ~ FL1 99) to print in label format group 1. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred label file number appears then press **[PRINT/M+]** to save.
- c. Instrument displays label file number (FL2 01 ~ FL2 99) to print in label format group 2. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred label file number appears then press **[PRINT/M+]** to save.
- d. At this point, LP-50/TSC setup is completed.

### 5.5.4 When comport is set as Auto (Auto 1~3)

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. Instrument displays Auto Accumulation. 2 parameters (on, off) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
  - On = Auto memory accumulation enable. Instrument will accumulate the printed value to memory.
  - Off = Auto memory accumulation disable.
5. Instrument displays Check Control. 2 parameters (on, off) are available. By default, print data will only be transmitted under all auto print modes. Press **[PRINT/M+]** to save.

- On = (When check function is in effect) Only OK value (value which is within Lo and Hi Limits) will be transmitted.
- Off = (When check function is in effect) Check requirement is disable.
- 6. Instrument displays Stability control. 2 parameters (Yes, no) are available. **By default, only stable value will be transmitted under all auto print modes.** Press **[PRINT/M+]** to save.
- 7. Instrument displays minimum output weight. 21 parameters (0d~20d) are available. **By default, only stable value which is  $\geq 20d$  under all auto print modes.** Press **[PRINT/M+]** to save.
- 8. Instrument displays print format. 4 parameters (Lab 1, Lab 2, LP-50 and TSC). Instrument will not generate any output if the actual weight is less than the parameter weight selected. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
  - Lab 1 = Output in Landscape direction. If Lab 1 is selected, refer to **5.5.3.1** for other settings.
  - Lab 2 = Output in Portrait Direction. If Lab 2 is selected, refer to **5.5.3.2** for other settings.
  - LP-50/TSC = Output to LP-50/TSC label printer. If LP-50/TSC is selected, refer to **5.5.3.3** for other settings.
- 9. At this point, Auto (Auto 1~3) setup is completed.

### 5.5.5 When Comport 1 is set as Scanner

1. Instrument displays baud rate. 9 parameters (1200~256000) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
2. Instrument displays Parity. 3 parameters (None, odd, even) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
3. Instrument displays Data length. 2 parameters (7, 8) are available. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. At this point, scanner setup is completed.

## 6. Basic Operations

### 6.1 Power On, Inputting Operator Number & Power Off

To power on instrument, press **[ON/OFF]** for 0.5 second.

After powered on, instrument will display software number, software revision, all display segments, calibration count value and parameter set count value.

At this point, depends on internal function number F28 setting, instrument may ask for operator number input. If this is the case: -

- Input 4-digit operator number, or
- Press **[CE/x10]** then **[Print/M+]** to skip operator number when oP appears.

After above, the instrument will go to the last working mode before powered off and is ready for operation.

To power off instrument, simply press **[ON/OFF]**.

### 6.2 Warm Up Time & Set Weight to Zero When Unloaded

It is important to allow the instrument enough warm up time. This is especially important when this instrument is running at high resolution (e.g. 6000d or higher) application. Refer to **1.3** for details.

If zero result is not obtained when unloaded, press **[ZERO]** to set weight displayed to zero.

### 6.3 Keyboard Lock

When keyboard lock is enabled, only **[ON/OFF]**, **[ZERO]** and **[TARE]** can function. Refer to F20 on **5.4** for keyboard lock settings.

### 6.4 Tare Modes

Tare function is used to cancel the weight of a box or a container in order to get the net weight result. Various tare modes are available. Refer to below paragraphs for details.

#### 6.4.1 Manual Tare<sup>11</sup>

1. Remove all loads from platform.
2. Make sure that the **Zero Indicator** is on. If not, press **[ZERO]**.
3. Place container on platform.
4. Press **[TARE]**.
5. Weight displayed will become zero and **Net Indicator** appears to indicate tare is in effect and weight being displayed is net weight.
6. To cancel tare effect, remove all loads from platform and press **[TARE]**.
7. **Net Indicator** disappears. **Gross Indicator** appears to indicate tare effect has been removed and weight displayed is gross weight.

#### 6.4.2 Auto Tare (F12)<sup>12</sup>

3 parameters are available: - Off, Auto and Contin

- Off: - Auto tare disable.
- Auto: - instrument will assume the first stable weight ( $\geq 20d$  or  $20d_1$ ) applied is a container and will then tare off the weight of it automatically. When container is removed and gross weight result is zero, tare effect will be cancelled automatically.
- Contin (continuous auto tare): - all stable weight ( $\geq 20d$  or  $20d_1$ ) applied will be tare off automatically. When all loads are removed and gross weight result is zero, tare effect will be cancelled automatically.

#### 6.4.3 Repetitive Tare (F13)<sup>13</sup>

When F13 is set to OFF, this instrument does not permit multiple tare operation. Tare effect can only be cancelled when container is removed and gross weight is zero.

When F13 is set to ON, this instrument will permit multiple tare operation provided that **both** of the below requirements are met: -

- 
- 11 Maximum tare (subtractive) = -Max for single range mode and dual weighing range/interval mode.
  - 12 Set F12 = ON to enable Auto Tare Function
  - 13 Set F13 = ON to enable Repeated Tare Function.

- a. The tare operation does not permit a reduction of the value of the tare, and
- b. The tare effect can only be cancelled when there is no load on the platform.

#### 6.4.4 Preset Tare (F63)<sup>14 15</sup>

Preset tare allows a pre-determined tare weight value can be entered via numeric keys.

During weighing mode and when weight is zero, press **[0]**, then enter the pre-determined tare weight value through numeric keys then press **[PRINT/M+]** to enter.

After the pre-determined tare value has been entered: -

- Instrument displays the preset tare value entered.
- Net indicator appears to indicate the value being displays is net weight.
- Preset Tare Indicator appears to indicate Preset tare mode is in effect.

To cancel preset tare effect: -

- Remove all loads from platform then press **[TARE]**, or
- Enter a zero preset tare value then press **[PRINT/M+]**.

**Notes: -**

- The pre-determined tare weight entered will be rounded to the nearest division of the instrument. This does not affect the accuracy of the subsequent weighing and operation.
- Manual tare is possible when Repetitive Tare (F13) is set to On.

---

14 Set F63 = ON to enable Preset Tare Function. Some countries may not consider preset tare function as a legal for trade function. Contact your dealer for more information.

15 Set also F12 to Off

## 6.5 Select the Preferred Function Mode<sup>16</sup>

This instrument supports the below function modes. Abbreviation of each function mode is bracketed.

- Weighing (Weigh).
- Piece Count (Count).
- Action-Tare-Memory (AtM).
- Animal Weighing (Ani).
- Quick access to Customer & Product Code Setting (PCd).

Press **[FUNC/SET]** until the abbreviation of the desired function mode appears then press **[PRINT/M+]** to enter.

The working mode employed before powering off will be employed again automatically when re-powered on.

## 6.6 Weight Units<sup>17</sup>

This instrument supports kg, g and lb. To shift among various weight units, repeat press and hold **[MR/UNIT]** to shift among various weight units.

### 6.6.1 Weight unit gram (g)

Disregarding to the setting of **F9**, weight unit gram (g) is available only when 3 or 4 decimal places (0.000 or 0.0000) is selected in F81. Contact your dealer for more information about this.

### 6.6.2 Select the preferred weight unit<sup>18</sup>

The desired weight units should enable in F9. Repeat press and hold **[MR/UNIT]** until the preferred weight unit appears.

## 6.7 Memory Accumulation<sup>19</sup>

There are 2 types of Memory Accumulation: -

- a. Automatic Accumulation mode, and
- b. Manual Accumulation mode.

---

<sup>16</sup> Depends on F11 setting.

<sup>17</sup> Depends on F9 setting.

<sup>18</sup> Changing weight unit during operation will clear all accumulate weight data from memory.

<sup>19</sup> Only weight result will be accumulated.



Maximum accumulation limit is = 8 digits (e.g. 99999999) plus decimal (if any). **Err 28** appears when maximum accumulation limit is exceeded.

### 6.7.1 Automatic Accumulation<sup>20</sup>

Automatic accumulation is activated when Auto Accumulation is set to **On** in Auto 1, Auto 2, Auto 3 or Manual mode is selected in F16 and/or F17.

Under the automatic accumulation mode, corresponding results will be accumulated automatically.

### 6.7.2 Manual Accumulation<sup>21</sup>

Manual Accumulation is activated when scanner, PC or CMD mode is selected for **both** F16 and/or F17.

Under the Manual Accumulation mode, press **[PRINT/M+]** to accumulate the current value to memory.

### 6.7.3 When data is accumulated to memory<sup>22 23 24</sup>

1. When a result is accumulated to memory, this instrument displays “**n\_\_\_\_\_x**”. **M+ Indicator** appears to indicate that memory contains stored data. “x” means the total number of transactions accumulated to memory.
2. This instrument returns to normal display status after 2 seconds.

### 6.7.4 Memory recall and clearance

Accumulation data will be stored in memory and will not be erased by normal power off (by pressing the **[ON/OFF]** key) process.

Instrument will automatically erase accumulation data stored when: -

- Changing weight unit, or
- Change to another working mode, or

---

<sup>20</sup> Refer to 5.5.4 for setting details.

<sup>21</sup> Refer to 5.5.3 for setting details.

<sup>22</sup> Memory Accumulation Function accumulated weight results only.

<sup>23</sup> When F16 and F17 is set to mode Auto1~3, unstable result or result which is less than 20d (20d<sub>1</sub> for dual weighing range/interval mode) will not be accumulated to memory.

<sup>24</sup> All data stored will be erased when weight unit or working mode is changed.

- A different operator number is entered during power on process.

Follow below procedures to recall and clear accumulation data manually.

1. Press **[MR/UNIT]** to recall total accumulated weight.
2. Instrument flashes between “**A\_\_\_Y**” (**Y** means the number of transactions accumulated) and total accumulated result.
3. At this point: -
  - Press **[ZERO]** to quit, or
  - Press **[CE/x10]** to clear memory. After **[CE/x10]** is pressed, instrument display Clear and M+ Indicator disappears to indicate no data is stored in memory.
4. Press **[MR/UNIT]** to recall total accumulated weight.
5. Instrument flashes between “**A\_\_\_Y**” (**Y** means the number of transactions accumulated) and total accumulated result.
6. At this point: -
  - Press **[ZERO]** to quit, or
  - Press **[CE/x10]** to clear memory. After **[CE/x10]** is pressed, instrument displays Clear and **M+ Indicator** disappears to indicate no data is stored in memory.

## 6.8 Extended Display Mode<sup>25</sup>

When F68 is set to OIML or NTEP, by pressing **[CE/x10]** the weighing resolution will be temporary (for 5 seconds) changed to 10 times finer. Display keeps flashing when instrument is displaying the extended result.

## 6.9 Tri-color Backlight

This instrument is equipped with a tri-color backlight. The tri-colors are yellow, green and red.

- In normal operation, green is used for display illumination.
- When check function is activated, yellow = Lo; green = OK; red = Hi.

### 6.9.1 When powered by built-in rechargeable battery

Backlight will turn to minimum when weight remains stable / unchanged for 5 seconds. In order to save power, stable for backlight means  $\pm 5$  division

---

<sup>25</sup> When F68 = OIML or NTEP.

variation.

### 6.9.2 When powered by external power adaptor

Backlight will remain on always.

### 6.10 Customer & Product Code

This instrument supports Customer and Product entry. Both Customer & Product Code accept numeric numbers, letters, symbols and any combination of these. Maximum code length = 18 digits. Refer to below table for code entry assignment.

Key	Assignment				
0	0	Space			
1	1	-	/	_	
2	2	A	B	C	
3	3	D	E	F	
4	4	G	H	I	
5	5	J	K	L	
6	6	M	N	O	
7	7	P	Q	R	S
8	8	T	U	V	
9	9	W	X	Y	Z
Check	Shift				

#### Notes: -

- When inputting upper case letters, the gross sign will appear.
- When inputting lower case letters, the decimal (or the psc) sign right to cursor will appear.

### 6.10.1 Enter a customer & product code manually<sup>26</sup>

- a. Go to customer/product code setting manual by either one of the below methods.
  - If Quick Manual Code Setting function (CPd) in F11 is set to on: -
    - Press **[FUNC/SET]** until C.P. Code appears then press **[PRINT/M+]**.
    - Press **[FUNC/SET]** or **[MR/UNIT]** until the desired mode appears (select C Code to enter customer code or select P Code to enter product code), then press **[PRINT/M+]** to confirm.
  - If Quick Manual Code Setting function (PCd) in F11 is set to Off: -
    - Go to F19, then press **[PRINT/M+]**.
    - Press **[FUNC/SET]** or **[MR/UNIT]** until the desired mode appears (C Code for customer code, P Code for product code), then press **[PRINT/M+]** to confirm.
- b. Instrument displays H code followed by 6 digits. Enter the first 6 digits of the t code here, then press **[PRINT/M+]** to confirm.
- c. Instrument displays M code followed by 6 digits. Enter the 7th ~ 12th digits of the code here, then press **[PRINT/M+]** to confirm.
- d. Instrument displays L code followed by 6 digits. Enter the last 6 digits of the code here, then press **[PRINT/M+]** to confirm.
- e. Instrument displays **Plu=?**. At this point: -
  - Press the preferred PLU position (numeric key 0 ~ 9), then press **[PRINT/M+]** to save to that PLU position, or
  - Press **[PRINT/M+]** to utilize the code immediately but without saving to PLU, or
  - Press **[ZERO]** to quit.
- f. To go to other internal function, press **[FUNC/SET]** or **[MR/UNIT]** or press **[ZERO]** to quite to operation status.

---

<sup>26</sup> If a product code is less than 18 digits, press **[Print/M+]** to skip all blank digits displayed until instrument return to F19.

### 6.10.2 Enter a customer & product code by scanner<sup>27</sup>

Default scanner input target is product code. To change scanner input target, scan either one of the below barcodes, then scan a customer or product barcode.



### 6.10.3 Clear a customer & product code entered

To clear a customer/product code entered, press **[CE/x10]** on above procedures **b**, **c** and **d** on paragraph **6.10.1**.

### 6.10.4 Print a customer & product code entered<sup>28</sup>

Once a customer/product code is entered, it will be printed automatically through the assigned comport. No other setting is required.

## 6.11 Quick Access PLU

10 each quick access PLUs are available for each of the below: -

- a. Weight limits for each of the weight unit (g, kg and lb).
- b. Quantity limit for Piece Count Mode.
- c. Preset Tare value for each of the weight unit (g, kg and lb).
- d. Customer Code.
- e. Product Code.

---

<sup>27</sup> Maximum = 18 digits.

<sup>28</sup> Print format LAB 1 does not support customer/product code.

### 6.11.1 Weight limits PLUs

#### 6.11.1.1 Save weight limits to PLU

Follow the below steps to save Lo and Hi weight limits to PLU.

1. Select desired operation mode and weight unit, then press **[CHECK]**.
2. Instrument displays Low followed by a 6-digital value. Enter the Lo weight limit through numeric keys then press **[PRINT/M+]**.
3. Instrument displays HIGH followed by a 6-digital value. Enter the Hi weight limit through numeric keys then press and hold **[CHECK]** for 2 seconds.
4. Instrument displays **Save =?**. At this point: -
  - Press the preferred PLU position (numeric key 0 ~ 9), then press **[PRINT/M+]** to save to that PLU position and utilize these limits immediately, or
  - Press **[PRINT/M+]** to utilize these limits immediately but without saving to PLU, or
  - Press **[ZERO]** to quit.

#### 6.11.1.2 Recall weight limits from PLU

Follow the below steps to recall Lo and Hi limits.

1. Select desired operation mode and weight unit, then press and hold **[CHECK]** for 2 seconds.
2. Instrument displays **CHK =?**. Press PLU position (numeric key 0 ~ 9) then press **[PRINT/M+]** to recall the Lo & Hi limits stored in that position.
3. Instrument displays Lo and Hi limits and these values are now effective.

#### 6.11.1.3 Clear weight limits from PLU

Refer to **6.11.1.1**. Enter zero value for both Lo and Hi limit in step number 2 and 3. Then press the preferred PLU position to clear.

### 6.11.2 Quantity limits PLUs

#### 6.11.2.1 Save quantity limits to PLU

Follow the below steps to save Lo and Hi limits for quantity.

1. Go to piece count mode under desired weight unit, then press

### **[CHECK].**

2. Instrument displays Low followed by a 6-digital value. Enter the Lo quantity limit through numeric keys then press **[PRINT/M+]**.
3. Instrument displays HIGH followed by a 6-digital value. Enter the Hi quantity limit through numeric keys then press and hold **[CHECK]** for 2 seconds.
4. Instrument displays **Save =?**. At this point: -
  - Press the preferred PLU position (numeric key 0 ~ 9), then press **[PRINT/M+]** to save to that PLU position and utilize these limits immediately, or
  - Press **[PRINT/M+]** to utilize these limits immediately but without saving to PLU, or
  - Press **[ZERO]** to quit.

#### **6.11.2.2 Recall quantity limits from PLU**

Follow the below steps to recall Lo and Hi limits.

1. Go to piece count mode under desired weight unit, then press and hold **[CHECK]** for 2 seconds.
2. Instrument displays **CHK =?**. Press PLU position (numeric key 0 ~ 9) then press **[PRINT/M+]** to recall the Lo & Hi limits stored in that position.
3. Instrument displays Lo and Hi limits and these values are now effective.

#### **6.11.2.3 Clear quantity limits from PLU**

Refer to **6.11.2.1**. Enter zero value for both Lo and Hi limits in step number 2 and 3. Then press the preferred PLU position to clear.

### **6.11.3 Preset Tare PLUs**

#### **6.11.3.1 Save preset tare to PLU**

Follow the below steps to save preset tare value.

1. Select desired operation mode and weight unit.
2. Enter preset tare value through numeric keys then press and hold **[TARE]** for 2 seconds.
3. Instrument displays **Save =?**. At this point: -
  - Press the preferred PLU position (numeric key 0 ~ 9), then press

- **[PRINT/M+]** to save to that PLU position, or
- Press **[PRINT/M+]** to utilize this preset tare immediately but without saving to PLU, or
- Press **[ZERO]** to quit.

### 6.11.3.2 Recall preset tare from PLU

Follow the below steps to recall preset tare value.

1. Select desired operation mode and weight unit, then press and hold **[TARE]** for 2 seconds.
2. Instrument displays **PT =?**. Press PLU position (numeric key 0 ~ 9) then press **[PRINT/M+]** to recall the preset tare value stored in that position.
3. Preset tare value stored is now effective.

### 6.11.3.3 Clear preset tare from PLU

Refer to **6.11.3.1**. Enter zero value for both Lo and Hi limits in step number 2. Then press the preferred PLU position to clear.

## 6.11.4 Customer & product code PLUs

### 6.11.4.1 Save a customer/product code to PLU

Refer to **6.10.1** for procedures to save a customer/product code to PLU.

### 6.11.4.2 Recall a customer/product code from PLU

Follow the below steps to recall a customer/product code from PLU.

1. Select desired operation mode and weight unit, then press and hold the PLU position (numeric key 0 ~ 9) then press **[PRINT/M+]** to recall the product or customer code stored in that position.
2. Press **[FUNC]** or **[UNIT]** until the desired mode appears (select C Code for customer code or select P Code for product code), then press **[PRINT/M+]** to confirm.
3. Code stored is now effective.




### 6.11.4.3 Clear customer / product code from PLU

Refer to **6.10.1** and enter blank value for all H, M and L codes in step numbers b, c, and d. Then press the preferred PLU position to clear.



## 6.12 Enter a Key Command by Scanner

Simply scan one of the below barcodes to simulate pressing the **[ZERO]**, **[TARE]** and **[PRINT/M+]** on keyboard.



## 7. Weighing Mode

1. Refer to **6.6** on how to select the desired weight unit.
2. If zero weight cannot be obtained when unloaded, press **[ZERO]**. After **[ZERO]** is pressed, the **Zero Indicator** will appear<sup>29</sup>.
3. Always place an object onto platform gently. Excessive force/shock applied to platform may cause un-recoverable damage to the weight sensor inside platform.
4. The weight of the object is displayed automatically.
5. It is a good practice to remove all loads from platform after weighing. It will prolong the life of the weight sensor.

---

<sup>29</sup> Maximum weight value can be zero depends on F65 setting. Contact your dealer for detail.

## 8. Piece Count Mode

1. Refer to **6.5** on how to select the desired weight unit.
2. If a container is used, place it onto the platform and press **[TARE]**.
3. Apply samples with the known quantity (sample size) on platform.
4. Press and hold **[FUNC/SET]** then input the sample quantity through numeric keys then press **[PRINT/M+]**.
5. This instrument will calculate, store the average piece weight and confirm with 2 beeps. The quantity is then displayed.
6. Add to or remove from the platform, the corresponding quantity will be displayed automatically.
7. To count different articles, press and hold **[FUNC/SET]** and repeat procedures listed above.

### 8.1 Auto Unit Piece Weight Enhancement Function

In order to obtain the best counting result and minimize sampling error, this instrument is equipped with Auto Unit Piece Weight Enhancement Function.

This function will automatically be employed when Unit piece weight is determined by actual sample method.

Auto Unit Piece Weight Enhancement Function is built-in the Piece Count mode. This function starts automatically when all of the below are met: -

- a. Unit piece weight is determined by actual sampling method.
- b. The quantity **added** to platter is more than 5 pieces but less than current quantity on scale.
- c. The total quantity on scale is less than 10000 pieces.

When all the above requirements are met, a new unit piece weight will be calculated and stored in memory and confirmed by a "beep" sound.

### 8.2 Shift among Quantity, Average Piece Weight and Weight Info

1. Repeat press and hold **[MR/UNIT]** to shift among quantity, average piece weight and weight info.
2. Quantity display format = numeric numbers & PCS (e.g.1000 PCS).  
Average piece weight display format = numeric numbers & weight unit &/PCS (e.g. 499.960g/PCS).

3. Weight display format (when Piece Count Function is in effect) = numeric numbers & weight unit & PCS (e.g. 500 kg PCS).

### 8.3 Recall the Average Piece Weight before Powered Off

Press and hold **[FUNC/SET]** for 2 seconds, then press **[MR/UNIT]** to recall the last average piece weight before instrument was powered off.

## 9. Action-Tare-Memory (ATM)

### 9.1 Description of ATM Mode

It means action, then tare, then memory: -

- Action = load or remove weight from weighing platform.
- Tare = the above weight added on or removed from will be tare off automatically.
- Memory = the above weight will be added to or deducted (in case of removal) from accumulated memory.

### 9.2 Basic ATM Settings

1. Refer to **6.6** on how to select the desired weight unit.
2. Enter ATM mode.
3. Press and hold **[FUNC/SET]** to trigger Auto Accumulation target. Then to select Auto Accumulation target by pressing **[FUNC/SET]** or **[MR/UNIT]**, then press **[PRINT/M+]**.
  - Gross = Gross weight will be accumulated.
  - Net = Net weight will be accumulated.
4. Instrument prompts for delay time (second). Delay time is the time interval (00 ~ 99 seconds): -
  - Between a valid stable weight result is obtained and before it is tare off and accumulated to memory.
  - Display time of total accumulated weight result (after all loadings are removed) and before it is clear from print out memory.
5. Enter delay time through numeric keys then press **[PRINT/M+]** to enter.
6. At this point, ATM mode is ready for use.

### 9.3 Start Using ATM<sup>30</sup>

1. Apply container on platform. Instrument will tare off the weight of the container.
2. Apply or removed load on or from platform. The weight result is displayed for the time interval set forth by above point 2. Then instrument will accumulate the weight result in memory then clear it from the display. **Notes:** -
  - Both positive and negative weight will be accumulated to memory.
  - Positive weight will be added to the accumulated memory.
  - Negative weight will be deducted from the accumulated memory.
3. Apply/remove another load on/from platform. The weight result is displayed for the time interval set forth by above point 2. Then instrument will accumulate the weight result in memory and clear it from the display.
4. Repeat point 3 until all weighing sequence is completed.
5. To recall current total accumulated weight, press **[MR/UNIT]**.
6. At this point: -
  - Press **[ZERO]** to quit, or
  - Press **[PRINT/M+]** to print the current accumulated weight.
7. When all loads are removed from weighing platform. Total accumulated weight value will then be erased automatically.

#### 9.3.1 Weight Check Control for ATM

When weight Check Control is in effect, only weights within Lo and Hi limits will be tare off and accumulated.

##### 9.3.1.1 Comport settings of weight Check Control for ATM when an external peripheral is connected to instrument.

- a. Set F26 (near zero value) according to application requirement or 00000 to disable near zero value control. Refer to **12.1** for more information about F26 near zero function.
- b. Refer to **5.5.4** on comport settings and set Check Control = On.
- c. In ATM mode, refer to **11.1** to enter Lo and Hi limits.

---

<sup>30</sup> Weight changed less than 10d will not be processed.

### 9.3.1.2 Settings of weight Check Control for ATM when no external peripheral is connected to instrument.

- a. Set both Comport 1 and Comport 2 to Off.
- b. Set F26 (near zero value) according to application requirement or 00000 to disable near zero value control. Refer to **12.1** for more information about F26 near zero function.
- c. At this point, ATM comport setup is completed for this mode.

## 10. Animal Weighing Mode<sup>31</sup>

### 10.1 Description of Animal Weighing Mode

Animal weighing mode is used to weigh live animals.

### 10.2 Basic Animal Weighing Settings

1. Refer to **6.6** on how to select the desired weight unit.
2. Enter Animal Weighing mode.
3. Press and hold **[FUNC/SET]** to trigger filter setting. Then select the preferred filter speed by pressing **[FUNC/SET]** or **[MR/UNIT]**. 5 filter speeds are available from (FLt 1 ~ FLt 5).
  - FLt 1 = Fast (Weight value is based on least number sampling data, accuracy will be lowest).
  - FLt 3 = Normal (Displayed average weight is calculated based on the last 8 internal readings).
  - FLt 5 = Slow (Weight value is based on most number of sampling data, accuracy will be highest).
4. Press **[PRINT/M+]** to save and set weight release variation value.
5. Press **[FUNC/SET]** or **[MR/UNIT]** key to select the preferred weight release variation value. 10 parameters are available from Off to 20: -
  - rE oFF = auto release disabled.
  - .....
  - rE 2 = auto release when weight varies  $\geq 2\%$  of rate capacity or W1 for dual weighing range/interval mode).
  - .....

---

31 Animal Weighing function will not operate when weight is less than 20d (or 20d<sub>1</sub> for dual weighing range/interval).

- rE 20 = auto release when weight varies  $\geq 20\%$  of rate capacity (or W1 for dual weighing range/interval mode).
- 6. Press **[PRINT/M+]** to save.
- 7. Instrument is now ready for animal weighing application.

### 10.3 Start Using Animal Weighing

1. Get an animal on platform.
2. This instrument will calculate the weight of an animal. The result obtained will be flashing.
3. In case more animals have to be weight in the same transaction, then get other animals on platform. An updated weight will be calculated and displayed<sup>32</sup> as above step 2.
4. To update the weight reading manually, press **[CE/x10]**.

## 11. Check Function<sup>33 34 35 36</sup>

This function is used to compare current weight result with the preset Lo and Hi limits. The comparison results (LO, OK, HI) will then be displayed in different backlight colors with or without buzzer<sup>37</sup>. Targets of Check mode are: -

- Weighing mode = weight value.
- Piece Count mode = piece value.
- Auto Tare Memory mode = weight value.

### 11.1 Set Lo & Hi Limits

Follow the below steps to set Lo and Hi limits.

1. During desired operation mode, press **[CHECK]**.
2. Instrument displays Low followed by a 6-digital value. Enter the Lo

---

32 Provide that extra weight added/removed fulfills the weight release variation value listed on point 5 of **10.2**.

33 Check mode will not operate when weight is less than 20d (or 20d<sub>1</sub> for dual weighing range/interval mode).

34 Set also F15 for desired Check buzzer output.

35 When F25 = Mode 1, set also F26 (Near Zero weight value).

36 Set F26 to zero.

37 Set F15 for preferred buzzer output configuration.

- limit through numeric keys then press **[PRINT/M+]** to save.
3. Instrument displays HIGH followed by a 6-digital value. Enter the Hi limit through numeric keys then press **[PRINT/M+]** to save.
  4. Check Mode is now enabled. The check result is shown by one of the backlight colors<sup>38</sup>. Check results are also sent to Control Output Port.

## 11.2 Hints for entering Lo and Hi Limits

1. For normal comparison, set both Lo and Hi limits.
2. To check only if result is lower than or equal to Lo ( $\text{result} \leq \text{LO}$ ), set Hi limit = 0.
3. To check only if result is higher than or equal to Hi ( $\text{result} \geq \text{HI}$ ), set Lo limit = 0.
4. To check if result is equal to a specified value, set both Hi limit and Lo limit = the specified value.

## 11.3 Cancel Check Function

To cancel check function, press **[CE/x10]** on point **2** and **3** of **11.1**.

## 12. Dynamic Check Mode<sup>39</sup>

Check function mode also supports dynamic applications which within the below specifications listed.

- a. Maximum belt speed: - 30 meter per minute.
- b. Maximum accuracy: - 3000d.
- c. Maximum speed: - 30 pack per minutes.

This instrument supports near zero function. Enter near zero value in F26. It is recommended that this value is = 70% of the target weight value. Refer to **12.1** for details.

---

<sup>38</sup> Yellow = Lo; Green = OK; Red = Hi.


<sup>39</sup> Set preferred near zero weight value in F26. By default, system will ignore any near zero which is less than 20d. If it is the case, system will deem 20d as near zero weight value.

## 12.1 Near Zero Function Description

Near zero value is very useful for dynamic and conveyor weighing applications. It is used to avoid false LO signal output when load is approaching and leaving the weighing platform.

HI/OK/LO comparison will only start when weight reading exceeds the preset near zero value. Refer to below diagram for more illustration.

## 12.2 Near Zero Value Illustration Diagram



After Hi, Lo limits and near zero value have been entered, this instrument is ready for dynamic checking.

## 13. Communication & Outputs<sup>40</sup>

### 13.1 Print Output & Formats

If Manual is selected in F16 and/or F17, refer to **5.5.3.1** (Lab 1), **5.5.3.2** (Lab 2) and **5.5.3.3** (LP-50/TSC) for details.

### 13.2 Auto 1~3 Output & Formats

If Auto 1~3 is selected in F16 and/or F17, refer to **5.5.4** for details.

---

<sup>40</sup> Instrument should be re-started (by power off then power on again) after F16 and/or F17 setting is changed under normal operation status.



### 13.3 PC Output & Protocol

If PC is selected in F16 and/or F17, refer to **Appendix B** for protocol details.

### 13.4 Sending Keyboard Commands from Computer

When Comport 2 is assigned as CMD, keyboard commands can be sent by an external device to this instrument. Refer to **Appendix A** for details.

### 13.5 Requesting Operation Results & System Parameters by Computer


To obtain operation results and system parameters by computer, set F17 to CMD.

- Refer to **Appendix C** for details to obtain operation results.
- Refer to **Appendix D** for details to obtain system parameters.

### 13.6 PC Software (Rathohan 19 End User Program)

A PC software is built to work with this instrument. This software enables users to preform: -

- Real Time Operation Status Monitoring
- Operation Parameters Setting
- Real Time Process Monitoring
- Individual and Totalized Record Storage
- Database File Output



Click / visit the below link to down this software and operation manual of it.

[www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)

Before using this software, read carefully the Software License Agreement of using this software. Do not use it if you do not agree with all terms and conditions listed on the License Agreement. It is assumed that by using this software, user agrees with all content of the License Agreement.

### 13.7 iOS and Android Apps

iOS and Android Apps are available to work with this instrument. They can be download at: -

- iOS App is named **i19**. Visit App Store and search for i19 or Fidelity Measurement to download.
- Android App is named **a19**. Visit Google Play and search for a19.

These 2 Apps support both Bluetooth and WIFI connection.

### 13.7.1 Using App via WIFI Connection

If WIFI module is used for App connection, the WIFI module should be connected to Comport 2. Go to F17 and select CMD, then select baud rate, parity and data length.

Baud rate, parity and data length settings should be the same as the WIFI module settings. Baud rate 115200 or higher is recommended.

### 13.7.2 Using App via Bluetooth Connection

This instrument comes (if ordered) with a Bluetooth module/kit for either iOS or Android. This module/kit is TTL based.

- Connect Bluetooth module/kit with instrument.
- If iOS device is used, go to F16, select bt, then iOS. Refer to **13.7.3** for more information.
- If Android device is used, go to F16, select bt, then Androi. Refer to **13.7.4** for other information.

Before setting, make use that all Bluetooth connection is disconnected, and the App is not activated.

### 13.7.3 Bluetooth Default Settings when iOS is selected

1. Instrument displays name of the Bluetooth module used. If necessary, change the name through keyboard on instrument. If English letters and symbols are needed, set F30 to **Yes** first.
2. Press **[Print/M+]** to save and go to next parameter.
3. Instrument displays Pin of the Bluetooth module used. If necessary, change the pin name through keyboard on instrument. Pin number of Bluetooth for iOS must be 6-digit. If English letters and symbols are needed, set F30 to **Yes** first.

4. Press **[Print/M+]** to save and return to F16.

**Notes: -**

- In case Bluetooth name and/or password is/are changed, instrument will display reset before returning to F16.
- Reset means new Bluetooth name and/or pin has/have been successfully changed.

#### **13.7.4 Bluetooth Default Settings when Android is selected**

Instrument does not support name or pin checking/setting under the Android mode.

#### **13.7.5 Using App via Bluetooth Module by Third Party**

Third party Bluetooth module may be used with instrument. Preferred Bluetooth type as below.

##### **13.7.5.1 Bluetooth Module for iOS device: -**

- Serial based Bluetooth 4.0 BLE is recommended. If TTL based Bluetooth 4.0 BLE module is used, Comport 1 has to be set for TTL output. Contact your dealer for assistance.
- Baud rate of this module should be set to 115200
- Working mode of this module should be set to Slave
- Refer to **13.7.2** for settings on instrument.

##### **13.7.5.2 Bluetooth Module for Android device: -**

- Serial based Bluetooth 2.0 is recommended. If TTL based Bluetooth 2.0 module is used, Comport 1 has to be set for TTL output. Contact your dealer for assistance.
- Baud rate of this module should be set to 38400
- Working mode of this module should be set to Slave
- Refer to **13.7.2** for settings on instrument.

#### **13.7.6 Running App on a Smart Device**

1. Complete all connection according to paragraph **13.7 ~ 13.7.5.2**.
2. Download App from App Store or Google Play. Refer to **13.7** for more

information.

3. Power on instrument.
4. Start running App on Smart device.

#### **13.7.6.1 Connection via WIFI**

1. On the App starting page, select WIFI Connection.
2. Enter IP and Port number of the WIFI module.
3. Click Connect. Connection should start automatically. If not, click the Start icon on App.

#### **13.7.6.2 Connection via Bluetooth**

##### **13.7.6.2.1 Connection via iOS Bluetooth Module/Kit**

1. Make sure Bluetooth is enabled on iOS device.
2. It is not necessary to do Bluetooth pairing on iOS device. The App will do pairing automatically.
3. Start App.
4. On the App starting page, select Bluetooth Connection.
5. Scroll and select the correct Bluetooth Module/Kit name.
6. Click Connect. Connection should start automatically. If not, click the Start icon on App.

##### **13.7.6.2.2 Connection via Android Bluetooth Module/Kit**

1. Make sure Bluetooth is enabled on Android device.
2. For first time use, complete pairing with the Bluetooth module/Kit. Default password of the Bluetooth Module/Kit is 12345.
3. Start App.
4. On the App starting page, select Bluetooth Connection.
5. Click on the correct Bluetooth Module name.
6. Click Connect. Connection should start automatically. If not, click the Start icon on App.

# 14. Printing Formats

## 14.1 Lab 1 Print Format<sup>41</sup>

When Lab 1 is selected, output in default format will be generated with printed data sent. No header will be generated when line number is set = 00. See below table for print format and explanations.

Weighing Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	10:59:52	1 W	25.010kg	25.000kg	50.010kg	25.010kg		L
2015-06-26	10:59:55	2 W	49.990kg	25.000kg	74.990kg	75.000kg		L
2015-06-26	10:59:59	3 W	75.000kg	25.000kg	100.000kg	150.000kg		A
2015-06-26	11:00:05	4 W	99.990kg	25.000kg	124.990kg	249.990kg		A

Piece Counting Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:00:26	1 C	100 P	25.000kg	50.000kg	25.000kg	250.038	g
2015-06-26	11:00:30	2 C	200 P	25.000kg	74.990kg	74.990kg	250.038	g
2015-06-26	11:00:33	3 C	300 P	25.000kg	100.010kg	150.000kg	250.038	g L
2015-06-26	11:00:36	4 C	400 P	25.000kg	125.000kg	250.000kg	250.038	g L

ATM Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:02:16	1 W	25.000kg	25.000kg	50.000kg	25.000kg		L
2015-06-26	11:02:19	2 W	24.990kg	50.000kg	74.990kg	49.990kg		L
2015-06-26	11:02:21	3 W	25.000kg	75.000kg	100.000kg	74.990kg		L
2015-06-26	11:02:24	4 W	25.000kg	99.990kg	124.990kg	99.990kg		L

Animal Function		No.	NET	TARE	GROSS	TOTAL	REF.	R
DATE	TIME							
2015-06-26	11:14:09	1 W	25.000kg	24.990kg	49.990kg	25.000kg		
2015-06-26	11:14:33	2 W	75.000kg	24.990kg	99.990kg	100.000kg		
2015-06-26	11:15:05	3 W	125.000kg	24.990kg	149.990kg	225.000kg		
2015-06-26	11:15:13	4 W	50.000kg	24.990kg	74.990kg	275.000kg		

- Date = Date of Printing
- Time = Time of Printing
- No. = Number of transaction. Data type W = Individual Weighing/ATM/Animal, C = Counting, M = memory recall data
- Net = Net result. Quantity of pieces for piece count mode. Weight for all other function.
- Tare = Tare Weight
- Gross = Gross Weight
- Total = Total accumulated weights
- Ref = Unit piece Weight (Piece Count function only)

<sup>41</sup> Lab 1 format does not support Customer or Produce Code.

- R = Check result (when check mode is in effect). A = OK, L = LO, H = HI

## 14.2 Standard Lab 2 Print Format<sup>42</sup>

Standard ticket/receipt printout of various function modes are described illustrated below.

### 14.2.1 Standard Lab 2 print format for Weighing & ATM mode

Refer to below diagram for printout content.

Time	09:39:21
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Net	3.751kg
Tare	0.000kg
Gross	3.751kg
Total	7.502kg
High	8.000kg
Low	3.000kg
Accept	

#### *Data Explanation*

*Time of Printout*

*Date of Printout*

*Accumulation No.*

*Customer Code (If entered)*

*Product Code (If entered)*

*Net Weight*

*Tare Weight*

*Gross Weight*

*Total Accumulated Net Weight*

*Hi Limit (If entered)*

*Lo Limit (If entered)*

*Comparison Result*

<sup>42</sup> When Lab 2 is selected under in F16 and/or F17

### 14.2.2 Standard Lab 2 print format for Piece count mode

Refer to below diagram for printout content.

Time	09:41:04
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Net	3.751kg
Unit.W	75.0145 g
Count	50pcs
Total	7.502kg
Total	100pcs
High	80pcs
Low	30pcs
Accept	

#### Data Explanation

Time of Printout  
Date of Printout  
Accumulation No.  
Customer Code (If entered)  
Product Code (If entered)  
Net Weight  
Unit Weight  
Pieces  
Total Accumulated Net Weight  
Total Accumulated Pieces  
  
Hi Limit (If entered)  
Lo Limit (If entered)  
Comparison Result

### 14.2.3 Standard Lab 2 print format for Animal weighing mode

Refer to below diagram for printout content.

Time	10:07:15
Date	2016-09-10
Seq	2
Name	ANDHFYROLSJFHEIOMC
Pcode	562188261631321879
Hold.W	12.503kg
Total	25.006kg

#### Data Explanation

Time of Printout  
Date of Printout  
Accumulation No.  
Customer Code (If entered)  
Product Code (If entered)  
Animal Net Weight  
Total Accumulated Net Weight

### 14.3 Customizing Lab 2 Print Format<sup>43</sup>

Custom printout is available for the below modes: -

- Weighing.
- Auto-Tare-Memory.
- Piece Count.
- Animal weighing.

---

43 When Lab 2 is selected under in F16 and/or F17

19 variants + 2 commands (**Cr LF and End**) are available for custom print output format. Refer to the below **Print output format variants table** for more detail.

#### 14.3.1 Print output format variants table

Symbol	Description
End	Edit finished
Cr LF	Insert one blank row
dAtE	Date of printing
tiME	Time of print
nEt	Net weight
tArE	Tare weight
GroSS	Gross weight
Unit	Average piece weight
Count	Number of piece
H rEF	HI limit
L rEF	LO limit
Ani	Weight Hold (Animal weighing)
Ch rES	Comparison result
trAnS	Transaction sequent number (if this transaction is accumulated to memory)
ACC	Total accumulated weight (when accumulation function is in effect)
SiGn	Signature
P Code	Product code
Id	Machine ID
GrouP	Machine group number
oPCodE	Operator number
C CodE	Customer code



### 14.3.2 To edit custom Lab 2 print output format

Follow the below steps to create custom printout.

- Go to internal function and select the desired function number to edit,
- Select **CUSTOM** and press **[Print/M+]**,
- This instrument displays **Line 1** and the last variant or command (see **14.3.1** for details) stored,
- Press **[Print/M+]** to confirm or select other variant or command by press **[FUNC/SET]** or **[MR/UNIT]**. Then press **[Print/M+]** to confirm and save,
- This instrument displays **Line 2** and the last variant or command stored,
- Repeat steps **d** and **e** for other lines,
- To finish editing, select command **End**, then press **[Print/M+]** to confirm.
- This instrument returns to and displays the current internal function number,
- If required, repeat steps **a** to **h** to create and edit custom printout format for other modes.

### 14.4 Lab 3 Print Format<sup>44</sup>

Current working mode and all related data are sent under this mode. Refer to below table for data output format.

Function & Output	Weighing	Count	ATM	Peak Hold	Animal
Data 1	Opr	Opr	Opr	Opr	Opr
Data 2	Seq	Seq	Seq	(Blank)	Seq
Data 3	0	1	2	3	4
Data 4	Mac	Mac	Mac	Mac	Mac
Data 5	MacGp	MacGp	MacGp	MacGp	MacGp
Data 6	Date	Date	Date	Date	Date
Data 7	Time	Time	Time	Time	Time
Data 8	Name	Name	Name	Name	Name
Data 9	Pcode	Pcode	Pcode	Pcode	Pcode
Data 10	Gross	Gross	Gross	Tare	Gross
Data 11	Tare	Tare	Tare	Peak	Tare

---

<sup>44</sup> When Lab 3 is selected under in F16 and/or F17

<b>Data 12</b>	Net	Net	Net	Unit	Net
<b>Data 13</b>	Low	Total.W	Low	CR LF	Total.W
<b>Data 14</b>	High	Unit	High		Unit
<b>Data 15</b>	Result	Count	Result		CR LF
<b>Data 16</b>	Total.W	Unit.W	Total.W		
<b>Data 17</b>	Unit	Unit	Unit		
<b>Data 18</b>	CR LF	Low	CR LF		
<b>Data 19</b>		High			
<b>Data 20</b>		Result			
<b>Data 21</b>		Total.C			
<b>Data 22</b>		CR LF			

**Note:** - Semi colon is inserted between data.

#### 14.5 Lab 4 Print Format<sup>45</sup>

Transaction data is sent in journal output format with gross and net weight of each individual transaction. Refer to below diagram for details.

Name ANDHFYROLSJFHEIOMC		
Pcode 562188261631321879		
Opr 8888		
Mac 1234		
MacGp 56		
Date 2016-09-09		
Time 13:54:08		
Seq	Gross	Net
001	2.499	2.499 kg
002	2.499	2.499 kg
003	5.001	5.001 kg
004	5.002	5.002 kg
005	7.502	7.502 kg
006	2.499	2.499 kg
-----		
006	25.002	kg

#### Data Explanation

*Customer Code (if entered)*

*Product Code (If entered)*

*Operator No. (If entered)*

*Machine ID (If entered)*

*Machine Group No. (If entered)*

*Date of 1st Printout*

*Time of 1st Printout*

*Accumulation No., Gross Weight and Net Weight or Pieces*

*Total Accumulation No. and Total Net Weight or Pieces*

<sup>45</sup> When Lab 4 is selected under in F16 and/or F17.

## 14.6 Lab 5 Print Format<sup>46</sup>

Transaction data is sent in journal output format with time and net weight of each individual transaction. Refer to below diagram for details.

Name	ANDHFYROLSJFHEIOMC	
Pcode	562188261631321879	
Opr	8888	
Mac	1234	
MacGp	56	
Date	2016-09-09	
Seq	Time	Net
001	14:08:51	2.499 kg
002	14:08:55	5.002 kg
003	14:08:59	5.002 kg
004	14:09:02	7.502 kg
005	14:09:06	10.004 kg
006	14:09:09	7.502 kg
-----		
006	Total	37.511 kg

### *Data Explanation*

*Customer Code (if entered)*

*Product Code (If entered)*

*Operator No. (If entered)*

*Machine ID (If entered)*

*Machine Group No. (If entered)*

*Date of 1st Printout*

*Accumulation No., Time of Printout and Net Weight or Pieces*

*Total Accumulation No. and Total Net Weight or Pieces*

## 15. Label Printing

This instrument supports the below label printer models: -

- LP50 by Datecs ([www.datecs.bg/en](http://www.datecs.bg/en))
- TDP247, TDP345 by TSC ([www.tscprinters.com](http://www.tscprinters.com))
- TTP247, TTP345 by TSC ([www.tscprinters.com](http://www.tscprinters.com))

### Notes: -

- Set all preferred operation parameters according to F16 and/or F17 listed on **5.4**.
- Refer to **Appendix E** for TSC printer installation and setup procedures.
- Refer to **Appendix F** for detail on how to create and upload label to TSC printer by Bartender Label software.

### Cautions: -

1. Do not combine data of different working modes on the same label.
2. Do not print any labels of non-current working mode. This will retrieve

---

<sup>46</sup> When Lab 5 is selected under in F16 and/or F17.

wrong data of non-current working mode.

3. Print only label data when the same working mode in operation.
4. Do not combine data of various working modes on same label. This will retrieve wrong data of non-current working mode.

## **15.1 Label Format Groups & Label File Names**

2 label format groups are available, these are: -

- FL1 (label file group 1), and
- FL2 (label file group 2).

### **15.1.1 FL1 (Label Format Group 1)**

**FL1** (format group 1) is for current transaction data printing (during normal working status).

100 printout selections (00 ~ 99) are available in format group 1. In order to trigger the preferred label to be printed, label files stored in printer for this format group 1 must have a file name of AA01, AA02, AA03.... AA99.

- **FL1 00:** - Select this to disable current transaction label printing.
- **FL1 01:** - Select this to print label file AA01 stored in printer.
- **FL1 02:** - Select this to print label file AA02 stored in printer.
- ....
- **FL1 98:** - Select this to print label file AA98 stored in printer.
- **FL1 99:** - Select this to print label file AA99 stored in printer.

### **15.1.2 FL2 (Label Format Group 2)**

**FL2** (format group 2) is for totalized (MR) data printing (during normal working status).

100 printout selections (00 ~ 99) are available in format group 2. In order to trigger the preferred label to be printed, label files stored in printer for this format group 1 must have a file name of BB01, BB02, BB03.... BB99.

- **FL2 00:** - Select this to disable totalized (MR) data label printing.
- **FL2 01:** - Select this to print label file BB01 stored in printer.

- **FL2 02:** - Select this to print label file BB02 stored in printer.
- ....
- **FL2 98:** - Select this to print label file BB98 stored in printer.
- **FL2 99:** - Select this to print label file BB99 stored in printer.

## 15.2 Label Programming

Prompt commands, information description, working mode and suggested length on label are listed on the below table.

**Caution:** - Do not combine information of different working mode on the same label.

### 15.2.1 Label programming information table

Prompt Command <sup>47</sup>	Description	Working Mode <sup>48</sup>	Suggested Length
b	Product Code	All	18
c	Total accumulated pieces	Piece count	10
d	Machine ID	All	4
e	Machine Group Number	All	2
f	Operator Number	All	4
K	Date	All	10
L	Time	All	8
M	No. of accumulated transaction (8 digits with leading space)	All	8
m	No. of accumulated transaction (6 digits with leading zero)	All	6

<sup>47</sup> Prompt commands are case sensitive.

<sup>48</sup> "All" means the information is good for all working modes.

N	Total accumulated weight	Weighing ATM	9
n	Total accumulated weight without unit or decimal	Weighing ATM	6
O	Net weight	All	10
o	Net weight without unit or decimal	All	6
P	Tare weight	All	10
p	Tare weight without unit or decimal	All	6
Q	Gross weight	All	10
q	Gross weight without unit or decimal	All	6
R	HI limit <sup>49</sup>	All	10
S	LO limit <sup>50</sup>	All	10
T	Comparison Result	All	11
U	Number of piece	Piece Count	10
V	Average piece weight	Piece Count	9
Y	Weight hold	Animal Weighing	11
y	Weight hold without unit or decimal	Animal Weighing	6
Z	Customer Code	All	18

49 Each working mode has its own Hi Limit format (weight for weighing & auto tare memory mode; pieces for piece count mode; % for percentage mode). If Hi Limit has to be printed, set Hi Limit value under the preferred working mode.

50 Each working mode has its own Lo Limit format (weight for weighing mode& auto tare memory; pieces for piece count mode; % for percentage mode). If Hi Limit has to be printed, set Hi Limit value under the preferred working mode.



3. Press **[CHECK]**. Instrument displays number of copy to generate each time. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred parameter appears then press **[PRINT/M+]** to save.
4. Instrument displays label file number (FL1 01 ~ FL1 99) to print in label format group 1. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred label file number appears then press **[PRINT/M+]** to save.
5. Instrument displays label file number (FL2 01 ~ FL2 99) to print in label format group 2. Press **[FUNC/SET]** or **[MR/UNIT]** until the preferred label file number appears then press **[PRINT/M+]** to save.
6. At this point, label settings are completed.

## 15.4 Repetitive Printout

This Instrument supports repetitive printout under Manual print mode. Press **[PRINT/M+]** for additional printout copies.

Conditions and criteria as below: -

- a. When Auto Accumulation is set to On: Repetitive print is only possible when the actual weight on scale is equal to the weight value of the 1<sup>st</sup> printout.
- b. When Auto Accumulation is set to Off: Repetitive print is possible if minimum output weight set is matched and when **[PRINT/M+]** is pressed.
- c. Weight value of repetitive printout will not change the total accumulation result. Only the weight value of the 1<sup>st</sup> printout will be accumulated to memory.

## 16. Built-in Battery & Recharging

### 16.1 Battery Operation Time

Remaining battery power of the built-in rechargeable battery is displayed by the **Battery Power/Level Indicator**.

### 16.2 Symbols & Remaining Power



Full Battery:  $\geq 6.3V$ .



2 Blocks:  $\geq 6.0V$  (Battery level~75%).




1 Block:  $\geq 5.7V$  (Battery level~20%).




 Frame only: <5.7V (Battery level is less than 15%).

### 16.3 Battery Recharge

When  appears, it means that the built-in rechargeable battery is at low voltage status. It is recommended to recharge as soon as possible.

To protect the built-in rechargeable battery, this instrument will be powered off automatically when battery is at extremely low level. If this is the case, do not attempt to power this instrument on. Recharge this instrument immediately. Fail to do so may cause unrecoverable damages to the built-in rechargeable battery.

Battery charging status is shown by the Battery Power/Level Indicator: -

- Progressing: - Recharging in process.
- Flashing : - Recharge completed.

Battery recharge is possible while operating. Overcharge protection circuit is inside to prevent battery damages from overcharge.

**Notes: -**

- This instrument will auto power on when an energized power adaptor is plugged in.
- The backlight remains switched on when an energized power adaptor is plugged in.

## 17. Error Codes

Error Code No.	Description
Err 1	Time value error
Err 2	Date value error
Err 3	Exceed manual zero
Err 4	Offset out of range/unstable during power on (5 minutes for OIML and NTEP mode)

<b>Err 5</b>	No load cell detected
<b>Err 6</b>	Tare operation error
<b>Err 7</b>	Logic error. HI limit set is lower than LO limit (and HI is not = 0)
<b>Err 8</b>	Logic error. LO limit is higher than HI limit (and HI is not = 0)
<b>Err 13</b>	Exceed maximum power on
<b>Err 19</b>	Capacity or division setting error (Division set is higher than 10000d)
<b>Err 22</b>	Manual Zero and Tare stability error
<b>Err 23</b>	Capacity setting error, Capacity 1 > Capacity 2
<b>Err 24</b>	Division setting error, e1 > e2
<b>Err 25</b>	Span gain is too low
<b>Err 26</b>	Not able to obtain stable status for longer than 10 sec
<b>Err 27</b>	<ul style="list-style-type: none"> <li>Calculated value per e of Cal 2 varies more than 1% as of Cal 1. Properly a load cell problem.</li> <li>Mass value of Cal 2 is less than 150% of Cal 1.</li> </ul>
<b>Err 28</b>	Maximum accumulation limit is exceeded.
<b>Err 43</b>	Cannot communicate Bluetooth Module
<b>--oL--</b>	Overload (Gross weight is more than Max plus 9d)
<b>HALT</b>	Major system error detected. Power off instrument and remove power adaptor immediately. Then check load cell connection and system power status.
<b>UndEr</b>	Negative Weight values exceeds display range
<b>Reboot</b>	Important parameters have been changed. Power off and then power on instrument again to reboot.

## 18. Daily Care & Maintenance

1. Clean the instrument with a soft, damp cloth. If necessary, use a mild detergent in water.
2. Do not use any harsh, abrasive material, acetone, volatile solvent, thinner or alcohol for cleaning.
3. Verify the accuracy of this instrument periodically. Re-calibrate if necessary. In some countries, calibration requires authorized/qualified agent. Contact your dealer for more information.
4. Store this instrument in a dry and clean place.
5. Recharge battery before and every 4 months during long time storage.

## 19. Downloading All Appendixes

For environment protection and information updating speed, all Appendixes of this manual are listed on the full manual version which is available for download at: -


[www.fi-measurement.com/resource/manuals](http://www.fi-measurement.com/resource/manuals)

## 20. Appendix A: - Keyboard Commands<sup>51</sup>

Keyboard commands can be sent to this instrument from computer through any standard communication program to simulate keyboard entries.

To enable keyboard commands, connect the external peripheral which generates keyboard commands to Comport 2 and set Comport 2 to CMD. Keyboard Command format as below: -

- a. Hex code 0D (CR), then
- b. Hex code 0A (LF) then
- c. Letter shown on below illustration diagram, then
- d. Space (Hex code 20).



<sup>51</sup> Keyboard commands are case sensitive.

# 21. Appendix B: - PC Output Protocols

Data Code	Description
,	Comma
+, -	Polarity Sign Positive = space, Negative = minus (-)
P	Polarity Sign Positive = 0, Negative = minus (-) Control command <ul style="list-style-type: none"> <li>• ETX : End of Text</li> <li>• STX : Start of Text</li> <li>• CF : Carriage Return</li> <li>• LF : Line Feed</li> <li>• SOH : Start of Heading</li> <li>• = : ASCII equal sign (DEC 61, HEX 3D)</li> </ul>
C	
G/N	Gross/Net <ul style="list-style-type: none"> <li>• NT = Net weight</li> <li>• GS = Gross weight</li> </ul>
NET	Net Weight
S	Status Code <ul style="list-style-type: none"> <li>• ST for Stable</li> <li>• US for unstable</li> </ul>
R	Revered 7 digits weight value including location of decimal point. If there is no decimal point, then the last character = space.
SP	Space
SWA	Status Word A
SWB	Status Word B
U	Weight Unit <ul style="list-style-type: none"> <li>• kg = kilogram</li> <li>• lb = pound</li> <li>• g(space) = gram</li> </ul>
W	7 digits weight value including location of decimal point. If there is no decimal point, then the first character = space.

Weight

Protocol 1

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
s	s	,	G	N	+	-	w	w	w	w	w	w	,	u	u	c	c
S	T		G	S				1		0	0	0		k	g	CR	LF
S	T		G	S	-			0		0	1	2		k	g	CR	LF
S	T		G	S		2	2	0		4	5	0		l	b	CR	LF

220.450lb

1.000kg

-0.012kg

Protocol 2

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
c	SWA	SWB	SP	Field 1 (Net Weight)				Field 2 (Tare Weight)				CR				CR
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
STX	5	7		0	0	0	0	1	5	0	0	2	0	0	0	CR
STX	5	!		2	2	0	4	5	0	1	0	0	0	0	0	CR

Net

-0.015kg

220.450lb

Tare Value  
2.000kg  
100.000lb

Protocol 3

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
c	c	SP	+	-	w	w	w	w	w	w	SP	u	u	SP	SP	SP	c	c	c
SOH	STX					1		0	0	0		k	g				CR	LF	LF
SOH	STX		-			0		0	1	5		k	g				CR	LF	LF
SOH	STX			2	2	0		4	5	0		l	b				CR	LF	LF

1.000kg

-0.015kg

220.450lb

Protocol 4

1	2	3	4	5	6	7	8	9
c	c	r	r	r	r	r	r	p
=	0	0	0	.	1			0
=	5	1	0	.	0			-
=	0	0	5	4	.	0	2	0

1.000kg

-0.015kg

220.450lb

Protocol 5

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
s	s	,	G	N	,	+	-	w	w	w	w	w	w	u	u	c	c
S	T		G	S					1	.	0	0	0	0	k	g	CR
S	T		G	S		-			0	.	0	1	5	k	g	CR	LF
S	T		G	S			2	2	0	.	4	5	0	l	b	CR	LF

1.000kg

-0.015kg

220.450lb

### Protocol 6

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	NET		SP	+-	w	w	w	w	w	w	w	u	u	c	c
N	E	T					1	.	0	0	0	k	g	CR	LF
N	E	T		-			0	.	0	1	4	k	g	CR	LF
N	E	T			2	2	0	.	4	5	0	l	b	CR	LF

1.000kg  
-0.014kg  
220.450lb

### Protocol 7

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
c	c	SP	+-	w	w	w	w	w	w	w	SP	u	u	SP	SP	SP	c	c
SOH	STX					1	.	0	0	0	0	k	g				CR	LF
SOH	STX		-	2	2	0	.	0	1	5		k	g				CR	LF
SOH	STX			2	2	0	.	4	5	0		l	b				CR	LF

1.000kg  
-0.015kg  
220.450lb

### Protocol 8

1	2	3	4	5	6	7	8	9	10
c	+-	w	w	w	w	w	w	w	c
STX		1	.	0	0	0	0	0	ETX
STX	-			0	.	0	1	5	ETX
STX		2	2	0	.	4	5	0	ETX

1.000kg  
-0.015kg  
220.450lb

### Protocol 9

1	2	3	4	5	6	7	8	9	10	11	12
c	+-	SP		w	w	w	w	w	u	u	c
STX				1	.	0	0	0	k	g	ETX
STX	-			0	.	0	1	5	k	g	ETX
STX		2	2	0	.	4	5	0	l	b	ETX

1.000kg  
-0.015kg  
220.450lb

## 22. Appendix C: - Operation Result Commands<sup>52</sup>

Operation Result commands are those commands which are used to request operation result and details from this instrument. These commands can be sent to this instrument from computer through any standard communication program. Command format as below: -

- a. Hex code 0D (CR), then
- b. Hex code 0A (LF), then
- c. Command code listed on below command table, then
- d. Space (Hex code 20).

Refer to below table for commands details.

**Operation Result Commands Table**

Prompt Command <sup>53</sup>	Description
<b>b</b>	Product Code
<b>c</b>	Total accumulated pieces
<b>d</b>	Machine ID
<b>e</b>	Machine Group Number
<b>f</b>	Operator Number
<b>g</b>	Customer Code
<b>J</b>	Current status, weight and tare weight values
<b>K</b>	Date
<b>L</b>	Time

52 Connect the external peripheral which generates operation result commands to Comport 2 and set Comport 2 to CMD.

53 Prompt commands are case sensitive.



<b>M</b>	No. of accumulated transaction
<b>N</b>	Total accumulated weight
<b>n</b>	Total accumulated weight without unit or decimal
<b>O</b>	Net weight
<b>o</b>	Net weight without unit or decimal
<b>P</b>	Tare weight
<b>p</b>	Tare weight without unit or decimal
<b>Q</b>	Gross weight
<b>q</b>	Gross weight without unit or decimal
<b>R</b>	HI limit
<b>S</b>	LO limit
<b>T</b>	Comparison Result
<b>U</b>	Number of piece
<b>V</b>	Average piece weight
<b>Y</b>	Weight hold
<b>y</b>	Weight hold without unit or decimal
<b>Z</b>	Read internal count (AD) value

## 23. Appendix D: - System Parameter Inquiry Commands<sup>54</sup>

System parameter inquiry commands are used to check system parameter settings. Command format as below: -

- Hex code 0D (ASCII code \$0D), then
- Hex code 0A (LF) (ASCII code \$0A) then
- Command code listed on below table (all commands are case sensitive), then
- Hex code 20 (ASCII code \$20).

Command Code	Description	Number & Description Responded Parameters Notes: - a. If more than one parameter, semi colon separation is inserted between parameters. b. Response from instrument always end up with Hex code 0D 0A
Aa	Calibration weight unit and application	<ul style="list-style-type: none"> <li><b>d1</b> = calibration weight unit: - 0 = kg; 1 = lb.</li> <li><b>d2</b> = application: - 0 = none; 1 = OIML; 2= NTEP</li> </ul>
Ab	Decimal format, decimal point of kg, g and lb	<ul style="list-style-type: none"> <li><b>d1</b> = decimal format: - 0 = dot; 1 = comma</li> <li><b>d2</b> = kg: - 0 = no decimal; 1 = 1 decimal place..... 4 = 4 decimal place</li> <li><b>d3</b> = g: - 0 = no decimal; 1 = 1 decimal place..... 4 = 4 decimal place; n = not</li> </ul>

<sup>54</sup> Connect the external peripheral which generates system parameter inquiry commands to Comport 2 and set Comport 2 to CMD.

		<p>applicable</p> <ul style="list-style-type: none"> <li>• <b>d4</b> = lb: - 0 = no decimal; 1 = 1 decimal place..... 4 = 4 decimal place</li> </ul>
Ac	Capacity1 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = capacity in kg. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d2</b> = capacity = g. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d3</b> = capacity = lb. Data length = 8 including decimal with leading space (Hex code 20)</li> </ul>
Ad	Capacity 2 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = mode: - 0 = Off; 1 = dual weighing range; 2 = dual interval</li> <li>• <b>d2</b> = capacity in kg. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d3</b> = capacity = g. Data length = 8 including decimal with leading space (Hex code 20)</li> <li>• <b>d4</b> = capacity = lb. Data length = 8 including decimal with leading space (Hex code 20)</li> </ul>
Ae	Division 1 of kg, g, lb	<ul style="list-style-type: none"> <li>• <b>d1</b> = kg: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li>• <b>d2</b> = g: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>

		<ul style="list-style-type: none"> <li><b>d3</b> = lb: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>
Af	Division 2 of kg, g, lb	<ul style="list-style-type: none"> <li><b>d1</b> = kg: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li><b>d2</b> = g: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> <li><b>d3</b> = lb: - 0 = 1; 1 = 2; 2 = 5; 3 = 10; 4 = 20; 5 = 50</li> </ul>
Ag	Gravity Factor of Calibration Place and Operation Place	<ul style="list-style-type: none"> <li><b>d1</b> = gravity factor of calibration place. Data length = 8 including decimal with leading space (Hex code 20).</li> <li><b>d2</b> = gravity of location of operation place. Data length = 8 including decimal with leading space (Hex code 20).</li> </ul>
Ah	Linearity Compensation Function	0 = Off; 1 = On
Ai	ad value of zero point (offset) value, weight value of LD1, ad value of LD1, weight value of LD2 and ad value of LD2	<ul style="list-style-type: none"> <li><b>d1</b> = ad value of zero point. Data length = 8 including decimal with leading space (Hex code 20).</li> <li><b>d2</b> = weight value of LD1. Data length = 8 including decimal with leading space (Hex code 20).</li> <li><b>d3</b> = ad value of LD1. Data length = 8 (integers only) with leading space (Hex code 20).</li> <li><b>d4</b> = weight value of LD2. Data length = 8 including</li> </ul>

		<p>decimal with leading space (Hex code 20).</p> <ul style="list-style-type: none"> <li><b>d5</b> = ad value of LD2. Data length = 8 (integers only) with leading space (Hex code 20).</li> </ul>
Aj	ad value of zero point (offset), span weight value, net span AD value	<ul style="list-style-type: none"> <li><b>d1</b> = as value of zero point. Data length = 8 (integers only) with leading space (Hex code 20).</li> <li><b>d2</b> = span weight value. Data length = 8 including decimal with leading space (Hex code 20).</li> <li><b>d3</b> = net span AD value. Data length = Data length = 8 (integers only) with leading space (Hex code 20)</li> </ul>
Ak	Weight unit enable/disable for kg, g and lb	<ul style="list-style-type: none"> <li><b>d1</b> = kg: - 0 = Off; 1 = On</li> <li><b>d2</b> = g: - 0 = Off; 1 = On</li> <li><b>d3</b> = lb: - 0 = Off; 1 = On</li> </ul>
Al	Filter strength	0 = level 1; 1 = level 2; ... ;7 = level 8; 8 = level 9
Am	Initial Zero range, manual zero range, auto zero tracking speed	<ul style="list-style-type: none"> <li><b>d1</b> = initial zero range: - 0 = Off, 1 = 1%, 2 = 2%; ... 5 = 5%; 6 = 10%; 7 = 20%</li> <li><b>d2</b> = manual zero range: - 0 = 1%; 1 = 2%; 2 = 3%; 3 = 4%; 4 = 5%; 5 = 10%; 6 = 20%; 7 = 50%; 8 = 75%; 9 = 100%</li> <li><b>d3</b> = auto zero tracking speed: - 00 = Off; 01 = 0.25e; 02 = 0.50e; 03 =</li> </ul>

		10e; 04 = 1.5e; 05 = 2.0e; 06 = 2.5e; 07 = 3.0e; ....; 09 = 5e; 10 = 7.5e; 11 = 10e
An	Auto tare, repetitive tare and preset tare	<ul style="list-style-type: none"> <li>• <b>d1</b> = auto tare: - 0 = Off; 1 = On; 2= Continuous</li> <li>• <b>d2</b> = repetitive tare: - 0 = Off; 1 = On</li> <li>• <b>d3</b> = Preset tare: - 0 = Off; 1 = On</li> </ul>
Ao	Stability control of manual zero and manual tare	<ul style="list-style-type: none"> <li>• <b>d1</b> = manual zero stability control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d2</b> = manual tare stability control: - 0 = no (disable); 1 = Yes (enable)</li> </ul>
Ap	Auto power off time, backlight brightness, color ratio, keypad buzzer and system buzzer	<ul style="list-style-type: none"> <li>• <b>d1</b> = auto power off time: - 0 = Off; 1 = 1 minute; 2 = 3 minute; 3 = 5 minute; 4 = 10 minute; 5 = 20 minute</li> <li>• <b>d2</b> = backlight brightness (01 ~ 99). 01 = lowest, 99 = highest.</li> <li>• <b>d3</b> = color ratio (01 ~ 99). 01 = least red output, 99 = highest red output</li> <li>• <b>d4</b> = keypad buzzer: - 0 = Off; 1 = On</li> <li>• <b>d5</b> = system buzzer: - 0 = Off; 1 = On</li> </ul>
Aq	Check result buzzer, near zero value, high limit for weighing, low limit for weighing, high	<ul style="list-style-type: none"> <li>• <b>d1</b> = check result buzzer: - 0 = Off; 1 = In; 2 = Out; 3 = hi, 4 = lo</li> <li>• <b>d2</b> = near zero value. Data length = 8 with leading</li> </ul>

	limit for counting, low limit for counting	<p>space (Hex code 20)</p> <ul style="list-style-type: none"> <li>• <b>d3</b> = Hi Limit for weighing. Integer only. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d4</b> = Lo Limit for weighing. Integer only. Data length = 8 including decimal with leading space (Hex code 20).</li> <li>• <b>d5</b> = Hi Limit for counting. Integer only. Data length = 8 (integers only) with leading space (Hex code 20).</li> <li>• <b>d6</b> = Lo Limit for counting. Integer only. Data length = 8 (integers only) with leading space (Hex code 20).</li> </ul>
Ar	Comport 1 working mode, baud rate, output protocol, print stability control, transmission interval, Auto Accumulation, number of copy, check result control, print format, label format group 1 file number, label format group 2 file number, data length, parity, minimum output	<ul style="list-style-type: none"> <li>• <b>d1</b> = working mode: - 0 = Auto 1; 1 = Auto 2; 2 = Auto 3; 3 = Manual; 4 = PC; 5 = Scanner; 6 = Off</li> <li>• <b>d2</b> baud rate: - 0 = 1200; 1 = 2400; 2 = 4800; 3 = 9600; 4 = 19200; 5 = 38400; 6 = 57600; 7 = 115200; 8 = 256000</li> <li>• <b>d3</b> = protocol: - 0 = Protocol 1; 1 = Protocol 2; ... ; 8 = Protocol 9</li> <li>• <b>d4</b> = print stability control: - 0 = no (disable); 1 = Yes (enable)</li> </ul>

	weight value	<ul style="list-style-type: none"> <li>• <b>d5</b> = transmission interval: - 0 = int 0; 1 = int 0.5; 2 = int 1.0; 3 = int 1.5; .....; 9 = int 300.</li> <li>• <b>d6</b> = Auto Accumulation: - 0 = Off (disable); 1 = On (enable)</li> <li>• <b>d7</b> = number of copy: - 0 = 1 copy; ... 7 = 8 Copy</li> <li>• <b>d8</b> = check result control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d9</b> = print format: - 0 = Lab 1; 1 = Lab 2; 2 = Lab 3; 3= Lab 4; 4 = Lab 5; 5 = LP-50; 6 = TSC</li> <li>• <b>d10</b> =label format group 1 file number (00~99): - 00 = file AA00; 1 = file AA01; ...98 = file AA98; 99 = file AA99</li> <li>• <b>d11</b> = label format group 2 file number (00~99): - 00 = file BB00; 1 = file BB01; ...98 = file BB98; 99 = file BB99</li> <li>• <b>d12</b> = data length:- 0 = 7bit; 1 = 8bit</li> <li>• <b>d13</b> = parity: = 0 = none; 1 = Odd; 2 = even</li> <li>• <b>d14</b>: minimum output weight value: - 0 = from 00d; 01 = from 01d; ... ; 20 = from 20d. Data length = 2 with leading zero</li> </ul>
As	Comport 2 working	<ul style="list-style-type: none"> <li>• <b>d1</b> = working mode: - 0 =</li> </ul>



	<p>mode, baud rate, output protocol, print stability control, transmission interval, Auto Accumulation, number of copy, check result control, print format, label format group 1 file number, label format group 2 file number, data length, parity, minimum output weight value</p>	<p>Auto 1; 1 = Auto 2; 2 = Auto 3; 3 = Manual; 4 = PC; 5 = CMD; 6 = Off</p> <ul style="list-style-type: none"> <li>• <b>d2</b> baud rate: - 0 = 1200; 1 = 2400; 2 = 4800; 3 = 9600; 4 = 19200; 5 = 38400; 6 = 57600; 7 = 115200; 8 = 256000</li> <li>• <b>d3</b> = protocol: - 0 = Protocol 1; 1 = Protocol 2; ... ; 8 = Protocol 9</li> <li>• <b>d4</b> = print stability control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d5</b> = transmission interval: - 0 = int 0; 1 = int 0.5; 2 = int 1.0; 3 = int 1.5; .....; 9 = int 300.</li> <li>• <b>d6</b> = Auto Accumulation: - 0 = Off (disable); 1 = On (enable)</li> <li>• <b>d7</b> = number of copy: - 0 = 1 copy; ... 7 = 8 Copy</li> <li>• <b>d8</b> = check result control: - 0 = no (disable); 1 = Yes (enable)</li> <li>• <b>d9</b> = print format: - 0 = Lab 1; 1 = Lab 2; 2 = Lab 3; 3 = Lab 4; 4 = Lab 5; 5 = LP-50; 6 = TSC</li> <li>• <b>d10</b> =label format group 1 file number (00~99): - 00 = file AA00; 1 = file AA01; ...98 = file AA98; 99 = file AA99</li> <li>• <b>d11</b> = label format group 2</li> </ul>
--	--	--

		<p>file number (00~99): - 00 = file BB00; 1 = file BB01; ...98 = file BB98; 99 = file BB99</p> <ul style="list-style-type: none"> <li>• <b>d12</b> = data length:- 0 = 7bit; 1 = 8bit</li> <li>• <b>d13</b> = parity: = 0 = none; 1 = Odd; 2 = even</li> <li>• <b>d14</b>: minimum output weight value: - 0 = from 00d; 01 = from 01d; ... ; 20 = from 20d. Data length = 2 with leading zero</li> </ul>
At	Current weight unit and function mode	<ul style="list-style-type: none"> <li>• <b>d1</b> = weight unit: - 0 = kg; 1 = g; 2 = lb</li> <li>• <b>d2</b> = function mode: - 0 = weighing; 1 = piece count; 2 = AT 1; 3 = (reserved); 4= animal weighing</li> </ul>
Av	Auxiliary Function mode enable/disable status	<ul style="list-style-type: none"> <li>• <b>d1</b> = Piece count: - 0 = Off; 1 = On</li> <li>• <b>d2</b> = ATM: - 0 = Off; 1 = On</li> <li>• <b>d3</b> = (reserved): - 0 = Off; 1 = On</li> <li>• <b>d4</b> = Animal Weighing: - 0 = Off; 1 = On</li> </ul>
Aw	Machine ID & group number	<ul style="list-style-type: none"> <li>• <b>d1</b> = 4 digit machine ID number. Nothing = no machine ID is set</li> <li>• <b>d2</b> = 2-digit machine group number. Nothing = no group number is set</li> </ul>
Ax	Operator Number	<p>4-digit operator number. **** = no operator number is set</p>

## **24. Appendix E: - TSC Printer Installation & Setup Procedures**

### **E.1 Before Installation**

Get the below ready before printer installation.

1. An appropriate cable to connect printer and computer. This cable usually comes with the printer. If not, contact your printer supplier.
2. Printer installation driver. This driver usually comes with the printer. If not, contact your printer supplier.
3. Diagnostic tool for printer. This tool usually comes with the printer. If not, contact your printer supplier or download it at: -  
[www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)
4. TCF file for printer. The suitable TCF file can be downloaded at: -
  - For TDP247 and TDP345: -  
[www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)
  - For TTP247 and TTP345: -  
[www.fi-measurement.com/resource/driversnsoftwares](http://www.fi-measurement.com/resource/driversnsoftwares)



#### **E.1.1 Printer Installation**

1. Turn off the printer, connect the appropriate cable, and then turn on the printer.
2. If the printer supports Plug-and-Play, and you have connected it using a USB or Parallel cable, then the Windows Add Hardware Wizard will automatically detect the printer and display a dialog that allows you to install a driver. Click Cancel and do not install the driver using this wizard.
3. Run the Driver Wizard utility from the Installation Directory where the driver files are located.
4. Select Install Printer Drivers and complete the wizard.
5. The driver should now be installed.

## E.1.2 Uploading TCF File to Printer

In order to allow proper operation between this instrument and TSC label printer, a TCF file must be uploaded to printer.

1. Connect printer with computer.
2. Power on printer.
3. Download the correct TCF file point 4 of E.1.
4. Unzip the download file and save in to computer.
5. Run Diagnostic tool for printer.
6. Click on Command Tool.
7. Click on Send file.
8. Double click on the TCF file and it will be uploaded to printer automatically.



## 25. Appendix F: - Create & Upload Label to TSC Printer

### F.1 Selecting the Correct Edition for Bartender Software



To enable label uploading from computer to TSC printer, it is necessary to run as Bartender as Automation or Enterprise Automation edition. Procedures as below: -

1. Install Bartender Software to computer. The Bartender software usually comes with the TSC printer. If not, please contact your printer supplier.
2. Run Bartender, then click on Help, then click on Edition Selection.
3. Select Enterprise Automation or Automation, then click OK.
4. At this point, correct Bartender edition is selected.

### F.2 Adding Information from Instrument to Label & Uploading to a TSC Printer

The below procedures are based on Bartender Label Software. If a different label creating software is used, contact your label software for more details if in doubt.

1. Create the foundation of a label by Bartender. All information to be obtained from instrument should be added afterward.
2. Once the label foundation has been completed; (a) click on File and (b) select Export Printer Code Template.
3. On Print System; (a) select TSC KP-100/200 (Flash) and (b) select to Port.
4. Click More Option.
5. Then (a) click Print Dialog Data Sources, then (b) click on Format ID/Name.



6. On Template Field, select Template Field for Type.

7. Enter the correct label file name on Name/Value. Refer to **15.1** for correct file name format.

8. (a) click Copies, check KDU and (b) input asterisk (\*) on Prompt box.

9. Below procedures explain how to edit information to be obtained from instrument.

10. Click Template Object Data Sources and Select the object which information from instrument (for example net, gross, tare weight and product code) to be sent to printer and printed on label.

11. Double click on the preferred data source to which variant(s) has/have to add.

(a) check the box below External Keyboard, then





(b) enter the appropriate command on the Prompt Box (refer to **15.2.1** for command detail).

12. Select Auto on the Source box under Template Field

13. Repeat point 11 to ~ 12 for all other data sources.

14. Click OK.

15. Click Export. In case of Verification Messages appear, select one of method on the dialogue box to fix and click Continue.



### F.3 Sample Label

Sample label (for TSC printer)  
on right is available for  
download at: -

[www.fidelity-  
measurement.com/resource/dri  
versnsoftwares](http://www.fidelitymeasurement.com/resource/driversnsoftwares)

**Fidelity Measurement Company**

TSC Printer Sample Label



**Product No. Code**



Tare	kg	Gross	kg	Net
------	----	-------	----	-----

Packed By 1234

Machine ID 8888 Machine Group 22

Production Date / Time



Fidelity Measurement Co., Ltd.  
[www.fi-measurement.com](http://www.fi-measurement.com)  
e-mail: [info@fi-measurement.com](mailto:info@fi-measurement.com)